

ECMA

Standardizing Information and Communication Systems

**Protocol for Computer Supported
Telecommunications Applications
(CSTA) Phase III**

ECMA

Standardizing Information and Communication Systems

**Protocol for Computer Supported
Telecommunications Applications
(CSTA) Phase III**

Brief History

This Standard ECMA-285 defines Phase III of Protocol for Computer Supported Telecommunications Applications (CSTA) for OSI Layer 7 communication between a computing network and a telecommunications network. This Standard is part of a Suite of Standards and Technical Reports for Phase III of CSTA. All of the Standards and Technical Reports in the Suite are based on practical experience of ECMA member companies and each one represents a pragmatic and widely-based consensus.

The evolution of this Suite began with CSTA Phase I, which included only the CSTA Services and Protocol Standards (ECMA-179 and ECMA-180). In Phase II, Technical Report ECMA TR/68 was added illustrating how CSTA services and events may be used in typical call scenarios. That Technical Report reflected a common understanding of ECMA member companies.

Phase III of CSTA extends the previous Phase II Standards (ECMA-217 and ECMA-218) in major theme directions as well as numerous details. This incorporates technology based upon the *versit* CTI Encyclopedia (Version 1.0), which was contributed to ECMA by *versit*. Major areas of advancement include:

- New categories of services and events such as capabilities exchange, charging, media attach services, call data recording (CDR), etc.
- Additional services and events for call and device control.
- Enhancement to existing services and events.
- Organization of services and events to reflect a grouping based on function (call control, device control, etc.)

This ECMA Standard is contributed to ISO/IEC JTC1 under the terms of the fast-track procedure, for adoption as an ISO/IEC International Standard.

Adopted as Standard ECMA-285 by the General Assembly of December 1998.

ASN.1 Tools Acknowledgement

The ASN.1 specified in this Standard has been checked for conformance with the ASN.1 Standard by the OSS ASN.1 Tools.

Table of Contents

1	Scope	1
2	Conformance	1
2.1	Static Requirements	1
2.2	Dynamic Requirements	1
2.3	PICS Requirement	1
3	References	1
4	Definitions	2
5	CSTA Service Definition Model	2
5.1	CSTA Application Layer Structure	2
5.2	Remote Operations	2
5.3	The CSTA Service Response	2
5.4	Cross Referencing of Event Reports	3
5.5	Handling of Private Data	3
6	Interconnection service boundary	3
7	Security	3
8	Association Management	3
8.1	Implicit association	3
8.2	Dynamic association management using ACSE	3
8.2.1	Encoding of application context name	4
8.2.2	Encoding of application context information	4
9	CSTA parameter types	10
9.1	Switching function objects	10
9.2	Device Identifiers	11
9.3	Call and connection identifiers	13
9.4	Connection states	14
9.5	Status reporting	15
9.6	Device and feature types and other parameters	17
9.7	Security	22
9.8	Common extensions	23
9.9	Call control	24
9.10	Capability Exchange	26
9.11	Call Detail Record	72
9.12	Charge information	74

9.13	Data call types	75
9.14	Escape types	76
9.15	Media services	77
9.16	Physical device features	79
9.17	Data Collection	81
9.18	Event Cause	82
9.19	Error Value	84
10	Event Report Service	89
11	Capability exchange services	94
11.1	Services	94
11.1.1	Get logical device information	94
11.1.2	Get physical device information	96
11.1.3	Get switching function capabilities	97
11.1.4	Get switching function devices	100
11.1.5	Switching function devices	101
12	System services	102
12.1	Registration services	102
12.1.1	Change system status filter	102
12.1.2	System register	103
12.1.3	System register abort	104
12.1.4	System register cancel	105
12.2	Services	106
12.2.1	Request system status	106
12.2.2	System status	107
12.2.3	Switching function capabilities changed	108
12.2.4	Switching function devices changed	109
13	Monitoring services	110
13.1	Services	110
13.1.1	Change monitor filter	110
13.1.2	Monitor start	111
13.1.3	Monitor stop	112
14	Snapshot services	113
14.1	Services	113
14.1.1	Snapshot call	113
14.1.2	Snapshot device	115
14.1.3	Snapshot calldata	116
14.1.4	Snapshot devicedata	117

15	Call control services and events	118
15.1	Services	118
15.1.1	Accept call	118
15.1.2	Alternate call	119
15.1.3	Answer call	120
15.1.4	Call back call-related	121
15.1.5	Call back message call-related	122
15.1.6	Camp on call	123
15.1.7	Clear call	124
15.1.8	Clear Connection	125
15.1.9	Conference call	126
15.1.10	Consultation call	127
15.1.11	Deflect call	128
15.1.12	Dial digits	129
15.1.13	Directed pickup call	130
15.1.14	Group pickup call	131
15.1.15	Hold call	132
15.1.16	Intrude call	133
15.1.17	Join call	134
15.1.18	Make call	135
15.1.19	Make predictive call	136
15.1.20	Park call	138
15.1.21	Reconnect call	139
15.1.22	Retrieve call	140
15.1.23	Single step conference call	141
15.1.24	Single step transfer call	142
15.1.25	Transfer call	143
15.2	Events	144
15.2.1	Bridged	144
15.2.2	Call cleared	145
15.2.3	Conferenced	146
15.2.4	Connection cleared	147
15.2.5	Delivered	148
15.2.6	Digits dialed	149
15.2.7	Diverted	150
15.2.8	Established	151
15.2.9	Failed	152
15.2.10	Held	153
15.2.11	Network capabilities changed	154
15.2.12	Network reached	155
15.2.13	Offered	156
15.2.14	Originated	157
15.2.15	Queued	158
15.2.16	Retrieved	159
15.2.17	Service initiated	160

15.2.18	Transferred	161
16	Call associated features	162
16.1	Services	162
16.1.1	Associate data	162
16.1.2	Cancel telephony tones	163
16.1.3	Generate digits	164
16.1.4	Generate telephony tones	165
16.1.5	Send user information	166
16.2	Events	167
16.2.1	Call information	167
16.2.2	Charging	168
16.2.3	Digits generated	169
16.2.4	Telephony tones generated	170
16.2.5	Service completion failure	171
17	Media attachment services and events	172
17.1	Services	172
17.1.1	Attach media service	172
17.1.2	Detach media service	173
17.2	Events	174
17.2.1	Media attached	174
17.2.2	Media detached	175
18	Routeing services	176
18.1	Registration services	176
18.1.1	Route register	176
18.1.2	Route register abort	177
18.1.3	Route register cancel	178
18.2	Services	179
18.2.1	Re-Route	179
18.2.2	Route end	180
18.2.3	Route reject	181
18.2.4	Route request	182
18.2.5	Route select	183
18.2.6	Route used	184
19	Physical device features	185
19.1	Services	185
19.1.1	Button press	185
19.1.2	Get auditory apparatus information	186
19.1.3	Get button information	187
19.1.4	Get display	188
19.1.5	Get hookswitch status	189
19.1.6	Get lamp information	190

19.1.7	Get lamp mode	191
19.1.8	Get message waiting indicator	192
19.1.9	Get microphone gain	193
19.1.10	Get microphone mute	194
19.1.11	Get ringer status	195
19.1.12	Get speaker mute	196
19.1.13	Get speaker volume	197
19.1.14	Set button information	198
19.1.15	Set display	199
19.1.16	Set hookswitch status	200
19.1.17	Set lamp mode	201
19.1.18	Set message waiting indicator	202
19.1.19	Set microphone gain	203
19.1.20	Set microphone mute	204
19.1.21	Set ringer status	205
19.1.22	Set speaker mute	206
19.1.23	Set speaker volume	207
19.2	Events	208
19.2.1	Button information	208
19.2.2	Button press	209
19.2.3	Display updated	210
19.2.4	Hookswitch	211
19.2.5	Lamp mode	212
19.2.6	Message waiting	213
19.2.7	Microphone gain	214
19.2.8	Microphone mute	215
19.2.9	Ringer status	216
19.2.10	Speaker mute	217
19.2.11	Speaker volume	218
20	Logical device features	219
20.1	Services	219
20.1.1	Call back non-call-related	219
20.1.2	Call back message non-call-related	220
20.1.3	Cancel call back	221
20.1.4	Cancel call back message	222
20.1.5	Get agent state	223
20.1.6	Get auto answer	224
20.1.7	Get auto work mode	225
20.1.8	Get caller id status	226
20.1.9	Get do not disturb	227
20.1.10	Get forwarding	228
20.1.11	Get last number dialed	229
20.1.12	Get routeing mode	230
20.1.13	Set agent state	231

20.1.14	Set auto answer	232
20.1.15	Set auto work mode	233
20.1.16	Set caller id status	234
20.1.17	Set do not disturb	235
20.1.18	Set forwarding	236
20.1.19	Set routeing mode	237
20.2	Events	238
20.2.1	Agent busy	238
20.2.2	Agent logged off	239
20.2.3	Agent logged on	240
20.2.4	Agent not ready	241
20.2.5	Agent ready	242
20.2.6	Agent working after call	243
20.2.7	Auto answer	244
20.2.8	Auto work mode	245
20.2.9	Call back	246
20.2.10	Call back message	247
20.2.11	Caller id status	248
20.2.12	Do not disturb	249
20.2.13	Forwarding	250
20.2.14	Routeing mode	251
21	Device maintenance events	252
21.1	Events	252
21.1.1	Back in service	252
21.1.2	Device capabilities changed	253
21.1.3	Out of service	254
22	I/O services	255
22.1	Registration services	255
22.1.1	I/O register	255
22.1.2	I/O register abort	256
22.1.3	I/O register cancel	257
22.2	Services	258
22.2.1	Data path resumed	258
22.2.2	Data path suspended	259
22.2.3	Fast data	260
22.2.4	Resume data path	261
22.2.5	Send broadcast data	262
22.2.6	Send data	263
22.2.7	Send multicast data	264
22.2.8	Start data path	265
22.2.9	Stop data path	266
22.2.10	Suspend data path	267

23	Data Collection Services	268
23.1	Services	268
23.1.1	Data Collected	268
23.1.2	Data Collection Resumed	270
23.1.3	Data Collection Suspended	271
23.1.4	Resume Data Collection	272
23.1.5	Start Data Collection	273
23.1.6	Stop Data Collection	274
23.1.7	Suspend Data Collection	275
24	Voice unit services and events	276
24.1	Services	276
24.1.1	Concatenate message	276
24.1.2	Delete message	277
24.1.3	Play message	278
24.1.4	Query voice attribute	279
24.1.5	Record message	280
24.1.6	Reposition	281
24.1.7	Resume	282
24.1.8	Review	283
24.1.9	Set voice attribute	284
24.1.10	Stop	285
24.1.11	Suspend	286
24.1.12	Synthesize message	287
24.2	Events	288
24.2.1	Play	288
24.2.2	Record	289
24.2.3	Review	290
24.2.4	Stop	291
24.2.5	Suspend play	292
24.2.6	Suspend record	293
24.2.7	Voice attribute changed	294
25	Call detail record services	295
25.1	Services	295
25.1.1	Call detail records notification	295
25.1.2	Call detail records report	296
25.1.3	Send stored call detail records	297
25.1.4	Start call detail records transmission	298
25.1.5	Stop call detail records transmission	299
26	Vendor specific extensions services and events	300
26.1	Registration services	300
26.1.1	Escape register	300
26.1.2	Escape register abort	301

26.1.3	Escape register cancel	302
26.2	Services	303
26.2.1	Escape	303
26.2.2	Private data version selection	304
26.3	Events	305
26.3.1	Private event	305
Annex A Protocol Implementation Conformance Statement (PICS) Performa		307
A.1	Introduction	307
A.2	Conformance	307
A.3	Instructions for completing the PICS proforma	307
A.4	Implementation identification	308
A.5	PICS proforma	308
A.5.1	CSTA Profiles	308
A.5.2	Capability Exchange Services	308
A.5.3	System Services	313
A.5.4	Monitoring Services	317
A.5.5	Snapshot Services	318
A.5.6	Call Control Services	320
A.5.7	Call Control Events	333
A.5.8	Call Associated Feature Services	343
A.5.9	Call Associated Feature Events	345
A.5.10	Media Attachment Services	347
A.5.11	Media Attachment Events	348
A.5.12	Routeing Services	350
A.5.13	Physical Device Services	354
A.5.14	Physical Device Events	364
A.5.15	Logical Device Services	367
A.5.16	Logical Device Events	375
A.5.17	Device Maintenance Events	380
A.5.18	I/O Services	380
A.5.19	Data Collection Services	386
A.5.20	Voice Unit Services	389
A.5.21	Voice Unit Events	395
A.5.22	Call Detail Record (CDR) Services	397
A.5.23	Vendor Specific Extension Services	399
A.5.24	Vendor Specific Extension Events	401

1 Scope

This Standard specifies application protocol data units (APDUs) for the services described in Standard ECMA-269, Services for Computer Supported Telecommunications Applications (CSTA) Phase III.

Clause 5 to clause 7 inclusive describes the concepts underlying the Remote Operations model, notation and service.

Clause 8 to clause 26 inclusive contains CSTA-specific protocol details and forms the main part of this Standard.

The protocol in this Standard operates in the context of an application association.

2 Conformance

A manufacturer may select any part of the CSTA protocol, as specified in this Standard, for implementation on a system as long as it satisfies the minimum conformance requirements as specified in clause 2 of ECMA-269.

A Protocol Implementation Conformance Statement (PICS) shall be used to specify the operations which are provided by a particular implementation. A PICS shall also specify the parameter options which are used.

2.1 Static Requirements

To conform to this Standard, a system shall support the transfer syntax (derived from the encoding rules specified in ITU-T X.690) named {joint-iso-ccitt asn1(1) basic-encoding(1)}; for the purpose of generating and interpreting CSTA protocol information as defined by the abstract syntax “CSTA-ASN.1-Object-Descriptor” for the operations supported.

2.2 Dynamic Requirements

To conform to this Standard, a system shall:

- a. follow the procedures as specified in this Standard, and Standard ECMA-269, relevant to each CSTA operation that the system claims to implement; and
- b. satisfy the definitions, as specified in Standard ECMA-269, relevant to each CSTA service that the system claims to implement.

2.3 PICS Requirement

To conform to this Standard, the following shall be stated by the implementer when defining a PICS corresponding to an application or implementation:

- a. which CSTA operations, as defined in Standard ECMA-269, are supported by the system for the particular implementation; and
- b. which optional parameters are supported by the PDUs belonging to the supported operations.

A PICS proforma is given in Annex A of this Standard.

3 References

ECMA-269	Services for Computer Supported Telecommunications Applications (CSTA) Phase III (December 1998)
ECMA TR/72	Glossary of Definitions and Terminology for Computer Supported Telecommunications Applications (CSTA) Phase III (December 1998)
CCITT Rec. E.164	Numbering Plan for ISDN
ISO 8649:1988	Information processing systems - Open Systems Interconnection - Service definition for the Association Control Service Element (this corresponds to CCITT Rec. X.217)
ISO 8650:1988	Information processing systems - Open Systems Interconnection - Protocol specification for the Association Control Service Element (this corresponds to CCITT Rec. X.227)
ITU-T X.680	Data Networks and Open System Communications - OSI networking and system aspects - abstract syntax notation one (ASN.1): Specification of basic notation

ITU-T X.690	Data Networks and Open System Communications - OSI networking and system aspects - abstract syntax notation one (ASN.1) - information technology - ASN.1 encoding rules
ISO/IEC 9072-1:1989	Information processing systems - Text communication - Remote operations - Part 1: Model, notation and service definition (this corresponds to CCITT Rec. X.219)
ISO/IEC 9072-2:1989	Information processing systems - Text communication - Remote operations - Part 2: Protocol specification (this corresponds to CCITT Rec. X.229)
ISO/IEC 9545:1994	Information technology - Open Systems Interconnection - Application Layer structure

All the CCITT Recommendations that are referenced are the 1988 (Blue Book) version.

4 Definitions

CSTA-specific terminology is defined in ECMA TR/72. For the purposes of this Standard, the following additional definitions, defined in other standards, shall apply:

- Remote Operations (as per CCITT Rec. X.219)
- Application Association (as per CCITT Rec. X.217)
- Application Context (as per CCITT Rec. X.217)
- Private Telecommunications Network(as per CENELEC ENV 41007)

5 CSTA Service Definition Model

5.1 CSTA Application Layer Structure

The CSTA Application Layer structure conforms to the model described in ISO/IEC 9545.

5.2 Remote Operations

The services of CSTA are modeled as Remote Operations as described in CCITT Rec. X.219. Typically, one entity requests that a particular operation be performed; the other entity attempts to perform the operation and responds to the requestor. Consequently the operation of the protocol is an elementary request/reply interaction, supported within the OSI Application Layer, and carried out within the context of an application association.

For some of the CSTA services, the entity to which the request is sent generates a reply which can indicate success or failure. For these services, CSTA shall adopt the operations Class 2, defined in CCITT Rec. X.219 as:

- Asynchronous, reporting success or failure (result or error).

For some of the CSTA services, the entity to which the request is sent generates a reply which can only indicate failure. For these services, CSTA shall adopt the operations Class 3, defined in CCITT Rec. X.219 as:

- Asynchronous, reporting failure (error) only, if any.

For some of the CSTA services, particularly the ongoing reporting of events, no reply is generated. For these services, CSTA shall adopt the operations Class 5, defined in CCITT Rec. X.219 as:

- Asynchronous, outcome not reported.

The protocol description for the particular service defines the relevant class of the operation used for that service.

CSTA shall correlate the single response, denoting success or failure, with the originating request by using the mechanisms within the ROSE protocol.

5.3 The CSTA Service Response

CSTA employs a generic response mechanism which is, in principle, decoupled from the specifics of the switching activity. The following points describe the operation of the CSTA service response:

- a. Specific services may have an unconfirmed mode where responses to correct requests are not returned.
- b. The server shall check the correctness of the request (e.g. syntactical checks) before issuing the response. Incorrect requests shall result in an error response, even in the unconfirmed mode.

5.4 Cross Referencing of Event Reports

A computer application process may need to cross reference a CSTAEventReport to one of the following:

- a. a CSTA Object ID (Call ID or Device ID),
- b. an earlier Monitor request; or
- c. one of many Monitor requests (pertaining to the same CSTA Object).

For the above scenarios the necessary cross referencing function may be fulfilled by use of the parameter "MonitorCrossRefID". The content of MonitorCrossRefID depends upon the context and it may be one of the following: Call ID, Device ID or another independently switch managed static identifier. The independent identifier may have a unique correlation to either: one device, one call, or one monitor request.

The switching system limit on the number of monitor requests on one CSTA Object (Call or Device) is an implementation option. This Standard does not stipulate how many monitor requests on one object are to be supported by the switch. If using Static Device or Call identifiers the limit can only be one.

5.5 Handling of Private Data

If an entity receives the parameter CSTAPrivateData, and it can not recognize the information contained, the parameter shall be discarded, and the rest of the message shall be processed.

6 Interconnection service boundary

The protocol in this Standard is an OSI Application Layer protocol and uses the Remote Operations protocol defined in CCITT Rec. X.229. The Remote Operations protocol assumes certain services are provided by the underlying layers, and these services are also assumed by the protocol for CSTA.

7 Security

This protocol also provides a mechanism for secure transmission of CSTA PDUs as defined in this Standard.

8 Association Management

The protocol in this Standard operates in the context of an application association. This application association can be either:

- an implicit association achieved via off-line agreement; or
- a dynamically negotiated association realized through the use of ACSE.

8.1 Implicit association

An a-priori agreement exists between switching and computing functions: the application context is implicit, dynamic negotiation is not possible.

8.2 Dynamic association management using ACSE

ACSE requires the use of an application context Name (as defined by ISO 8649). This is an object id that uniquely identifies CSTA independently of the different versions of the protocol.

The CSTA protocol version information is carried within the User Information field of the A-ASSOCIATE request and response PDUs.

An application context is established (using ACSE) as follows:

- the system generating the A-ASSOCIATE request includes the CSTA application context name and a list of all protocol versions that it is prepared to offer in the User Information field;
- on receipt of the A-ASSOCIATE request, the receiving system selects the protocol version to be used by identifying the highest version that is common to both systems;
- the protocol version selected is conveyed to the requestor in the User Information field of the A-ASSOCIATE response.

In addition to negotiating the protocol version, it is necessary for the requesting and responding systems to specify the CSTA services that they support. As with the protocol version information, this is also achieved by carrying additional information in the User Information field of the A-ASSOCIATE request and response PDUs. The application association requestor shall:

- list the services required from the serving application;
- list the services it can supply.

The responder shall include similar information for the responding application. At this point the association requestor will either accept or reject the association.

8.2.1 Encoding of application context name

```
CSTA-application-context-name
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta( 218) }
-- Common to all CSTA protocol versions
```

8.2.2 Encoding of application context information

```
CSTA-application-context-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) application-context-information( 200) }
```

DEFINITIONS ::=

BEGIN

EXPORTS

CallAssociatedEvents, CallControlEvents, DeviceMaintenanceEvents,
LogicalDeviceFeatureEvents, MediaAttachmentEvents, PhysicalDeviceFeatureEvents,
VendorSpecEvents, VoiceUnitEvents, CallControlServices, CallAssociatedServices,
MediaAttachmentServices, RouteingServices, VoiceUnitServices;

ACSEUserInformationForCSTA ::= SEQUENCE

```
{
  cSTAVersion                                CSTAVersion,
  cSTAFunctionsRequiredByApplication [0] IMPLICIT CSTAFunctionality    OPTIONAL,
  cSTAFunctionsThatCanBeSupplied        [1] IMPLICIT CSTAFunctionality    OPTIONAL,
  cSTAPrivateDataVersionList            [2] IMPLICIT CSTAPrivateDataVersionList OPTIONAL}
```

CSTAPrivateDataVersionList ::= SEQUENCE OF INTEGER

CSTAVersion ::= BIT STRING

```
{
  versionOne           (0), -- CSTA protocol version defined in ECMA 180
  versionTwo           (1), -- CSTA protocol version defined in ECMA 218
  versionThree         (2), -- CSTA protocol version defined in ECMA 285
  versionFour          (3), -- Reserved for future use
  versionFive          (4), -- Reserved for future use
  versionSix           (5), -- Reserved for future use
  versionSeven         (6), -- Reserved for future use
  versionEight         (7), -- Reserved for future use
  versionNine          (8), -- Reserved for future use
  versionTen           (9), -- Reserved for future use
  versionEleven        (10), -- Reserved for future use
  versionTwelve        (11), -- Reserved for future use
  versionThirteen      (12), -- Reserved for future use
  versionFourteen      (13), -- Reserved for future use
  versionFifteen       (14), -- Reserved for future use
  versionSixteen       (15)} -- Reserved for future use
```

-- When requesting an application association, the requestor will set the
-- corresponding bits for each version that it supports. When responding,
-- the responder shall specify only one bit corresponding to the version
-- selected (the highest common to both systems).

CSTAFunctionality ::= SEQUENCE

```
{
  capabilityExchangeServices [ 0] IMPLICIT CapabilityExchangeServices    DEFAULT {},
  systemServices            [ 1] IMPLICIT SystemServices                DEFAULT {},
  monitoringServices         [ 2] IMPLICIT MonitoringServices            DEFAULT {} }
```

```
snapshotServices          [ 3] IMPLICIT SnapshotServices          DEFAULT {},
callControlServAndEvts    [ 4] IMPLICIT CallControlServAndEvts    DEFAULT {},
callAssociatedServAndEvts [ 5] IMPLICIT CallAssociationServAndEvts    DEFAULT {},
mediaAttachmentServAndEvts [ 6] IMPLICIT MediaAttachmentServAndEvts    DEFAULT {},
routeingServices          [ 7] IMPLICIT RouteingServices          DEFAULT {},
physicalDeviceFeatures    [ 8] IMPLICIT PhysicalDeviceFeatures    DEFAULT {},
logicalDeviceFeatures     [ 9] IMPLICIT LogicalDeviceFeatures     DEFAULT {},
deviceMaintenanceEvents   [10] IMPLICIT DeviceMaintenanceEvents   DEFAULT {},
ioServices                [11] IMPLICIT IOServices                DEFAULT {},
dataCollectionServices     [12] IMPLICIT DataCollectionServices     DEFAULT {},
voiceUnitServAndEvts      [13] IMPLICIT VoiceUnitServAndEvts      DEFAULT {},
cdrServices               [14] IMPLICIT CDRServices               DEFAULT {},
vendorSpecServAndEvts     [15] IMPLICIT VendorSpecServAndEvts     DEFAULT {}

CapabilityExchangeServices ::= BIT STRING
{
    getLogicalDeviceInfo      ( 0),
    getPhysicalDeviceInfo     ( 1),
    getSwitchingFunctionCapabilities ( 2),
    getSwitchingFunctionDevices ( 3),
    switchingFunctionDevices   ( 4)}

SystemServices ::= BIT STRING
{
    changeSystemStatusFilter    ( 0),
    systemRegister              ( 1),
    systemRegisterAbort         ( 2),
    systemRegisterCancel        ( 3),
    requestSystemStatus         ( 4),
    systemStatus                ( 5),
    switchingFunctionCapabilitiesChanged ( 6),
    switchingFunctionDevicesChanged ( 7)}

MonitoringServices ::= BIT STRING
{
    changeMonitorFilter        ( 0),
    monitorStart               ( 1),
    monitorStop                 ( 2)}

SnapshotServices ::= BIT STRING
{
    snapshotCall                ( 0),
    snapshotDevice              ( 1),
    snapshotCallData            ( 2),
    snapshotDeviceData          ( 3)}

CallControlServAndEvts ::= SEQUENCE
{
    callControlServices [0] IMPLICIT CallControlServices    DEFAULT {},
    callControlEvents   [1] IMPLICIT CallControlEvents     DEFAULT {}

CallControlServices ::= BIT STRING
{
    acceptCall                (0),
    alternateCall              (1),
    answerCall                 (2),
    callBack                   (3),
    callBackMessage            (4),
    campOnCall                 (5),
    clearCall                  (6),
    clearConnection            (7),
    conferenceCall              (8),
    consultationCall           (9),
    deflectCall                (10),
    dialDigits                 (11),
    directedPickupCall         (12),
    groupPickupCall            (13),
    holdCall                   (14),
    intrudeCall                (15),
    joinCall                   (16),
    makeCall                   (17),
    makePredictiveCall         (18),
    parkCall                   (19),
    reconnectCall              (20),
```

```
retrieveCall          (21),
singleStepConference  (22),
singleStepTransfer    (23),
transferCall          (24)}
```

```
CallAssociationServAndEvts ::= SEQUENCE
{
    callAssociatedServices [ 0 ] IMPLICIT CallAssociatedServices    DEFAULT {},
    callAssociatedEvents   [ 1 ] IMPLICIT CallAssociatedEvents      DEFAULT {}
}
```

```
CallAssociatedServices ::= BIT STRING
{
    associateData          (0),
    cancelTelephonyTones   (1),
    generateDigits          (2),
    generateTelephonyTones (3),
    sendUserInformation     (4)}
```

```
MediaAttachmentServAndEvts ::= SEQUENCE
{
    mediaAttachmentServices [ 0 ] IMPLICIT MediaAttachmentServices  DEFAULT {},
    mediaAttachmentEvents   [ 1 ] IMPLICIT MediaAttachmentEvents    DEFAULT {}
}
```

```
MediaAttachmentServices ::= BIT STRING
{
    attachMediaService      (0),
    detachMediaService       (1)}
```

```
RouteingServices ::= BIT STRING
{
    routeRegister           ( 0 ),
    routeRegisterCancel     ( 1 ),
    routeRegisterAbort      ( 2 ),
    reRoute                 ( 3 ),
    routeEnd                ( 4 ),
    routeReject             ( 5 ),
    routeRequest            ( 6 ),
    routeSelect             ( 7 ),
    routeUsed               ( 8 )}
```

```
PhysicalDeviceFeatures ::= SEQUENCE
{
    physicalDeviceServices [ 0 ] IMPLICIT PhysicalDeviceFeatureServices  DEFAULT {},
    physicalDeviceEvents   [ 1 ] IMPLICIT PhysicalDeviceFeatureEvents    DEFAULT {}
}
```

```
PhysicalDeviceFeatureServices ::= BIT STRING
{
    buttonPress              ( 0 ),
    getAuditoryApparatusInfo ( 1 ),
    getButtonInformation     ( 2 ),
    getDisplay               ( 3 ),
    getHookSwitchStatus     ( 4 ),
    getLampInfo              ( 5 ),
    getLampMode              ( 6 ),
    getMessageWaitingIndicator ( 7 ),
    getMicrophoneGain        ( 8 ),
    getMicrophoneMute        ( 9 ),
    getRingerStatus          (10),
    getSpeakerMute           (11),
    getSpeakerVolume         (12),
    setButtonInformation     (13),
    setDisplay               (14),
    setHookSwitchStatus     (15),
    setLampMode              (16),
    setMessageWaitingIndicator (17),
    setMicrophoneGain        (18),
    setMicrophoneMute        (19),
    setRingerStatus          (20),
    setSpeakerMute           (21),
    setSpeakerVolume         (22) }
```

```
LogicalDeviceFeatures ::= SEQUENCE
{
    logicalDeviceServices [0] IMPLICIT LogicalDeviceFeatureServices  DEFAULT {},
}
```

```
logicalDeviceEvents      [1] IMPLICIT LogicalDeviceFeatureEvents      DEFAULT {}

LogicalDeviceFeatureServices ::= BIT STRING
{
    callBackNonCallRel      ( 0),
    callBackMsgNonCallRel   ( 1),
    cancelCallBack          ( 2),
    cancelCallBackMsg       ( 3),
    getAgentStatus          ( 4),
    getAutoAnswer           ( 5),
    getAutoWorkMode         ( 6),
    getCallerIDStatus       ( 7),
    getDoNotDisturb         ( 8),
    getForwarding           ( 9),
    getLastNumberDialed     (10),
    getRouteingMode         (11),
    setAgentState           (12),
    setAutoAnswer           (13),
    setAutoWorkMode         (14),
    setCallerIDStatus       (15),
    setDoNotDisturb         (16),
    setForwarding           (17),
    setRouteingMode         (18)}

IOServices ::= BIT STRING
{
    ioRegister              (0),
    ioRegisterAbort         (1),
    ioRegisterCancel        (2),
    dataPathResumed         (3),
    dataPathSuspended       (4),
    fastData                (5),
    resumeDataPath          (6),
    sendBroadcastData       (7),
    sendData                (8),
    sendMulticastData       (9),
    startDataPath           (10),
    stopDataPath            (11),
    suspendDataPath         (12)}

DataCollectionServices ::= BIT STRING
{
    dataCollected          ( 0),
    dataCollectionResumed   ( 1),
    dataCollectionSuspended ( 2),
    resumeDataCollection    ( 3),
    startDataCollection     ( 4),
    stopDataCollection      ( 5),
    suspendDataCollection   ( 6)}

VoiceUnitServAndEvts ::= SEQUENCE
{
    voiceUnitServices       [0] IMPLICIT VoiceUnitServices      DEFAULT {},
    voiceUnitEvents         [1] IMPLICIT VoiceUnitEvents        DEFAULT {} }

VoiceUnitServices ::= BIT STRING
{
    concatenateMessage      (0),
    deleteMessage          (1),
    playMessage             (2),
    queryVoiceAttribute      (3),
    recordMessage           (4),
    reposition              (5),
    resume                  (6),
    review                  (7),
    setVoiceAttribute       (8),
    stop                    (9),
    suspend                 (10),
    synthesizeMessage       (11)}

CDRServices ::= BIT STRING
{
    cdrNotification         (0),
    cdrReport               (1),
```

```
        sendStoredCDRRecords      (2),
        startCDRTransmission      (3),
        stopCDRTransmission       (4)}

VendorSpecServAndEvts ::= SEQUENCE
{
    vendorSpecServices      [0] IMPLICIT VendorSpecServices      DEFAULT {},
    vendorSpecEvents        [1] IMPLICIT VendorSpecEvents        DEFAULT {}
}

VendorSpecServices ::= BIT STRING
{
    escapeRegister           (0),
    escapeRegisterAbort     (1),
    escapeRegisterCancel    (2),
    escape                   (3),
    privateDataVersionSelection (4)}

CallControlEvents ::= BIT STRING
{
    bridged                  (15),
    callCleared              (0),
    conferenced              (1),
    connectionCleared        (2),
    delivered                (3),
    digitsDialed              (14),
    diverted                 (4),
    established              (5),
    failed                   (6),
    held                     (7),
    networkCapabilitiesChanged (16),
    networkReached            (8),
    offered                  (17),
    originated               (9),
    queued                   (10),
    retrieved                (11),
    serviceInitiated         (12),
    transferred              (13) }

CallAssociatedEvents ::= BIT STRING
{
    callInformation          (0),
    charging                 (1),
    dTMFDigitsDetected       (2),
    telephonyTonesDetected   (3),
    serviceCompletionFailure  (4)}

MediaAttachmentEvents ::= BIT STRING
{
    mediaAttached (0),
    mediaDetached (1)}

PhysicalDeviceFeatureEvents ::= BIT STRING
{
    buttonInformation (0),
    buttonPress       (1),
    displayUpdated    (2),
    hookswitch        (3),
    lampMode          (4),
    messageWaiting    (5),
    microphoneGain     (6),
    microphoneMute     (7),
    ringerStatus       (8),
    speakerMute        (9),
    speakerVolume      (10)}

LogicalDeviceFeatureEvents ::= BIT STRING
{
    agentBusy           ( 0),
    agentLoggedOn       ( 1),
    agentLoggedOff      ( 2),
    agentNotReady       ( 3),
    agentReady          ( 4),
    agentWorkingAfterCall ( 5),
    autoAnswer          ( 6),
    autoWorkMode        ( 7),
```



```
        callBack          ( 8),
        callBackMessage   ( 9),
        callerIDStatus    (10),
        doNotDisturb       (11),
        forwarding         (12),
        routeingMode       (13)}

DeviceMaintenanceEvents ::= BIT STRING
{
    backInService          (0),
    deviceCapabilityChanged (2),
    outOfService           (1)      }

VoiceUnitEvents ::= BIT STRING
{
    play          (1),
    record        (3),
    review        (5),
    stop          (0),
    suspendPlay   (2),
    suspendRecord (4),
    voiceAttributesChange (6)      }

VendorSpecEvents ::= BIT STRING
{
    privateEvent (0)}

END -- of CSTA-application-context-information
```

9 CSTA parameter types

The major parameters have been assigned distinct application tags to facilitate parsing. The data is defined in logical groups in ascending order of application tag. Application tags used are:

- APPLICATION 1 - 8: Device identifiers
- APPLICATION 11 - 14: Connection identifiers and local connection states
- APPLICATION 21 - 24: . . . Status reporting
- APPLICATION 29 - 30: . . . CSTACommonArguments

9.1 Switching function objects

```
CSTA-switching-function-objects
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) switching-function-objects( 122) }
DEFINITIONS ::=
BEGIN

EXPORTS
CSTAObject;

IMPORTS
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) };

CSTAObject ::= CHOICE
    {deviceObject    DeviceID,
     callObject      ConnectionID}

END -- of CSTA-switching-function-objects
```

9.2 Device Identifiers

```
CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }

DEFINITIONS ::=
BEGIN

EXPORTS
DeviceID, NumberDigits, CallingDeviceID, CalledDeviceID,
SubjectDeviceID, RedirectionDeviceID, AssociatedCallingDeviceID,
AssociatedCalledDeviceID, NetworkCallingDeviceID, NetworkCalledDeviceID;

IMPORTS
MediaClass FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

CallingDeviceID ::= [APPLICATION 1] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

CalledDeviceID ::= [APPLICATION 2] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

SubjectDeviceID ::= [APPLICATION 3] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

RedirectionDeviceID ::= [APPLICATION 4] CHOICE
{numberdialed         DeviceID,
 notKnown              [7] IMPLICIT          NULL,
 notRequired           [8] IMPLICIT          NULL,
 notSpecified          [9] IMPLICIT          NULL}

AssociatedCallingDeviceID ::= [APPLICATION 5] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

AssociatedCalledDeviceID ::= [APPLICATION 6] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

NetworkCallingDeviceID ::= [APPLICATION 7] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

NetworkCalledDeviceID ::= [APPLICATION 8] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT          NULL}

DeviceID ::= SEQUENCE
{
  deviceIdentifier      CHOICE
  {
    dialingNumber       [0] IMPLICIT          NumberDigits,
    deviceNumber         [1] IMPLICIT          DeviceNumber,
    implicitPublic       [2] IMPLICIT          NumberDigits,
    explicitPublic       [3] IMPLICIT          PublicTON,
    implicitPrivate      [4] IMPLICIT          NumberDigits,
    explicitPrivate      [5] IMPLICIT          PrivateTON,
    other                [6] IMPLICIT          OtherPlan},
  mediaClass            MediaClass OPTIONAL}

PublicTON ::= CHOICE
{
  unknown               [0] IMPLICIT          IA5String,
  international         [1] IMPLICIT          IA5String,
```

```

        national          [2] IMPLICIT      IA5String,
        networkspecific    [3] IMPLICIT      IA5String,
        subscriber         [4] IMPLICIT      IA5String,
        abbreviated        [5] IMPLICIT      IA5String  }
-- The public type of numbers are derived from CCITT E.164

PrivateTON ::= CHOICE
    {
        unknown            [0] IMPLICIT      IA5String,
        level3RegionalNumber [1] IMPLICIT      IA5String,
        level2RegionalNumber [2] IMPLICIT      IA5String,
        level1RegionalNumber [3] IMPLICIT      IA5String,
        pTNSpecificNumber   [4] IMPLICIT      IA5String,
        localNumber         [5] IMPLICIT      IA5String,
        abbreviated         [6] IMPLICIT      IA5String  }
-- The private type of numbers are derived from ECMA-155

OtherPlan ::= OCTET STRING      -- Allows future expansion to cover other numbering
                                -- plans (such as X.121 etc.)

NumberDigits ::= IA5String

DeviceNumber ::= INTEGER

END  -- of CSTA-device-identifiers
```

9.3 Call and connection identifiers

```
CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }

DEFINITIONS ::=
BEGIN

EXPORTS
CallID, ConnectionID;

IMPORTS
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) };

ConnectionID ::= [APPLICATION 11] CHOICE
{
  callID      [0] IMPLICIT      CallID,
  deviceID    [1]                LocalDeviceID,
  both        SEQUENCE
  {
    callID      [0] IMPLICIT      CallID,
    deviceID    [1]                LocalDeviceID
  }
}

CallID ::= OCTET STRING (SIZE(0..8))

LocalDeviceID ::= CHOICE
{
  staticID      DeviceID,
  dynamicID     [3] IMPLICIT      OCTET STRING (SIZE(0..32)) }

END -- of CSTA-call-connection-identifiers
```

9.4 Connection states

```
CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }

DEFINITIONS ::=
BEGIN

EXPORTS
ConnectionList, LocalConnectionState;

IMPORTS
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ConnectionList ::= SEQUENCE OF SEQUENCE
{
  newConnection [0] ConnectionID      OPTIONAL,
  oldConnection [1] ConnectionID      OPTIONAL,
  -- mandatory, if the switching function previously reported
  -- the CallID
  endpoint [2] CHOICE
  {
    deviceID      DeviceID,
    notKnown      NULL}      OPTIONAL,
  associatedNID [3] CHOICE
  {
    deviceID      DeviceID,
    notKnown      NULL}      OPTIONAL,
  -- the associatedNID is mandatory in the case of external
  -- calls and shall be omitted otherwise
  resultingConnectionInfo ConnectionInformation OPTIONAL}

-- newConnection is optional only for the transferringDevice in the
-- Transferrend event, otherwise mandatory.

LocalConnectionState ::= [APPLICATION 14] IMPLICIT ENUMERATED
{
  null      (0),
  initiated (1),
  alerting  (2),
  connected (3),
  hold      (4),
  queued    (5),
  fail      (6)}

END -- CSTA-connection-states
```

9.5 Status reporting

```
CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }

DEFINITIONS ::=
BEGIN

EXPORTS
MonitorObject, MonitorCrossRefID, MonitorFilter, MonitorType,
MonitorMediaClass, SnapshotCallData, SnapshotDeviceData;

IMPORTS
CallControlEvents, CallAssociatedEvents, MediaAttachmentEvents,
PhysicalDeviceFeatureEvents, LogicalDeviceFeatureEvents,
DeviceMaintenanceEvents, VoiceUnitEvents, VendorSpecEvents
  FROM CSTA-application-context-information
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) application-context-information( 200) }
ServicesPermitted FROM CSTA-call-control
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-control(130) }
CSTAObject FROM CSTA-switching-function-objects
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) switching-function-objects( 122) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) connection-states( 125) }
ConnectionInformation, MediaCallCharacteristics, MediaServiceType,
MediaServiceInstanceID, MediaStreamID FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) }
;

MonitorObject ::= CSTAObject;

MonitorCrossRefID ::= [APPLICATION 21] IMPLICIT OCTET STRING (SIZE(0..4))

MonitorFilter ::= SEQUENCE-- default is no filter (i.e. all events)
{ callControl          [0] IMPLICIT CallControlEvents          DEFAULT {},
  callAssociated        [6] IMPLICIT CallAssociatedEvents        DEFAULT {},
  mediaAttachment       [7] IMPLICIT MediaAttachmentEvents      DEFAULT {},
  physicalDeviceFeature [8] IMPLICIT PhysicalDeviceFeatureEvents DEFAULT {},
  logicalDeviceFeature  [9] IMPLICIT LogicalDeviceFeatureEvents  DEFAULT {},
  maintenance           [3] IMPLICIT DeviceMaintenanceEvents    DEFAULT {},
  voiceUnit             [5] IMPLICIT VoiceUnitEvents            DEFAULT {},
  private               [4] IMPLICIT VendorSpecEvents           DEFAULT {} }

-- setting the relevant bit requests the filter for the appropriate events

MonitorType ::= ENUMERATED
{
  call          (0),
  device        (1)
}

MonitorMediaClass ::= BIT STRING
{
  voice          (0),
  data           (1),
  image          (2),
  audio          (4),
  other          (3) }
```

SnapshotDeviceData ::= [APPLICATION 22] IMPLICIT SEQUENCE OF SnapshotDeviceResponseInfo

SnapshotDeviceResponseInfo ::= SEQUENCE

```
{
    connectionIdentifier      ConnectionID,
    localCallState            CallState,
    servicesPermitted          [0] IMPLICIT ServicesPermitted      OPTIONAL,
    mediaServiceInfoList       [1] IMPLICIT DeviceMediaInfoList     OPTIONAL,
    mediaCallCharacteristics    [2] IMPLICIT MediaCallCharacteristics OPTIONAL}
```

DeviceMediaInfoList ::= SEQUENCE OF SEQUENCE

```
{
    mediaStreamID      MediaStreamID      OPTIONAL,
    connectionInformation ConnectionInformation OPTIONAL}
```

SnapshotCallData ::= [APPLICATION 23] IMPLICIT SEQUENCE OF SnapshotCallResponseInfo

SnapshotCallResponseInfo ::= SEQUENCE

```
{
    deviceOnCall      SubjectDeviceID,
    callIdentifier     ConnectionID      OPTIONAL,
    localConnectionState LocalConnectionState OPTIONAL,
    servicesPermitted  [0] IMPLICIT ServicesPermitted OPTIONAL,
    mediaServiceInfoList [1] IMPLICIT CallMediaInfoList OPTIONAL
}
```

CallMediaInfoList ::= SEQUENCE OF SEQUENCE

```
{
    mediaServiceType      [0] IMPLICIT MediaServiceType,
    mediaServiceVersion    [1] IMPLICIT INTEGER          OPTIONAL,
    mediaServiceInstance   [2] IMPLICIT MediaServiceInstanceID OPTIONAL,
    mediaStreamID          [3] IMPLICIT MediaStreamID     OPTIONAL,
    connectionInformation  [4] IMPLICIT ConnectionInformation OPTIONAL}
```

-- The parameter MediaStreamID is conditional. Refer to ECMA 269, 16.1.1 for conditions.

CallState ::= CHOICE

```
{
    compoundCallState [0] IMPLICIT CompoundCallState,
    simpleCallState   [1] IMPLICIT SimpleCallState,
    unknown            [2] IMPLICIT NULL}
```

-- unknown is returned by server if no other CallState can be supplied

CompoundCallState ::= SEQUENCE OF LocalConnectionState

SimpleCallState ::= ENUMERATED

```
{
    callNull          (0),      -- '00'H - null-null
    callPending       (1),      -- '01'H - null-initiate
    callOriginated    (3),      -- '03'H - null-connect
    callDelivered     (35),     -- '23'H - alerting-connect
    callDeliveredHeld (36),     -- '24'H - alerting-held
    callReceived      (50),     -- '32'H - connect-alerting
    callEstablished   (51),     -- '33'H - connect-connect
    callEstablishedHeld (52),   -- '34'H - connected-held
    callReceivedOnHold (66),    -- '42'H - held-alerting
    callEstablishedOnHold (67), -- '43'H - held-connect
    callQueued        (83),     -- '53'H - queued-connect
    callQueuedHeld    (84),     -- '54'H - queued-held
    callFailed        (99),     -- '63'H - failed-connect
    callFailedHeld    (100),    -- '64'H - failed-held
    callBlocked       (96)}     -- '60'H - failed-null
```

-- This represents the main call states in a simplified encoding. The semantics
-- are identical to the sequence of connection states but they are represented by
-- an item from an enumerated list.

END -- of CSTA-status-reporting

9.6 Device and feature types and other parameters

```
CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }

DEFINITIONS ::=
BEGIN

EXPORTS
AccountInfo, AgentID, AgentPassword, AgentState, AuthCode, CallOrigination, CorrelatorData,
DataPathType, DisplayAttributeList, ForwardList, IOCrossRefID, IORegisterReqID,
MessageID, ParticipationType, PendingAgentState, RetryValue, RouteRegisterReqID,
RouteingCrossRefID, SelectValue, SysStatRegisterID, SystemStatus, TerminatingConditions,
ForwardingType, ForwardDefault, AttributeInfo,
EncodingAlgorithm, ControlData, UserData, TelephonyTone;

IMPORTS
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) };

AccountInfo ::= OCTET STRING (SIZE(0..32))

AgentID ::= OCTET STRING (SIZE(0..32))

AgentPassword ::= OCTET STRING (SIZE(0..32))

AgentState ::= ENUMERATED
{
  agentNotReady      (0),
  agentNull          (1),
  agentReady         (2),
  agentBusy          (3),
  agentWorkingAfterCall (4)}

AuthCode ::= OCTET STRING (SIZE(0..32))

CorrelatorData ::= OCTET STRING (SIZE(0..32))

IOCrossRefID ::= CHOICE
{
  switchProvided      [0] OCTET STRING (SIZE(0..4)),
  computerProvided    [1] OCTET STRING (SIZE(0..4))}

IORegisterReqID ::= OCTET STRING (SIZE(0..4))

MessageID ::= OCTET STRING

ParticipationType ::= ENUMERATED
{
  silent      (0),
  active      (1) }

RouteRegisterReqID ::= OCTET STRING (SIZE(0..4))

RouteingCrossRefID ::= [APPLICATION 24] IMPLICIT OCTET STRING (SIZE(0..4))

SelectValue ::= ENUMERATED
{
  normal      (0),
  leastCost   (1),
  emergency   (2),
  aCD         (3),
  userDefined (4) }

RetryValue ::= CHOICE-- used in RouteSelect Request service
{
  noListAvailable      [0] IMPLICIT BOOLEAN,
  noCountAvailable     [1] IMPLICIT BOOLEAN,
  retryCount           [2] IMPLICIT INTEGER }
```

```
SysStatRegisterID ::= OCTET STRING (SIZE(0..4))

SystemStatus ::= ENUMERATED
{
    disabled                (4),
    partiallyDisabled       (8),
    enabled                  (1),
    initializing             (0),
    messagesLost             (3),
    normal                   (2),
    overloadImminent         (5),
    overloadReached          (6),
    overloadRelieved         (7)
}

CallOrigination ::= BIT STRING
{
    internal    (0),
    external    (1)}

ForwardList ::= SEQUENCE OF SEQUENCE
{
    forwardingType      ForwardingType      OPTIONAL,
    forwardStatus       BOOLEAN,
    forwardDN           DeviceID             OPTIONAL,
    forwardDefault      ForwardDefault       OPTIONAL,
    ringCount           INTEGER (1..100)     OPTIONAL}
-- The parameters forwardingType and forwardDN are conditional.
-- Refer to ECMA 269, 22.1.10 for conditions.

ForwardingType ::= BIT STRING
{
    forwardImmediate      (0),
    forwardBusy           (1),
    forwardNoAns          (2),
    forwardDND            (9),
    forwardBusyInt        (3),
    forwardBusyExt        (4),
    forwardNoAnsInt       (5),
    forwardNoAnsExt       (6),
    forwardImmInt         (7),
    forwardImmExt         (8),
    forwardDNDInt         (10),
    forwardDNDExt         (11)}

ForwardDefault ::= ENUMERATED
{
    forwardingTypeAndForwardDN (0),
    forwardingType             (1),
    forwardDN                   (2)}

PendingAgentState ::= ENUMERATED
{
    agentNotReady          (0),
    agentNull              (1),
    agentReady             (2),
    agentWorkingAfterCall  (3)}

DataPathType ::= ENUMERATED
{
    text    (0),
    voice   (1)}

DisplayAttributeList ::= SEQUENCE
{
    physicalBaseRowNumber [0] IMPLICIT INTEGER OPTIONAL,
    physicalBaseColumnNumber [1] IMPLICIT INTEGER OPTIONAL,
    offset [2] IMPLICIT INTEGER OPTIONAL}

TerminatingConditions ::= BIT STRING
{
    durationExceeded (0),
    dTMFDigitDetected (1),
    endOfMessageDetected (2),
    speechDetected (3)}

AttributeInfo ::= CHOICE
```

```
{      encodingAlgorithm      [0] IMPLICIT EncodingAlgorithm,
      samplingRate            [1] IMPLICIT INTEGER,
      duration                [2] IMPLICIT INTEGER,
      filename                [3] IMPLICIT IA5String,
      currentPosition         [4] IMPLICIT INTEGER,
      currentSpeed            [5] IMPLICIT INTEGER,
      currentVolume           [6] IMPLICIT INTEGER (0 .. 100),
      currentGain             [7] IMPLICIT INTEGER (0 .. 100),
      currentState            [8] IMPLICIT CurrentState}
```

EncodingAlgorithm ::= ENUMERATED

```
{      aDPCM6K      (0),
      aDPCM8K      (1),
      muLawPCM6K   (2),
      aLawPCM6K    (3)}
```

CurrentState ::= ENUMERATED

```
{      stop      (0),
      play       (1),
      record     (2),
      suspendPlay (3),
      suspendRecord (4),
      review     (5)}
```

ControlData ::= SEQUENCE

```
{      gender      ENUMERATED
                        {male      (0),
                         female    (1)},
      language     OCTET STRING}
```

UserData ::= [APPLICATION 29] OCTET STRING (SIZE(0..256))

TelephonyTone ::= ENUMERATED

```
{      beep      ( 0),
      billing    ( 1),
      busy       ( 2),
      carrier    ( 3),
      confirmation ( 4),
      dial       ( 5),
      faxCNG     ( 6),
      hold       ( 7),
      howler     ( 8),
      intrusion  ( 9),
      modemCNG   (10),
      park       (11),
      recordWarning (12),
      reorder    (13),
      ringback   (14),
      silence    (15),
      sitVC      (16),
      sitIC      (17),
      sitRO      (18),
      sitNC      (19),
      switchSpec0 (20),
      switchSpec1 (21),
      switchSpec2 (22),
      switchSpec3 (23),
      switchSpec4 (24),
      switchSpec5 (25),
      switchSpec6 (26),
      switchSpec7 (27),
      switchSpec8 (28),
      switchSpec9 (29),
      switchSpec10 (30),
      switchSpec11 (31),
      switchSpec12 (32),
      switchSpec13 (33),
```

switchSpec14	(34),
switchSpec15	(35),
switchSpec16	(36),
switchSpec17	(37),
switchSpec18	(38),
switchSpec19	(39),
switchSpec20	(40),
switchSpec21	(41),
switchSpec22	(42),
switchSpec23	(43),
switchSpec24	(44),
switchSpec25	(45),
switchSpec26	(46),
switchSpec27	(47),
switchSpec28	(48),
switchSpec29	(49),
switchSpec30	(50),
switchSpec31	(51),
switchSpec32	(52),
switchSpec33	(53),
switchSpec34	(54),
switchSpec35	(55),
switchSpec36	(56),
switchSpec37	(57),
switchSpec38	(58),
switchSpec39	(59),
switchSpec40	(60),
switchSpec41	(61),
switchSpec42	(62),
switchSpec43	(63),
switchSpec44	(64),
switchSpec45	(65),
switchSpec46	(66),
switchSpec47	(67),
switchSpec48	(68),
switchSpec49	(69),
switchSpec50	(70),
switchSpec51	(71),
switchSpec52	(72),
switchSpec53	(73),
switchSpec54	(74),
switchSpec55	(75),
switchSpec56	(76),
switchSpec57	(77),
switchSpec58	(78),
switchSpec59	(79),
switchSpec60	(80),
switchSpec61	(81),
switchSpec62	(82),
switchSpec63	(83),
switchSpec64	(84),
switchSpec65	(85),
switchSpec66	(86),
switchSpec67	(87),
switchSpec68	(88),
switchSpec69	(89),
switchSpec70	(90),
switchSpec71	(91),
switchSpec72	(92),
switchSpec73	(93),
switchSpec74	(94),
switchSpec75	(95),
switchSpec76	(96),
switchSpec77	(97),
switchSpec78	(98),
switchSpec79	(99),
switchSpec80	(100),
switchSpec81	(101),

```
switchSpec82      (102),  
switchSpec83      (103),  
switchSpec84      (104),  
switchSpec85      (105),  
switchSpec86      (106),  
switchSpec87      (107),  
switchSpec88      (108),  
switchSpec89      (109),  
switchSpec90      (110),  
switchSpec91      (111),  
switchSpec92      (112),  
switchSpec93      (113),  
switchSpec94      (114),  
switchSpec95      (115),  
switchSpec96      (116),  
switchSpec97      (117),  
switchSpec98      (118),  
switchSpec99      (119),  
switchSpec100     (120)}
```

```
END  -- of CSTA-device-feature-types
```

9.7 Security

```
CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) }

DEFINITIONS ::=
BEGIN

EXPORTS
CSTASecurityData,TimeInfo;

CSTASecurityData ::= SEQUENCE
{
  messageSequenceNumber[0] IMPLICIT INTEGER      OPTIONAL,
  timestamp                TimeInfo              OPTIONAL,
  securityInfo              SecurityInfo           OPTIONAL}

SecurityInfo ::= CHOICE
{
  string      OCTET STRING,
  private     NULL}      -- The actual encoding is added here,
                        -- replacing NULL with another valid ASN.1 type.

TimeInfo ::= GeneralizedTime

END -- of CSTA-security
```

9.8 Common extensions

```
CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
DEFINITIONS ::=
BEGIN

EXPORTS
CSTACommonArguments, CSTAPrivateData;

IMPORTS
CSTASecurityData FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) };

CSTACommonArguments ::= [APPLICATION 30] IMPLICIT SEQUENCE
{ security      [0] IMPLICIT  CSTASecurityData      OPTIONAL,
  privateData   [1] IMPLICIT  SEQUENCE OF CSTAPrivateData  OPTIONAL }

CSTAPrivateData ::= CHOICE
{
  string      OCTET STRING,
  private     NULL}      -- The actual encoding is added here,
                        -- replacing NULL with another valid ASN.1 type.

END -- of CSTA-extension-types
```

9.9 Call control

```
CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }

DEFINITIONS ::=
BEGIN

EXPORTS
AutoOriginate, CallCharacteristics, CallQualifyingData, ConsultOptions, NetworkCapability,
ProgressIndicator, ServicesPermitted;

IMPORTS
CallControlServices, CallAssociatedServices, MediaAttachmentServices, RouteingServices,
VoiceUnitServices FROM CSTA-application-context-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) application-context-information( 200) };

AutoOriginate ::= ENUMERATED
{
  prompt          (0),
  doNotPrompt     (1) }

CallCharacteristics ::= BIT STRING
{
  acdCall          (0),
  priorityCall     (1),
  maintainanceCall (2),
  directAgent      (3),
  assistCall       (4),
  voiceUnitCall    (5)}

CallQualifyingData ::= OCTET STRING (SIZE(0..32))

ConsultOptions ::= ENUMERATED
{
  unrestricted     (0),
  consultOnly      (1),
  transferOnly     (2),
  conferenceOnly   (3) }

NetworkCapability ::= SEQUENCE
{
  networkType ENUMERATED
  {
    iSDNPublic      (0),
    nonISDNPublic   (1),
    iSDNPrivate     (2),
    nonISDNPrivate  (3),
    other           (4) },
  eventsProvided BIT STRING
  {
    bridged          (0),
    callCleared      (1),
    conferenced      (2),
    connectionCleared (3),
    delivered        (4),
    digitsDialed     (5),
    diverted         (6),
    established      (7),
    failed           (8),
    held             (9),
    networkCapabilitiesChange (10),
    networkReached   (11),
    offered          (12),
    originated       (13),
    queued           (14),
    retrieved        (15),
    serviceInitiated (16),
    transferred      (17) } OPTIONAL}

ProgressIndicator ::= SEQUENCE
{
  progressLocation ENUMERATED
```



```

        {
            user (0),
            privateNetServingLocal (1),
            publicNetServingLocal (2),
            transitNetwork (3),
            publicNetServingRemote (4),
            privateNetServingRemote (5),
            localInterface (6),
            internationalNetwork (7),
            networkBeyondInterwk (8),
            other (9)
        },
    progressDescription ENUMERATED
    {
        iSDNProgressDesc (0),
        qSIGProgressDesc (1),
        other (2)
    }}

ServicesPermitted ::= SEQUENCE
{
    callControlServices      CallControlServices,
    callAssociatedServices   CallAssociatedServices,
    mediaAttachmentServices  MediaAttachmentServices,
    routingServices          RoutingServices,
    voiceUnitServices        VoiceUnitServices}

END -- of CSTA-call-control
```

9.10 Capability Exchange

```
CSTA-capability-exchange
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) capability-exchange( 131) }

DEFINITIONS ::=
BEGIN

EXPORTS
CapExchangeServList, SystemStatusServList, MonitoringServList, SnapshotServList,
CallControlServList, CallControlEvtsList, CallAssociatedServList,
CallAssociatedEvtsList, MediaServList, MediaEvtsList, RouteingServList, PhysDevEvtsList,
PhysDevServList, LogicalEvtsList, LogicalServList, DeviceMaintEvtsList, IOServicesServList,
DataCollectionServList, VoiceUnitServList, VoiceUnitEvtsList, CDRServList,
VendorSpecificServList, VendorSpecificEvtsList, DeviceIDFormat, SwDomainFeatures,
SwAppearanceAddressability, SwAppearanceTypes, IgnoreUnsupportedParameters, PauseTime,
TimeStampMode, MiscMonitorCaps, MaxLengthParameters, FilterThreshold, ServiceCrossRefID,
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, ACDModels, AgentLogOnModels,
AppearanceType, TransAndConfSetup, MediaServiceCapsList, LogDevServList, LogDevEvtsList;

IMPORTS
MediaServiceType, MediaServiceInstanceID, ConnectionMode, ConnectionModeBMap
FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

ServiceCrossRefID ::= OCTET STRING (SIZE(0..4))

-- Capability Bitmaps

LogDevServList ::= SEQUENCE
{
    callControlServList      [0] IMPLICIT CallControlServList      OPTIONAL,
    callAssociatedServList   [1] IMPLICIT CallAssociatedServList   OPTIONAL,
    logicalServList          [2] IMPLICIT LogicalServList          OPTIONAL,
    mediaServList            [3] IMPLICIT MediaServList            OPTIONAL,
    iOServicesServList       [4] IMPLICIT IOServicesServList       OPTIONAL,
    dataCollectionServList   [5] IMPLICIT DataCollectionServList   OPTIONAL,
    voiceUnitServList        [6] IMPLICIT VoiceUnitServList        OPTIONAL}

LogDevEvtsList ::= SEQUENCE
{
    callControlEvtsList      [0] IMPLICIT CallControlEvtsList      OPTIONAL,
    callAssociatedEvtsList   [1] IMPLICIT CallAssociatedEvtsList   OPTIONAL,
    logicalEvtsList          [2] IMPLICIT LogicalEvtsList          OPTIONAL,
    mediaEvtsList            [3] IMPLICIT MediaEvtsList            OPTIONAL,
    voiceUnitEvtsList        [4] IMPLICIT VoiceUnitEvtsList        OPTIONAL}

-- 12.4.1
CapExchangeServList ::= SEQUENCE
{
    getLogicalDeviceInformation [0] IMPLICIT GetLogicalDeviceInformation OPTIONAL,
    getPhysicalDeviceInformation [1] IMPLICIT GetPhysicalDeviceInformation OPTIONAL,
    getSwitchingFunctionCaps     NULL,
    getSwitchingFunctionDevices [2] IMPLICIT GetSwitchingFunctionDevices OPTIONAL,
    switchingFunctionDevices     [3] IMPLICIT SwitchingFunctionDevices OPTIONAL}

GetLogicalDeviceInformation ::= BIT STRING
{
    privateDataInReq          ( 0),
    namedDeviceTypeInAck      ( 1),
    shortFormDeviceIDInAck    ( 2),
    miscMonitorCapsInAck      ( 3),
    maxCallBacksInAck         ( 4),
    maxAutoAnswerRingsInAck   ( 5),
    maxActiveCallsInAck       ( 6),
    maxHeldCallsInAck         ( 7),
    maxFwdSettingsInAck       ( 8),
    maxDevicesInConfInAck     ( 9),
    transAndConfSetupParameter (10)
```

```
transAndConfSetupConsultationInAck      (11),
transAndConfSetupHoldMakeInAck          (12),
transAndConfSetupAlternateInAck          (13),
transAndConfSetupTwoCallsHoldInAck       (14),
transAndConfSetupTwoCallsConnectedInAck  (15),
mediaClassSupportInAck                   (16),
connectionRateListInAck                  (17),
delayToleranceListInAck                  (18),
numberOfChannelsInAck                     (19),
maxChannelBindInAck                       (20),
privateDataInAck                          (21)}

GetPhysicalDeviceInformation ::= BIT STRING
{
    privateDataInReq                ( 0),
    namedDeviceTypesInAck           ( 1),
    otherLogicalDeviceListInAck     ( 2),
    deviceModelNameInAck            ( 3),
    maxDisplaysInAck                 ( 4),
    maxButtonsInAck                  ( 5),
    maxLampsInAck                    ( 6),
    maxRingPatternsInAck            ( 7),
    privateDataInAck                ( 8)}

GetSwitchingFunctionDevices ::= BIT STRING
{
    requestedDeviceID                ( 0),
    requestedDeviceCategoryACD        ( 1),
    requestedDeviceCategoryACDGroup   ( 2),
    requestedDeviceCategoryHuntGroup  ( 3),
    requestedDeviceCategoryPickGroup  ( 4),
    requestedDeviceCategoryOtherGroup ( 5),
    requestedDeviceCategoryNetwInterface ( 6),
    requestedDeviceCategoryPark       ( 7),
    requestedDeviceCategoryRouteingDevice ( 8),
    requestedDeviceCategoryStation    ( 9),
    requestedDeviceCategoryVoiceUnit  (10),
    requestedDeviceCategoryOther      (11),
    privateData                       (12),
    privateDataInAck                  (13)}

SwitchingFunctionDevices ::= BIT STRING
{
    segmentID                        ( 0),
    deviceListDeviceCategory         ( 1),
    deviceListNamedDeviceTypes       ( 2),
    deviceListDeviceAttributes        ( 3),
    deviceListDeviceName              ( 4),
    privateData                       ( 5)}

-- 12.4.2
SystemStatusServList ::= SEQUENCE
{
    changeSystemStatusFilter          [ 0] IMPLICIT ChangeSystemStatusFilter      OPTIONAL,
    systemRegister                    [ 1] IMPLICIT SystemRegister                OPTIONAL,
    systemStatusRegisterAbort         [ 2] IMPLICIT SystemStatusRegisterAbort     OPTIONAL,
    systemStatusRegisterCancel        [ 3] IMPLICIT SystemStatusRegisterCancel    OPTIONAL,
    requestSystemStatus               [ 4] IMPLICIT RequestSystemStatus            OPTIONAL,
    systemStatus                      [ 5] IMPLICIT SystemStatus                  OPTIONAL,
    swFunctionCapsChanged              [ 6] IMPLICIT SwFunctionCapsChanged          OPTIONAL,
    swFunctionDevicesChanged           [ 7] IMPLICIT SwFunctionDevicesChanged       OPTIONAL}

ChangeSystemStatusFilter ::= BIT STRING
{
    requestedStatusFilterInitializing ( 0), -- optional parameters
    requestedStatusFilterEnabled      ( 1), -- optional parameters
    requestedStatusFilterNormal        ( 2), -- optional parameters
    requestedStatusFilterMessageLost   ( 3), -- optional parameters
    requestedStatusFilterDisabled      ( 4), -- optional parameters
    requestedStatusFilterPartiallyDisabled ( 5), -- optional parameters
    requestedStatusFilterOverloadImminent ( 6), -- optional parameters
    requestedStatusFilterOverloadReached ( 7), -- optional parameters
```

```
requestedStatusFilterOverloadRelieved      ( 8),  -- optional parameters
privateData                                ( 9),  -- optional parameters
privateDataInAck                            (10)}  -- optional parameters

SystemRegister ::= BIT STRING
{
    requestTypesSystemStatus      ( 0),  -- optional parameters
    requestTypesRequestSystemStatus ( 1),  -- optional parameters
    statusFilterInitializing       ( 2),  -- optional parameters
    statusFilterEnabled            ( 3),  -- optional parameters
    statusFilterNormal             ( 4),  -- optional parameters
    statusFilterMessageLost        ( 5),  -- optional parameters
    statusFilterDisabled           ( 6),  -- optional parameters
    statusFilterPartiallyDisabled  ( 7),  -- optional parameters
    statusFilterOverloadImminent   ( 8),  -- optional parameters
    statusFilterOverloadReached    ( 9),  -- optional parameters
    statusFilterOverloadRelieved   (10),  -- optional parameters
    privateDataOctetString         (11),  -- optional parameters
    privateData                    (12),  -- optional parameters
    privateDataOctetStringInAck    (13),  -- optional parameters
    privateDataInAck               (14)}  -- optional parameters

SystemStatusRegisterCancel ::= BIT STRING
{
    privateData      (0),  -- optional parameters
    privateDataInAck (1)}  -- optional parameters

SystemStatusRegisterAbort ::= BIT STRING
{
    privateData      (0),  -- optional parameters
    privateDataInAck (1)}  -- optional parameters

RequestSystemStatus ::= BIT STRING
{
    privateDataInReq      ( 0),  -- optional parameters
    systemStatusInitializing ( 1),  -- optional parameters
    systemStatusEnabled    ( 2),  -- optional parameters
    systemStatusNormal      ( 3),  -- optional parameters
    systemStatusMessageLost ( 4),  -- optional parameters
    systemStatusDisabled    ( 5),  -- optional parameters
    systemStatusPartiallyDisabled ( 6),  -- optional parameters
    systemStatusOverloadImminent ( 7),  -- optional parameters
    systemStatusOverloadReached ( 8),  -- optional parameters
    systemStatusOverloadRelieved ( 9),  -- optional parameters
    privateDataInAck        (10),  -- optional parameters
    switchingFunctionSupportsSending (11),  -- misc characteristics
    switchingFunctionSupportsReceiving (12)}  -- misc characteristics

SystemStatus ::= BIT STRING
{
    systemStatusInitializing      ( 0),  -- optional parameters
    systemStatusEnabled           ( 1),  -- optional parameters
    systemStatusNormal            ( 2),  -- optional parameters
    systemStatusMessageLost       ( 3),  -- optional parameters
    systemStatusDisabled          ( 4),  -- optional parameters
    systemStatusPartiallyDisabled ( 5),  -- optional parameters
    systemStatusOverloadImminent  ( 6),  -- optional parameters
    systemStatusOverloadReached   ( 7),  -- optional parameters
    systemStatusOverloadRelieved  ( 8),  -- optional parameters
    privateData                   ( 9),  -- optional parameters
    privateDataInAck              (10),  -- optional parameters
    switchingFunctionSupportsSending (11),  -- misc characteristics
    switchingFunctionSupportsReceiving (12)}  -- misc characteristics

SwFunctionCapsChanged ::= BIT STRING
{
    privateData      (0),  -- optional parameters
    privateDataInAck (1)}  -- optional parameters

SwFunctionDevicesChanged ::= BIT STRING
{
    privateData      (0),  -- optional parameters
    privateDataInAck (1)}  -- optional parameters
```

```
MonitoringServList ::= SEQUENCE
{
    changeMonitorFilter      [ 0 ] IMPLICIT ChangeMonitorFilter      OPTIONAL,
    monitorStart             [ 1 ] IMPLICIT MonitorStart             OPTIONAL,
    monitorStop              [ 2 ] IMPLICIT MonitorStop              OPTIONAL}

ChangeMonitorFilter ::= BIT STRING
{
    privateData              (0),    -- optional parameters
    privateDataInAck         (1)}    -- optional parameters

MonitorStart ::= BIT STRING
{
    monitorObjectDevice      ( 0),    -- optional parameters
    monitorObjectCall        ( 1),    -- optional parameters
    requestedMonitorFilter   ( 2),    -- optional parameters
    monitorTypeCall          ( 3),    -- optional parameters
    monitorTypeDevice        ( 4),    -- optional parameters
    monitorMediaClassParameter ( 5),    -- optional parameters
    monitorMediaClassAudio    ( 6),    -- optional parameters
    monitorMediaClassData     ( 7),    -- optional parameters
    monitorMediaClassImage    ( 8),    -- optional parameters
    monitorMediaClassVoice    ( 9),    -- optional parameters
    monitorExistingCallsInAck (10),    -- optional parameters
    privateDataInAck         (11),    -- optional parameters
    callIDOnly               (12),    -- miscellaneous characteristics
    swDomainDefaultForMonitorTypeIsDevice (13)}    -- miscellaneous characteristics

MonitorStop ::= BIT STRING
{
    privateData              ( 0),    -- optional parameters
    privateDataInAck         ( 1),    -- optional parameters
    switchingFunctionSupportsSending ( 2),    -- misc characteristics
    switchingFunctionSupportsReceiving ( 3)}    -- misc characteristics

-- 12.4.4
SnapshotServList ::= SEQUENCE
{
    snapshotCall             [0] IMPLICIT SnapshotCall,
    snapshotDevice           [1] IMPLICIT SnapshotDevice,
    snapshotCallData         [2] IMPLICIT SnapshotCallData,
    snapshotDeviceData       [3] IMPLICIT SnapshotDeviceData}

SnapshotCall ::= BIT STRING
{
    privateData              ( 0),    -- optional parameters
    locaConnectionStateInAck ( 1),    -- optional parameters
    mediaServiceInfoListInAck ( 2),    -- optional parameters
    mediaServiceVersionInAck ( 3),    -- optional parameters
    mediaServiceInstanceInAck ( 4),    -- optional parameters
    mediaStreamID            ( 5),    -- optional parameters
    connectionInformation    ( 6),    -- optional parameters
    mediaCallCharacteristicsInAck ( 7),    -- optional parameters
    callCharacteristicsInAck ( 8),    -- optional parameters
    callingDeviceInAck       ( 9),    -- optional parameters
    calledDeviceInAck        (10),    -- optional parameters
    privateDataInAck         (11),    -- optional parameters
    callIDOnly               (12),    -- miscellaneous characteristics
    reportsWithSnapsCallData (13)}    -- miscellaneous characteristics

SnapshotDevice ::= BIT STRING
{
    privateData              ( 0),    -- optional parameters
    localCallStateCompoundCallState ( 1),    -- optional parameters
    localCallStateSimpleCallState ( 2),    -- optional parameters
    localCallStateUnknown    ( 3),    -- optional parameters
    mediaServiceInfoListInAck ( 4),    -- optional parameters
    mediaServiceVersionInAck ( 5),    -- optional parameters
    mediaServiceInstanceInAck ( 6),    -- optional parameters
    mediaStreamID            ( 7),    -- optional parameters
    connectionInformation    ( 8),    -- optional parameters
    mediaCallCharacteristicsInAck ( 9),    -- optional parameters
    privateDataInAck         (10),    -- optional parameters
    reportsWithSnapsDeviceData (11)}    -- miscellaneous characteristics
```

```
SnapshotCallData ::= BIT STRING
{
    segmentID                ( 0),  -- optional parameters
    localConnectionState     ( 1),  -- optional parameters
    mediaServiceInformationList ( 2),  -- optional parameters
    mediaServiceVersion       ( 3),  -- optional parameters
    mediaServiceInstance      ( 4),  -- optional parameters
    mediaStreamID             ( 5),  -- optional parameters
    connectionInformation     ( 6),  -- optional parameters
    privateData               ( 7)}  -- optional parameters

SnapshotDeviceData ::= BIT STRING
{
    segmentID                ( 0),  -- optional parameters
    localCallStateCompoundCallState ( 1),  -- optional parameters
    localCallStateSimpleCallState ( 2),  -- optional parameters
    localCallStateUnknown     ( 3),  -- optional parameters
    mediaServiceInformationList ( 4),  -- optional parameters
    mediaServiceVersion       ( 5),  -- optional parameters
    mediaServiceInstance      ( 6),  -- optional parameters
    mediaStreamID             ( 7),  -- optional parameters
    connectionInformation     ( 8),  -- optional parameters
    mediaCallCharacteristics   ( 9),  -- optional parameters
    privateData               (10)}  -- optional parameters

-- 12.4.5
CallControlServList ::= SEQUENCE
{
    acceptCall                [0] IMPLICIT AcceptCall          OPTIONAL,
    alternateCall              [1] IMPLICIT AlternateCall       OPTIONAL,
    answerCall                 [2] IMPLICIT AnswerCall          OPTIONAL,
    callBack                   [3] IMPLICIT CallBack            OPTIONAL,
    callBackMessage            [4] IMPLICIT CallBackMessage     OPTIONAL,
    campOnCall                 [5] IMPLICIT CampOnCall          OPTIONAL,
    clearCall                  [6] IMPLICIT ClearCall           OPTIONAL,
    clearConnection            [7] IMPLICIT ClearConnection     OPTIONAL,
    conferenceCall             [8] IMPLICIT ConferenceCall      OPTIONAL,
    consultationCall           [9] IMPLICIT ConsultationCall    OPTIONAL,
    deflectCall                [10] IMPLICIT DeflectCall        OPTIONAL,
    dialDigits                 [11] IMPLICIT DialDigits         OPTIONAL,
    directedPickupCall         [12] IMPLICIT DirectedPickupCall  OPTIONAL,
    groupPickupCall            [13] IMPLICIT GroupPickupCall     OPTIONAL,
    holdCall                   [14] IMPLICIT HoldCall           OPTIONAL,
    intrudeCall                [15] IMPLICIT IntrudeCall        OPTIONAL,
    joinCall                   [16] IMPLICIT JoinCall           OPTIONAL,
    makeCall                   [17] IMPLICIT MakeCall           OPTIONAL,
    makePredictiveCall         [18] IMPLICIT MakePredictiveCall  OPTIONAL,
    parkCall                   [19] IMPLICIT ParkCall           OPTIONAL,
    reconnectCall              [20] IMPLICIT ReconnectCall      OPTIONAL,
    retrieveCall               [21] IMPLICIT RetrieveCall       OPTIONAL,
    singleStepConference       [22] IMPLICIT SingleStepConference OPTIONAL,
    singleStepTransfer         [23] IMPLICIT SingleStepTransfer  OPTIONAL,
    transferCall               [24] IMPLICIT TransferCall       OPTIONAL}

AcceptCall ::= BIT STRING
{
    correlatorData            ( 0),  -- optional parameters
    userData                  ( 1),  -- optional parameters
    privateData               ( 2),  -- optional parameters
    privateDataInAck          ( 3),  -- optional parameters
    deviceIDOnly              ( 4),  -- misc characteristics
    ackModelMultiStep         ( 5)}  -- misc characteristics

AlternateCall ::= BIT STRING
{
    alerting                  ( 0),  -- initial states heldCall
    hold                       ( 1),  -- initial states heldCall
    queued                    ( 2),  -- initial states heldCall
    connectionReservation     ( 3),  -- optional parameters
    consultOptionConsultOnly   ( 4),  -- optional parameters
    consultOptionTransferOnly  ( 5),  -- optional parameters
    consultOptionConferenceOnly ( 6),  -- optional parameters
    consultOptionUnrestricted  ( 7),  -- optional parameters
```

```
privateData                ( 8),  -- optional parameters
privateDataInAck           ( 9),  -- optional parameters
deviceIDOnly               (10),  -- misc characteristics
ackModelMultiStep          (11),  -- misc characteristics
supportsOfferedModeOfAlerting (12)} -- misc characteristics

AnswerCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    initiated               ( 1),  -- initial states
    queued                  ( 2),  -- initial states
    correlatorData          ( 3),  -- optional parameters
    userData                ( 4),  -- optional parameters
    privateData             ( 5),  -- optional parameters
    privateDataInAck        ( 6),  -- optional parameters
    deviceIDOnly            ( 7),  -- misc characteristics
    supportsOfferedModeOfAlerting ( 8),  -- misc characteristics
    ackModelMultiStep       ( 9)} -- misc characteristics

CallBack ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    null                    ( 1),  -- initial states
    failed                   ( 2),  -- initial states
    queued                   ( 3),  -- initial states
    callCharacteristics      ( 4),  -- optional parameters
    privateData             ( 5),  -- optional parameters
    targetDeviceInAck        ( 6),  -- optional parameters
    privateDataInAck        ( 7),  -- optional parameters
    deviceIDOnly            ( 8),  -- misc characteristics
    moreCallBacksNegAck      ( 9),  -- misc characteristics
    ackModelMultiStep       (10)} -- misc characteristics

CallBackMessage ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    null                    ( 1),  -- initial states
    failed                   ( 2),  -- initial states
    queued                   ( 3),  -- initial states
    privateData             ( 4),  -- optional parameters
    targetDeviceInAck        ( 5),  -- optional parameters
    privateDataInAck        ( 6),  -- optional parameters
    deviceIDOnly            ( 7),  -- misc characteristics
    moreCallBacksNegAck      ( 8),  -- misc characteristics
    ackModelMultiStep       ( 9)} -- misc characteristics

CampOnCall ::= BIT STRING
{
    privateData             ( 0),  -- optional parameters
    privateDataInAck        ( 1),  -- optional parameters
    deviceIDOnly            ( 2),  -- misc characteristics
    ackModelMultiStep       ( 3)} -- misc characteristics

ClearCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    connected               ( 1),  -- initial states
    failed                   ( 2),  -- initial states
    queued                   ( 3),  -- initial states
    initiated               ( 4),  -- initial states
    hold                    ( 5),  -- initial states
    userData                ( 6),  -- optional parameters
    privateData             ( 7),  -- optional parameters
    privateDataInAck        ( 8),  -- optional parameters
    deviceIDOnly            ( 9),  -- misc characteristics
    callIDOnly              (10),  -- misc characteristics
    ackModelMultiStep       (11)} -- misc characteristics

ClearConnection ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    connected               ( 1),  -- initial states
    fail                    ( 2),  -- initial states
    queued                   ( 3),  -- initial states
```

```

    initiated                ( 4),  -- initial states
    hold                     ( 5),  -- initial states
    correlatorData           ( 6),  -- optional parameters
    userData                 ( 7),  -- optional parameters
    privateData              ( 8),  -- optional parameters
    privateDataInAck         ( 9),  -- optional parameters
    deviceIDOnly             (10),  -- misc characteristics
    ackModelMultiStep        (11)}  -- misc characteristics

ConferenceCall ::= BIT STRING
{
    activeCallConnected      ( 0),  -- initial states
    activeCallHold           ( 1),  -- initial states
    heldCallConnected        ( 2),  -- initial states
    heldCallHold             ( 3),  -- initial states
    privateData              ( 4),  -- optional parameters
    connectionParameterInAck ( 5),  -- optional parameters
    endpointDeviceID         ( 6),  -- optional parameters
    resultingConnectionInfo  ( 7),  -- optional parameters
    conferenceCallOnfoInAck  ( 8),  -- optional parameters
    privateDataInAck         ( 9),  -- optional parameters
    protectedAgainstClearing (10),  -- misc characteristics
    deviceIDOnly             (11),  -- misc characteristics
    ackModelMultiStep        (12)}  -- misc characteristics

ConsultationCall ::= BIT STRING
{
    connectionReservation    ( 0),  -- optional parameters
    accountCode              ( 1),  -- optional parameters
    authCode                 ( 2),  -- optional parameters
    correlatorData           ( 3),  -- optional parameters
    userData                 ( 4),  -- optional parameters
    callCharacteristics       ( 5),  -- optional parameters
    callCharacteristicsACDCall ( 6),  -- optional parameters
    callCharacteristicsPriorityCall ( 7),  -- optional parameters
    callCharacteristicsMaintenanceCall ( 8),  -- optional parameters
    callCharacteristicsDirectAgent ( 9),  -- optional parameters
    callCharacteristicsAssistCall (10),  -- optional parameters
    callCharacteristicsVoiceUnitCall (11),  -- optional parameters
    mediaCallCharacteristics  (12),  -- optional parameters
    callingConnectionInfo     (13),  -- optional parameters
    flowDirectionTransmit     (14),  -- optional parameters
    flowDirectionReceive      (15),  -- optional parameters
    flowDirectionTransmitAndReceive (16),  -- optional parameters
    numberOfChannels          (17),  -- optional parameters
    consultOptionConsultOnly  (18),  -- optional parameters
    consultOptionTransferOnly (19),  -- optional parameters
    consultOptionConferenceOnly (20),  -- optional parameters
    consultOptionUnrestricted (21),  -- optional parameters
    privateData              (22),  -- optional parameters
    initiatedCallInfoInAck    (23),  -- optional parameters
    privateDataInAck         (24),  -- optional parameters
    deviceIDOnly             (25),  -- misc characteristics
    multiStage               (26),  -- misc characteristics
    supportsAdjustmentOfMediaCharacteristics (27),  -- misc characteristics
    ackModelMultiStep        (28)}  -- misc characteristics

DeflectCall ::= BIT STRING
{
    alerting                 ( 0),  -- initial states
    connected                ( 1),  -- initial states
    failed                   ( 2),  -- initial states
    hold                     ( 3),  -- initial states
    queued                   ( 4),  -- initial states
    correlatorData           ( 5),  -- optional parameters
    userData                 ( 6),  -- optional parameters
    privateData              ( 7),  -- optional parameters
    privateDataInAck         ( 8),  -- optional parameters
    deviceIDOnly             ( 9),  -- misc characteristics
    ackModelMultiStep        (10)}  -- misc characteristics
```



```
DialDigits ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    privateData             ( 1),  -- optional parameters
    privateDataInAck        ( 2),  -- optional parameters
    deviceIDOnly            ( 3),  -- misc characteristics
    ackModelMultiStep       ( 4)}  -- misc characteristics

DirectedPickupCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    hold                    ( 1),  -- initial states
    queued                  ( 2),  -- initial states
    connected               ( 3),  -- initial states
    correlatorData          ( 4),  -- optional parameters
    userData                ( 5),  -- optional parameters
    privateData             ( 6),  -- optional parameters
    pickedCallInAck         ( 7),  -- optional parameters
    pickedCallInfoInAck     ( 8),  -- optional parameters
    privateDataInAck        ( 9),  -- optional parameters
    deviceIDOnly            (10),  -- misc characteristics
    supportsOfferedModeOfAlerting (11), -- misc characteristics
    supportsPrompting       (12),  -- misc characteristics
    promptingMode           (13),  -- misc characteristics
    ackModelMultiStep       (14)}  -- misc characteristics

GroupPickupCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    connected               ( 1),  -- initial states
    hold                    ( 2),  -- initial states
    queued                  ( 3),  -- initial states
    pickGroup               ( 4),  -- optional parameters
    correlatorData          ( 5),  -- optional parameters
    userData                ( 6),  -- optional parameters
    privateData             ( 7),  -- optional parameters
    pickedCallInAck         ( 8),  -- optional parameters
    pickedCallInfoInAck     ( 9),  -- optional parameters
    privateDataInAck        (10),  -- optional parameters
    supportsPrompting       (11),  -- misc characteristics
    promptingMode           (12),  -- misc characteristics
    supportsOfferedModeOfAlerting (13), -- misc characteristics
    ackModelMultiStep       (14)}  -- misc characteristics

HoldCall ::= BIT STRING
{
    connectionReservation   ( 0),  -- optional parameters
    privateData             ( 1),  -- optional parameters
    privateDataInAck        ( 2),  -- optional parameters
    deviceIDOnly            ( 3),  -- misc characteristics
    ackModelMultiStep       ( 4)}  -- misc characteristics

IntrudeCall ::= BIT STRING
{
    participationTypeSilent ( 0),  -- optional parameters
    participationTypeActive ( 1),  -- optional parameters
    userData                ( 2),  -- optional parameters
    privateData             ( 3),  -- optional parameters
    conferencedCallInfoInAck ( 4), -- optional parameters
    privateDataInAck        ( 5),  -- optional parameters
    deviceIDOnly            ( 6),  -- misc characteristics
    supportsConference      ( 7),  -- misc characteristics
    supportsAlternate       ( 8),  -- misc characteristics
    ackModelMultiStep       ( 9)}  -- misc characteristics

JoinCall ::= BIT STRING
{
    autoOriginatePrompt     ( 0),  -- optional parameters
    autoOriginateDoNotPrompt ( 1), -- optional parameters
    participationTypeSilent ( 2),  -- optional parameters
    participationTypeActive ( 3),  -- optional parameters
    accountCode             ( 4),  -- optional parameters
    authCode                 ( 5),  -- optional parameters
    correlatorData          ( 6),  -- optional parameters
```

```

    userData                ( 7),  -- optional parameters
    conferencedCallInAck    ( 8),  -- optional parameters
    conferencedCallInfoInAck ( 9),  -- optional parameters
    privateDataInAck        (10),  -- optional parameters
    deviceIDOnly            (11),  -- misc characteristics
    supportsPrompting       (12),  -- misc characteristics
    promptingMode           (13),  -- misc characteristics
    ackModelMultiStep       (14)}  -- misc characteristics

MakeCall ::= BIT STRING
{
    initiated                ( 0),  -- initials states
    null                    ( 1),  -- initials states
    accountCode              ( 2),  -- optional parameters
    authCode                 ( 3),  -- optional parameters
    autoOriginatePrompt      ( 4),  -- optional parameters
    autoOriginateDoNotPrompt ( 5),  -- optional parameters
    correlatorData          ( 6),  -- optional parameters
    userData                ( 7),  -- optional parameters
    callCharacteristics      ( 8),  -- optional parameters
    callCharacteristicsACDCall ( 9),  -- optional parameters
    callCharacteristicsPriorityCall (10),  -- optional parameters
    callCharacteristicsMaintenanceCall (11),  -- optional parameters
    callCharacteristicsDirectAgent (12),  -- optional parameters
    callCharacteristicsAssistCall (13),  -- optional parameters
    callCharacteristicsVoiceUnitCall (14),  -- optional parameters
    mediaCallCharacteristics (15),  -- optional parameters
    callingConnectionInfo    (16),  -- optional parameters
    privateData              (17),  -- optional parameters
    initiatedCallInfoInAck   (18),  -- optional parameters
    privateDataInAck         (19),  -- optional parameters
    deviceIDOnly             (20),  -- misc characteristics
    multiStage               (21),  -- misc characteristics
    supportsPrompting        (22),  -- misc characteristics
    promptingMode            (23),  -- misc characteristics
    offHook                  (24),  -- misc characteristics
    mediaCharacteristicsAdjustable (25),  -- misc characteristics
    ackModelMultiStep        (26)}  -- misc characteristics

MakePredictiveCall ::= BIT STRING
{
    signallingDetection      ( 0),  -- optional parameters
    signallingConditionCallDelivered ( 1),  -- optional parameters
    signallingConditionCallEstablished ( 2),  -- optional parameters
    signallingConditionActionDestinationDetection ( 3),  -- optional parameters
    signallingConditionActionRemainConnected ( 4),  -- optional parameters
    destinationDetection    ( 5),  -- optional parameters
    destinationConditionHumanVoice ( 6),  -- optional parameters
    destinationConditionAnsweringMachine ( 7),  -- optional parameters
    destinationConditionFax ( 8),  -- optional parameters
    destinationActionClearConnection ( 9),  -- optional parameters
    destinationActionRemainConnected (10),  -- optional parameters
    defaultActionClearConnection (11),  -- optional parameters
    defaultActionRemainConnected (12),  -- optional parameters
    accountCode              (13),  -- optional parameters
    authCode                 (14),  -- optional parameters
    autoOriginatePrompt      (15),  -- optional parameters
    autoOriginateDoNotPrompt (16),  -- optional parameters
    alertTime                (17),  -- optional parameters
    correlatorData          (18),  -- optional parameters
    callCharacteristics      (19),  -- optional parameters
    callCharacteristicsACDCall (20),  -- optional parameters
    callCharacteristicsPriorityCall (21),  -- optional parameters
    callCharacteristicsMaintenanceCall (22),  -- optional parameters
    callCharacteristicsDirectAgent (23),  -- optional parameters
    callCharacteristicsAssistCall (24),  -- optional parameters
    callCharacteristicsVoiceUnitCall (25),  -- optional parameters
    userData                (26),  -- optional parameters
    privateData              (27),  -- optional parameters
    initiatedCallInfoInAck   (28),  -- optional parameters
}
```

```
privateDataInAck          (29),  -- optional parameters
deviceIDOnly              (30),  -- misc characteristics
supportsPrompting         (31),  -- misc characteristics
promptingMode             (32),  -- misc characteristics
reservesCallingDevice     (33),  -- misc characteristics
ackModelMultiStep        (34)}  -- misc characteristics

ParkCall ::= BIT STRING
{
    hold                  ( 0),  -- initial states
    connected             ( 1),  -- initial states
    correlatorData        ( 2),  -- optional parameters
    privateData           ( 3),  -- optional parameters
    parkedToInAck         ( 4),  -- optional parameters
    privateDataInAck      ( 5),  -- optional parameters
    deviceIDOnly          ( 6),  -- misc characteristics
    ackModelMultiStep     ( 7)}  -- misc characteristics

ReconnectCall ::= BIT STRING
{
    alerting              ( 0),  -- initial states
    connected             ( 1),  -- initial states
    fail                  ( 2),  -- initial states
    initiated              ( 3),  -- initial states
    queued                ( 4),  -- initial states
    privateData           ( 5),  -- optional parameters
    privateDataInAck      ( 6),  -- optional parameters
    deviceIDOnly          ( 7),  -- misc characteristics
    ackModelMultiStep     ( 8)}  -- misc characteristics

RetrieveCall ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    privateDataInAck      ( 1),  -- optional parameters
    deviceIDOnly          ( 2),  -- misc characteristics
    ackModelMultiStep     ( 3)}  -- misc characteristics

SingleStepConference ::= BIT STRING
{
    participationTypeActive ( 0),  -- optional parameters
    participationTypeSilent ( 1),  -- optional parameters
    accountCode            ( 2),  -- optional parameters
    authCode               ( 3),  -- optional parameters
    correlatorData         ( 4),  -- optional parameters
    userData               ( 5),  -- optional parameters
    privateData            ( 6),  -- optional parameters
    conferencedCallInfoInAck ( 7),  -- optional parameters
    privateDataInAck       ( 8),  -- optional parameters
    deviceIDOnly           ( 9),  -- misc characteristics
    ackModelMultiStep      (10)}  -- misc characteristics

SingleStepTransfer ::= BIT STRING
{
    accountCode           ( 0),  -- optional parameters
    authCode              ( 1),  -- optional parameters
    correlatorData        ( 2),  -- optional parameters
    userData              ( 3),  -- optional parameters
    privateData           ( 4),  -- optional parameters
    connectionParameterInAck ( 5),  -- optional parameters
    endpointDeviceID      ( 6),  -- optional parameters
    resolutionConnectionInformation ( 7),  -- optional parameters
    transferredCollInfoInAck ( 8),  -- optional parameters
    privateDataInAck      ( 9),  -- optional parameters
    deviceIDOnly          (10),  -- misc characteristics
    multipleDevices       (11),  -- misc characteristics
    ackModelMultiStep     (12)}  -- misc characteristics

TransferCall ::= BIT STRING
{
    activeCallConnected    ( 0),  -- initial states
    activeCallHold         ( 1),  -- initial states
    heldCallConnected      ( 2),  -- initial states
    heldCallHold           ( 3),  -- initial states
    privateData            ( 4),  -- optional parameters
```

```
connectionsParameterInAck      ( 5),  -- optional parameters
endpointDeviceID               ( 6),  -- optional parameters
resultingConnectionInformation ( 7),  -- optional parameters
transferredCallInfoInAck       ( 8),  -- optional parameters
privateDataInAck               ( 9),  -- optional parameters
deviceIDOnly                   (10),  -- misc characteristics
multipleDevices                (11),  -- misc characteristics
ackModelMultiStep              (12)}  -- misc characteristics

-- 12.4.6

CallControlEvtsList ::= SEQUENCE
{
    bridged                [0] IMPLICIT Bridged                OPTIONAL,
    callCleared            [1] IMPLICIT CallCleared            OPTIONAL,
    conferenced            [2] IMPLICIT Conferenced            OPTIONAL,
    connectionCleared      [3] IMPLICIT ConnectionCleared      OPTIONAL,
    delivered              [4] IMPLICIT Delivered              OPTIONAL,
    digitsDialed           [5] IMPLICIT DigitsDialed           OPTIONAL,
    diverted               [6] IMPLICIT Diverted               OPTIONAL,
    established            [7] IMPLICIT Established            OPTIONAL,
    failed                 [8] IMPLICIT Failed                 OPTIONAL,
    held                   [9] IMPLICIT Held                   OPTIONAL,
    netwCapsChanged        [10] IMPLICIT NetwCapsChanged        OPTIONAL,
    netwReached            [11] IMPLICIT NetwReached            OPTIONAL,
    offered                [12] IMPLICIT Offered                OPTIONAL,
    originated             [13] IMPLICIT Originated             OPTIONAL,
    queued                [14] IMPLICIT Queued                 OPTIONAL,
    retrieved              [15] IMPLICIT Retrieved              OPTIONAL,
    serviceInitiated       [16] IMPLICIT ServiceInitiated       OPTIONAL,
    transferred            [17] IMPLICIT Transferred            OPTIONAL }

Bridged ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    servicesPermitted        ( 2),  -- optional parameters
    mediaCallCharacteristics ( 3),  -- optional parameters
    callCharacteristics      ( 4),  -- optional parameters
    bridgedConnectionInfo    ( 5),  -- optional parameters
    privateData              ( 6)}  -- optional parameters

CallCleared ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    mediaCallCharacteristics ( 2),  -- optional parameters
    callCharacteristics      ( 3),  -- optional parameters
    privateData              ( 4),  -- optional parameters
    callIDOnly              ( 5)}  -- miscellaneous characteristics

Conferenced ::= BIT STRING
{
    confereceConnectionsEndpointDeviceID ( 0),  -- optional parameters
    confereceConnectionsresultingConnectionInfo ( 1),  -- optional parameters
    userData                ( 2),  -- optional parameters
    servicesPermitted        ( 3),  -- optional parameters
    mediaCallCharacteristics ( 4),  -- optional parameters
    callCharacteristics      ( 5),  -- optional parameters
    bridgedConnectionInfo    ( 6),  -- optional parameters
    privateData              ( 7)}  -- optional parameters

ConnectionCleared ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    chargingInfo            ( 2),  -- optional parameters
    numberUnitsNumberOfChargingUnits    ( 3),  -- optional parameters
    numberUnitsTypeOfUnits    ( 4),  -- optional parameters
    numberUnitsNumberOfCurrencyUnits    ( 5),  -- optional parameters
    typeOfChargingInfoSubTotal ( 6),  -- optional parameters
    typeOfChargingInfoTotal   ( 7),  -- optional parameters
```

```
chargingMultiplierATHousandth      ( 8),  -- optional parameters
chargingMultiplierAHundredth       ( 9),  -- optional parameters
chargingMultiplierATenth            (10),  -- optional parameters
chargingMultiplierOne               (11),  -- optional parameters
chargingMultiplierTen               (12),  -- optional parameters
chargingMultiplierHundred           (13),  -- optional parameters
chargingMultiplierThousand          (14),  -- optional parameters
servicesPermitted                   (15),  -- optional parameters
mediaCallCharacteristics            (16),  -- optional parameters
callCharacteristics                 (17),  -- optional parameters
droppedConnectionInfo              (18),  -- optional parameters
privateData                         (19)}  -- optional parameters

Delivered ::= BIT STRING
{
    originatingNIDConnection      ( 0),  -- optional parameters
    userData                      ( 1),  -- optional parameters
    servicesPermitted             ( 2),  -- optional parameters
    netwCallingDevice             ( 3),  -- optional parameters
    netwCalledDevice              ( 4),  -- optional parameters
    mediaCallCharacteristics       ( 5),  -- optional parameters
    callCharacteristics            ( 6),  -- optional parameters
    connectionInfo                ( 7),  -- optional parameters
    privateData                   ( 8)}  -- optional parameters

DigitsDialed ::= BIT STRING
{
    servicesPermitted             ( 0),  -- optional parameters
    netwCallingDevice             ( 1),  -- optional parameters
    netwCalledDevice              ( 2),  -- optional parameters
    diallingConnectionInfo        ( 3),  -- optional parameters
    callCharacteristics            ( 4),  -- optional parameters
    privateData                   ( 5)}  -- optional parameters

Diverted ::= BIT STRING
{
    callingDevice                 ( 0),  -- optional parameters
    calledDevice                  ( 1),  -- optional parameters
    userData                      ( 2),  -- optional parameters
    servicesPermitted             ( 3),  -- optional parameters
    mediaCallCharacteristics       ( 4),  -- optional parameters
    callCharacteristics            ( 5),  -- optional parameters
    connectionInfo                ( 6),  -- optional parameters
    netwCallingDevice             ( 7),  -- optional parameters
    netwCalledDevice              ( 8),  -- optional parameters
    privateData                   ( 9),  -- optional parameters
    sendsDivertedToAll            (10)}  -- optional parameters

Established ::= BIT STRING
{
    originatingNIDConnection      ( 0),  -- optional parameters
    userData                      ( 1),  -- optional parameters
    servicesPermitted             ( 2),  -- optional parameters
    netwCallingDevice             ( 3),  -- optional parameters
    netwCalledDevice              ( 4),  -- optional parameters
    mediaCallCharacteristics       ( 5),  -- optional parameters
    callCharacteristics            ( 6),  -- optional parameters
    establishedConnectionInfo      ( 7),  -- optional parameters
    privateData                   ( 8)}  -- optional parameters

Failed ::= BIT STRING
{
    originatingNIDConnection      ( 0),  -- optional parameters
    userData                      ( 1),  -- optional parameters
    servicesPermitted             ( 2),  -- optional parameters
    netwCallingDevice             ( 3),  -- optional parameters
    netwCalledDevice              ( 4),  -- optional parameters
    mediaCallCharacteristics       ( 5),  -- optional parameters
    callCharacteristics            ( 6),  -- optional parameters
    failedConnectionInfo          ( 7),  -- optional parameters
    privateData                   ( 8),  -- optional parameters
    callIDOnly                    ( 9)}  -- miscellaneous characteristics
```

```
Held ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    servicesPermitted       ( 1),  -- optional parameters
    mediaCallCharacteristics ( 2),  -- optional parameters
    callCharacteristics     ( 3),  -- optional parameters
    heldConnectionInfo      ( 4),  -- optional parameters
    privateData             ( 5)}  -- optional parameters
```

```
NetwCapsChanged ::= BIT STRING
{
    progressLocationUser          ( 0),  -- optional parameters
    progressLocationPrivateServLocal ( 1),  -- optional parameters
    progressLocationPublicServLocal ( 2),  -- optional parameters
    progressLocationTransit       ( 3),  -- optional parameters
    progressLocationPublicServRemote ( 4),  -- optional parameters
    progressLocationPrivateServRemote ( 5),  -- optional parameters
    progressLocationLocal         ( 6),  -- optional parameters
    progressLocationInternational ( 7),  -- optional parameters
    progressLocationNetwBeyondInterworking ( 8),  -- optional parameters
    progressLocationOther         ( 9),  -- optional parameters
    progressDescriptionISDN       (10),  -- optional parameters
    progressDescriptionQSIG       (11),  -- optional parameters
    progressDescriptionOther      (12),  -- optional parameters
    userData                     (13),  -- optional parameters
    typeOfNetworkISDNPublic       (14),  -- optional parameters
    typeOfNetworkNonISDNPublic    (15),  -- optional parameters
    typeOfNetworkISDNPrivate      (16),  -- optional parameters
    typeOfNetworkNonISDNPrivate   (17),  -- optional parameters
    typeOfNetworkOther            (18),  -- optional parameters
    eventsProvidedParameter       (19),  -- optional parameters
    eventsProvidedBridged         (20),  -- optional parameters
    eventsProvidedCallCleared     (21),  -- optional parameters
    eventsProvidedConferenced     (22),  -- optional parameters
    eventsProvidedConnectionCleared (23),  -- optional parameters
    eventsProvidedDelivered       (24),  -- optional parameters
    eventsProvidedDigitsDialed    (25),  -- optional parameters
    eventsProvidedDiverted        (26),  -- optional parameters
    eventsProvidedEstablished     (27),  -- optional parameters
    eventsProvidedFailed          (28),  -- optional parameters
    eventsProvidedHeld            (29),  -- optional parameters
    eventsProvidedNetwCapsChanged (30),  -- optional parameters
    eventsProvidedNetwReached     (31),  -- optional parameters
    eventsProvidedOffered         (32),  -- optional parameters
    eventsProvidedOriginated      (33),  -- optional parameters
    eventsProvidedQueued          (34),  -- optional parameters
    eventsProvidedRetrieved       (35),  -- optional parameters
    eventsProvidedServiceInitiated (36),  -- optional parameters
    eventsProvidedTransferd       (37),  -- optional parameters
    servicesPermitted             (38),  -- optional parameters
    mediaCallCharacteristics      (39),  -- optional parameters
    callCharacteristics           (40),  -- optional parameters
    outboundConnectionInfo        (41),  -- optional parameters
    privateData                   (42)}  -- optional parameters
```

```
NetwReached ::= BIT STRING
{
    originatingNIDConnection ( 0),  -- optional parameters
    userData                 ( 1),  -- optional parameters
    typeOfNetworkISDNPublic  ( 2),  -- optional parameters
    typeOfNetworkNonISDNPublic ( 3),  -- optional parameters
    typeOfNetworkISDNPrivate ( 4),  -- optional parameters
    typeOfNetworkNonISDNPrivate ( 5),  -- optional parameters
    typeOfNetworkOther       ( 6),  -- optional parameters
    eventsProvidedParameter   ( 7),  -- optional parameters
    eventsProvidedBridged     ( 8),  -- optional parameters
    eventsProvidedCallCleared ( 9),  -- optional parameters
    eventsProvidedConferenced (10),  -- optional parameters
    eventsProvidedConnectionCleared (11),  -- optional parameters
    eventsProvidedDelivered   (12),  -- optional parameters
    eventsProvidedDigitsDialed (13),  -- optional parameters
```

```
eventsProvidedDiverted      (14),      -- optional parameters
eventsProvidedEstablished   (15),      -- optional parameters
eventsProvidedFailed        (16),      -- optional parameters
eventsProvidedHeld          (17),      -- optional parameters
eventsProvidedNetwCapsChanged (18),      -- optional parameters
eventsProvidedNetwReached   (19),      -- optional parameters
eventsProvidedOffered       (20),      -- optional parameters
eventsProvidedOriginated    (21),      -- optional parameters
eventsProvidedQueued        (22),      -- optional parameters
eventsProvidedRetrieved     (23),      -- optional parameters
eventsProvidedServiceInitiated (24),    -- optional parameters
eventsProvidedTransferd     (25),      -- optional parameters
servicesPermitted           (26),      -- optional parameters
mediaCallCharacteristics    (27),      -- optional parameters
callCharacteristics         (28),      -- optional parameters
outboundConnectionInfo     (29),      -- optional parameters
netwCallingDevice          (30),      -- optional parameters
netwCalledDevice           (31),      -- optional parameters
privateData                 (32)}      -- optional parameters

Offered ::= BIT STRING
{
    originatingNIDConnection      ( 0),  -- optional parameters
    userData                      ( 1),  -- optional parameters
    servicesPermitted             ( 2),  -- optional parameters
    netwCallingDevice             ( 3),  -- optional parameters
    netwCalledDevice              ( 4),  -- optional parameters
    mediaCallCharacteristics      ( 5),  -- optional parameters
    callCharacteristics           ( 6),  -- optional parameters
    offeredConnectionInfo         ( 7),  -- optional parameters
    privateData                   ( 8)}   -- optional parameters

Originated ::= BIT STRING
{
    originatingDevice             ( 0),  -- optional parameters
    servicesPermitted             ( 1),  -- optional parameters
    netwCallingDevice             ( 2),  -- optional parameters
    netwCalledDevice              ( 3),  -- optional parameters
    mediaCallCharacteristics      ( 4),  -- optional parameters
    callCharacteristics           ( 5),  -- optional parameters
    originatedConnectionInfo      ( 6),  -- optional parameters
    privateData                   ( 7)}   -- optional parameters

Queued ::= BIT STRING
{
    numberQueued                  ( 0),  -- optional parameters
    callsInFront                  ( 1),  -- optional parameters
    userData                      ( 2),  -- optional parameters
    servicesPermitted             ( 3),  -- optional parameters
    netwCallingDevice             ( 4),  -- optional parameters
    netwCalledDevice              ( 5),  -- optional parameters
    mediaCallCharacteristics      ( 6),  -- optional parameters
    callCharacteristics           ( 7),  -- optional parameters
    queuedConnectionInfo          ( 8),  -- optional parameters
    privateData                   ( 9)}   -- optional parameters

Retrieved ::= BIT STRING
{
    correlatorData                ( 0),  -- optional parameters
    servicesPermitted             ( 1),  -- optional parameters
    mediaCallCharacteristics      ( 2),  -- optional parameters
    callCharacteristics           ( 3),  -- optional parameters
    retrievedConnectionInfo       ( 4),  -- optional parameters
    privateData                   ( 5)}   -- optional parameters

ServiceInitiated ::= BIT STRING
{
    servicesPermitted             ( 0),  -- optional parameters
    mediaCallCharacteristics      ( 1),  -- optional parameters
    callCharacteristics           ( 2),  -- optional parameters
    initiatedConnectionInfo       ( 3),  -- optional parameters
    netwCallingDevice             ( 4),  -- optional parameters
    netwCalledDevice              ( 5),  -- optional parameters
```

```
privateData ( 6)} -- optional parameters

Transferred ::= BIT STRING
{
    transferredConnectionsEndpointDeviceID ( 0), -- optional parameters
    transferredConnectionsResultingConnectionInfo ( 1), -- optional parameters
    userData ( 2), -- optional parameters
    chargingInfo ( 3), -- optional parameters
    numberUnitsNumberOfChargingUnits ( 4), -- optional parameters
    numberUnitsTypeOfUnits ( 5), -- optional parameters
    numberUnitsNumberOfCurrencyUnits ( 6), -- optional parameters
    typeOfChargingInfoSubTotal ( 7), -- optional parameters
    typeOfChargingInfoTotal ( 8), -- optional parameters
    chargingMultiplierAThousandth ( 9), -- optional parameters
    chargingMultiplierAHundredth (10), -- optional parameters
    chargingMultiplierATenth (11), -- optional parameters
    chargingMultiplierOne (12), -- optional parameters
    chargingMultiplierTen (13), -- optional parameters
    chargingMultiplierHundred (14), -- optional parameters
    chargingMultiplierThousand (15), -- optional parameters
    servicesPermitted (16), -- optional parameters
    mediaCallCharacteristics (17), -- optional parameters
    callCharacteristics (18), -- optional parameters
    connectionInfo (19), -- optional parameters
    privateData (20)} -- optional parameters

-- 12.4.7
CallAssociatedServList ::= SEQUENCE
{
    associateData [0] IMPLICIT AssociateData OPTIONAL,
    cancelTelephonyTones [1] IMPLICIT CancelTelephonyTones OPTIONAL,
    generateDigits [2] IMPLICIT GenerateDigits OPTIONAL,
    generateTelephonyTones [3] IMPLICIT GenerateTelephonyTones OPTIONAL,
    sendUserInformation [4] IMPLICIT SendUserInformation OPTIONAL}

AssociateData ::= BIT STRING
{
    accountCode ( 0), -- optional parameters
    authCode ( 1), -- optional parameters
    correlatorData ( 2), -- optional parameters
    callQualifyingData ( 3), -- optional parameters
    privateData ( 4), -- optional parameters
    privateDataInAck ( 5), -- optional parameters
    deviceIDOnly ( 6), -- misc characteristics
    rejectsRequestsWithOldConnectionID ( 7), -- misc characteristics
    ackModelMultiStep ( 8)} -- misc characteristics

CancelTelephonyTones ::= BIT STRING
{
    privateData ( 0), -- optional parameters
    privateDataInAck ( 1), -- optional parameters
    ackModelMultiStep ( 2)} -- misc characteristics

GenerateDigits ::= BIT STRING
{
    digitModeDTMF ( 0), -- optional parameters
    digitModePulse ( 1), -- optional parameters
    toneDuration ( 2), -- optional parameters
    pulseRate ( 3), -- optional parameters
    pauseDuration ( 4), -- optional parameters
    privateData ( 5), -- optional parameters
    privateDataInAck ( 6), -- optional parameters
    deviceIDOnly ( 7), -- misc characteristics
    supportsDTMFtonesABCD ( 8), -- misc characteristics
    supportsPauseToneChar ( 9), -- misc characteristics
    ackModelMultiStep (10)} -- misc characteristics

GenerateTelephonyTones ::= BIT STRING
{
    toneToSendBeep ( 0), -- optional parameters
    toneToSendBilling ( 1), -- optional parameters
    toneToSendBusy ( 2), -- optional parameters
```


toneToSendCarrier	(3),	-- optional parameters
toneToSendConfirmation	(4),	-- optional parameters
toneToSendDial	(5),	-- optional parameters
toneToSendFaxCNG	(6),	-- optional parameters
toneToSendHold	(7),	-- optional parameters
toneToSendHowler	(8),	-- optional parameters
toneToSendIntrusion	(9),	-- optional parameters
toneToSendModemCNG	(10),	-- optional parameters
toneToSendPark	(11),	-- optional parameters
toneToSendRecordWarning	(12),	-- optional parameters
toneToSendReorder	(13),	-- optional parameters
toneToSendRingback	(14),	-- optional parameters
toneToSendSilence	(15),	-- optional parameters
toneToSendSitVC	(16),	-- optional parameters
toneToSendSitIC	(17),	-- optional parameters
toneToSendSitRO	(18),	-- optional parameters
toneToSendSitNC	(19),	-- optional parameters
toneToSendSf0	(20),	-- optional parameters
toneToSendSf1	(21),	-- optional parameters
toneToSendSf2	(22),	-- optional parameters
toneToSendSf3	(23),	-- optional parameters
toneToSendSf4	(24),	-- optional parameters
toneToSendSf5	(25),	-- optional parameters
toneToSendSf6	(26),	-- optional parameters
toneToSendSf7	(27),	-- optional parameters
toneToSendSf8	(28),	-- optional parameters
toneToSendSf9	(29),	-- optional parameters
toneToSendSf10	(30),	-- optional parameters
toneToSendSf11	(31),	-- optional parameters
toneToSendSf12	(32),	-- optional parameters
toneToSendSf13	(33),	-- optional parameters
toneToSendSf14	(34),	-- optional parameters
toneToSendSf15	(35),	-- optional parameters
toneToSendSf16	(36),	-- optional parameters
toneToSendSf17	(37),	-- optional parameters
toneToSendSf18	(38),	-- optional parameters
toneToSendSf19	(39),	-- optional parameters
toneToSendSf20	(40),	-- optional parameters
toneToSendSf21	(41),	-- optional parameters
toneToSendSf22	(42),	-- optional parameters
toneToSendSf23	(43),	-- optional parameters
toneToSendSf24	(44),	-- optional parameters
toneToSendSf25	(45),	-- optional parameters
toneToSendSf26	(46),	-- optional parameters
toneToSendSf27	(47),	-- optional parameters
toneToSendSf28	(48),	-- optional parameters
toneToSendSf29	(49),	-- optional parameters
toneToSendSf30	(50),	-- optional parameters
toneToSendSf31	(51),	-- optional parameters
toneToSendSf32	(52),	-- optional parameters
toneToSendSf33	(53),	-- optional parameters
toneToSendSf34	(54),	-- optional parameters
toneToSendSf35	(55),	-- optional parameters
toneToSendSf36	(56),	-- optional parameters
toneToSendSf37	(57),	-- optional parameters
toneToSendSf38	(58),	-- optional parameters
toneToSendSf39	(59),	-- optional parameters
toneToSendSf40	(60),	-- optional parameters
toneToSendSf41	(61),	-- optional parameters
toneToSendSf42	(62),	-- optional parameters
toneToSendSf43	(63),	-- optional parameters
toneToSendSf44	(64),	-- optional parameters
toneToSendSf45	(65),	-- optional parameters
toneToSendSf46	(66),	-- optional parameters
toneToSendSf47	(67),	-- optional parameters
toneToSendSf48	(68),	-- optional parameters
toneToSendSf49	(69),	-- optional parameters
toneToSendSf50	(70),	-- optional parameters

```
toneToSendSf51      (71),  -- optional parameters
toneToSendSf52      (72),  -- optional parameters
toneToSendSf53      (73),  -- optional parameters
toneToSendSf54      (74),  -- optional parameters
toneToSendSf55      (75),  -- optional parameters
toneToSendSf56      (76),  -- optional parameters
toneToSendSf57      (77),  -- optional parameters
toneToSendSf58      (78),  -- optional parameters
toneToSendSf59      (79),  -- optional parameters
toneToSendSf60      (80),  -- optional parameters
toneToSendSf61      (81),  -- optional parameters
toneToSendSf62      (82),  -- optional parameters
toneToSendSf63      (83),  -- optional parameters
toneToSendSf64      (84),  -- optional parameters
toneToSendSf65      (85),  -- optional parameters
toneToSendSf66      (86),  -- optional parameters
toneToSendSf67      (87),  -- optional parameters
toneToSendSf68      (88),  -- optional parameters
toneToSendSf69      (89),  -- optional parameters
toneToSendSf70      (90),  -- optional parameters
toneToSendSf71      (91),  -- optional parameters
toneToSendSf72      (92),  -- optional parameters
toneToSendSf73      (93),  -- optional parameters
toneToSendSf74      (94),  -- optional parameters
toneToSendSf75      (95),  -- optional parameters
toneToSendSf76      (96),  -- optional parameters
toneToSendSf77      (97),  -- optional parameters
toneToSendSf78      (98),  -- optional parameters
toneToSendSf79      (99),  -- optional parameters
toneToSendSf80      (100), -- optional parameters
toneToSendSf81      (101), -- optional parameters
toneToSendSf82      (102), -- optional parameters
toneToSendSf83      (103), -- optional parameters
toneToSendSf84      (104), -- optional parameters
toneToSendSf85      (105), -- optional parameters
toneToSendSf86      (106), -- optional parameters
toneToSendSf87      (107), -- optional parameters
toneToSendSf88      (108), -- optional parameters
toneToSendSf89      (109), -- optional parameters
toneToSendSf90      (110), -- optional parameters
toneToSendSf91      (111), -- optional parameters
toneToSendSf92      (112), -- optional parameters
toneToSendSf93      (113), -- optional parameters
toneToSendSf94      (114), -- optional parameters
toneToSendSf95      (115), -- optional parameters
toneToSendSf96      (116), -- optional parameters
toneToSendSf97      (117), -- optional parameters
toneToSendSf98      (118), -- optional parameters
toneToSendSf99      (119), -- optional parameters
toneToSendSf100     (120), -- optional parameters
toneDuration        (121), -- optional parameters
privateData          (122), -- optional parameters
privateDataInAck     (123), -- optional parameters
deviceIDOnly         (124), -- misc characteristics
ackModelMultiStep    (125)} -- misc characteristics

SendUserInfo ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1),  -- optional parameters
    deviceIDOnly         ( 2),  -- misc characteristics
    ackModelMultiStep    ( 3)}  -- misc characteristics

-- 12.4.8
CallAssociatedEvtsList ::= SEQUENCE
{
    callInformation      [0] IMPLICIT CallInformation      OPTIONAL,
    charging             [1] IMPLICIT Charging             OPTIONAL,
    digitsGenerated      [2] IMPLICIT DigitsGenerated      OPTIONAL,
    telephonyTonesGenerated [3] IMPLICIT TelephonyTonesGenerated OPTIONAL,
```

```
serviceCompletionFailure      [4] IMPLICIT ServiceCompletionFailure  OPTIONAL}

CallInformation ::= BIT STRING
{
    callingDevice              ( 0),  -- optional parameters
    accountInfo                ( 1),  -- optional parameters
    authorisationCode          ( 2),  -- optional parameters
    correlatorData             ( 3),  -- optional parameters
    servicesPermitted          ( 4),  -- optional parameters
    userData                   ( 5),  -- optional parameters
    callQualifyingData         ( 6),  -- optional parameters
    connectionInfo             ( 7),  -- optional parameters
    privateData                 ( 8),  -- optional parameters
    genCallInfoForOutdatedConnID ( 9)} -- misc characteristics

Charging ::= BIT STRING
{
    numberUnitsNumberOfChargingUnits ( 0),  -- optional parameters
    numberUnitsTypeOfUnits           ( 1),  -- optional parameters
    numberUnitsNumberOfCurrencyUnits ( 2),  -- optional parameters
    typeOfChargingInfoSubTotal       ( 3),  -- optional parameters
    typeOfChargingInfoTotal          ( 4),  -- optional parameters
    chargingMultiplierAThousandth    ( 5),  -- optional parameters
    chargingMultiplierAHundredth     ( 6),  -- optional parameters
    chargingMultiplierATenth         ( 7),  -- optional parameters
    chargingMultiplierOne             ( 8),  -- optional parameters
    chargingMultiplierTen             ( 9),  -- optional parameters
    chargingMultiplierHundred        (10),  -- optional parameters
    chargingMultiplierThousand       (11),  -- optional parameters
    privateData                       (12)} -- optional parameters

DigitsGenerated ::= BIT STRING
{
    digitsDurationList           ( 0),  -- optional parameters
    pauseDurationList            ( 1),  -- optional parameters
    connectionInfo               ( 2),  -- optional parameters
    privateData                   ( 3)} -- optional parameters

TelephonyTonesGenerated ::= BIT STRING
{
    toneToSendBeep              ( 0),  -- optional parameters
    toneToSendBilling            ( 1),  -- optional parameters
    toneToSendBusy               ( 2),  -- optional parameters
    toneToSendCarrier            ( 3),  -- optional parameters
    toneToSendConfirmation       ( 4),  -- optional parameters
    toneToSendDial               ( 5),  -- optional parameters
    toneToSendFaxCNG             ( 6),  -- optional parameters
    toneToSendHold               ( 7),  -- optional parameters
    toneToSendHowler             ( 8),  -- optional parameters
    toneToSendIntrusion          ( 9),  -- optional parameters
    toneToSendModemCNG           (10),  -- optional parameters
    toneToSendPark               (11),  -- optional parameters
    toneToSendRecordWarning      (12),  -- optional parameters
    toneToSendReorder            (13),  -- optional parameters
    toneToSendRingback           (14),  -- optional parameters
    toneToSendSilence            (15),  -- optional parameters
    toneToSendSitVC              (16),  -- optional parameters
    toneToSendSitIC              (17),  -- optional parameters
    toneToSendSitRO              (18),  -- optional parameters
    toneToSendSitNC              (19),  -- optional parameters
    toneToSendSf0                (20),  -- optional parameters
    toneToSendSf1                (21),  -- optional parameters
    toneToSendSf2                (22),  -- optional parameters
    toneToSendSf3                (23),  -- optional parameters
    toneToSendSf4                (24),  -- optional parameters
    toneToSendSf5                (25),  -- optional parameters
    toneToSendSf6                (26),  -- optional parameters
    toneToSendSf7                (27),  -- optional parameters
    toneToSendSf8                (28),  -- optional parameters
    toneToSendSf9                (29),  -- optional parameters
    toneToSendSf10               (30),  -- optional parameters
    toneToSendSf11               (31),  -- optional parameters
}
```

[illegible]

```
toneToSendSf80          (100), -- optional parameters
toneToSendSf81          (101), -- optional parameters
toneToSendSf82          (102), -- optional parameters
toneToSendSf83          (103), -- optional parameters
toneToSendSf84          (104), -- optional parameters
toneToSendSf85          (105), -- optional parameters
toneToSendSf86          (106), -- optional parameters
toneToSendSf87          (107), -- optional parameters
toneToSendSf88          (108), -- optional parameters
toneToSendSf89          (109), -- optional parameters
toneToSendSf90          (110), -- optional parameters
toneToSendSf91          (111), -- optional parameters
toneToSendSf92          (112), -- optional parameters
toneToSendSf93          (113), -- optional parameters
toneToSendSf94          (114), -- optional parameters
toneToSendSf95          (115), -- optional parameters
toneToSendSf96          (116), -- optional parameters
toneToSendSf97          (117), -- optional parameters
toneToSendSf98          (118), -- optional parameters
toneToSendSf99          (119), -- optional parameters
toneToSendSf100         (120), -- optional parameters
toneFrequency           (121), -- optional parameters
toneDuration            (122), -- optional parameters
pauseDurationList       (123), -- optional parameters
connectionInfo          (124), -- optional parameters
privateData             (125)} -- optional parameters

ServiceCompletionFailure ::= BIT STRING
{
    primaryCallConnectionInfo      ( 0), -- optional parameters
    secondaryCallConnectionInfo    ( 1), -- optional parameters
    otherDevicesPrimaryCallList    ( 2), -- optional parameters
    otherDevicesSecondaryCallList  ( 3), -- optional parameters
    mediaCallCharacteristics       ( 4), -- optional parameters
    privateData                    ( 5)} -- optional parameters

-- 12.4.9

MediaServList ::= SEQUENCE
{
    attachMediaService      [0] IMPLICIT AttachMediaService      OPTIONAL,
    detachMediaService      [1] IMPLICIT DetachMediaService      OPTIONAL}

AttachMediaService ::= BIT STRING
{
    mediaServiceVersion          ( 0), -- optional parameters
    mediaServiceInstanceID       ( 1), -- optional parameters
    connectionModeConsultConference ( 2), -- optional parameters
    connectionModeConsultConferenceHold ( 3), -- optional parameters
    connectionModeDeflect       ( 4), -- optional parameters
    connectionModeDirectedPickup ( 5), -- optional parameters
    connectionModeJoin          ( 6), -- optional parameters
    connectionModeSingleStepConference ( 7), -- optional parameters
    connectionModeSingleStepConferenceHold ( 8), -- optional parameters
    connectionModeSingleStepTransfer ( 9), -- optional parameters
    connectionModeTransfer      (10), -- optional parameters
    connectionModeDirect        (11), -- optional parameters
    requestedConnectionState     (12), -- optional parameters
    privateData                 (13), -- optional parameters
    mediaServiceInstanceIDInAck  (14), -- optional parameters
    mediaConnectionInfoInAck     (15), -- optional parameters
    privateDataInAck            (16), -- optional parameters
    deviceIDOnly                (17), -- misc characteristics
    ackModelMultiStep           (18)} -- misc characteristics

DetachMediaService ::= BIT STRING
{
    alerting          ( 0), -- initial states
    connected         ( 1), -- initial states
    fail              ( 2), -- initial states
    hold              ( 3), -- initial states
    queued            ( 4), -- initial states
```

```
privateData                ( 5),  -- optional parameters
privateDataInAck           ( 6),  -- optional parameters
deviceIDOnly               ( 7),  -- misc characteristics
ackModelMultiStep          ( 8)}  -- misc characteristics

-- 12.4.10

MediaEvtsList ::= SEQUENCE
{
    mediaAttached  [0] IMPLICIT  MediaAttached  OPTIONAL,
    mediaDetached  [1] IMPLICIT  MediaDetached  OPTIONAL}

MediaAttached  ::= BIT STRING
{
    mediaServiceVersion      ( 0),  -- optional parameters
    mediaServiceInstanceID   ( 1),  -- optional parameters
    mediaStreamID            ( 2),  -- optional parameters
    mediaCallCharacteristics ( 3),  -- optional parameters
    callCharacteristics       ( 4),  -- optional parameters
    mediaConnectionInfo       ( 5),  -- optional parameters
    privateData              ( 6)}  -- optional parameters

MediaDetached  ::= BIT STRING
{
    mediaServiceVersion      ( 0),  -- optional parameters
    mediaServiceInstanceID   ( 1),  -- optional parameters
    mediaStreamID            ( 2),  -- optional parameters
    mediaCallCharacteristics ( 3),  -- optional parameters
    callCharacteristics       ( 4),  -- optional parameters
    mediaConnectionInfo       ( 5),  -- optional parameters
    privateData              ( 6)}  -- optional parameters

-- 12.4.11
RouteingServList ::= SEQUENCE
{
    routeRegister      [ 0] IMPLICIT RouteRegister      OPTIONAL,
    routeRegisterCancel [ 1] IMPLICIT RouteRegisterCancel OPTIONAL,
    routeRegisterAbort [ 2] IMPLICIT RouteRegisterAbort  OPTIONAL,
    reRoute            [ 3] IMPLICIT ReRoute             OPTIONAL,
    routeEnd           [ 4] IMPLICIT RouteEnd            OPTIONAL,
    routeReject        [ 5] IMPLICIT RouteReject         OPTIONAL,
    routeRequest       [ 6] IMPLICIT RouteRequest        OPTIONAL,
    routeSelect        [ 7] IMPLICIT RouteSelect         OPTIONAL,
    routeUsed          [ 8] IMPLICIT RouteUsed           OPTIONAL}

RouteRegister ::= BIT STRING
{
    routeingDevice      ( 0),  -- optional parameters
    requestedMonitorMediaClass ( 1),  -- optional parameters
    requestedMonitorMediaClassAudio ( 2),  -- optional parameters
    requestedMonitorMediaClassData ( 3),  -- optional parameters
    requestedMonitorMediaClassImage ( 4),  -- optional parameters
    requestedMonitorMediaClassVoice ( 5),  -- optional parameters
    privateData          ( 6),  -- optional parameters
    actualRouteingMediaClassInAck ( 7),  -- optional parameters
    privateDataInAck      ( 8),  -- optional parameters
    allRouteingDevices    ( 9)}  -- misc characteristics

RouteRegisterAbort ::= BIT STRING
{
    privateData          ( 0)}  -- optional parameters

RouteRegisterCancel ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck      ( 1)}  -- optional parameters

ReRoute ::= BIT STRING
{
    replyTimeout          ( 1),  -- optional parameters
    correlatorData        ( 2),  -- optional parameters
    privateData           ( 3)}  -- optional parameters

RouteEnd ::= BIT STRING
{
    errorValue            ( 1),  -- optional parameters
    correlatorData        ( 2),  -- optional parameters
```

```
privateData          ( 3),  -- optional parameters
supportsSending      ( 4),  -- misc characteristics
supportsReceiving    ( 5)}  -- misc characteristics

RouteReject ::= BIT STRING
{
    rejectCauseBusyOverflow      ( 0),  -- optional parameters
    rejectCauseQueueTimeOverflow ( 1),  -- optional parameters
    rejectCauseCapacityOverflow  ( 2),  -- optional parameters
    rejectCauseCalendarOverflow  ( 3),  -- optional parameters
    rejectCauseUnknownOverflow   ( 4),  -- optional parameters
    correlatorData               ( 5),  -- optional parameters
    privateData                  ( 6)}  -- optional parameters

RouteRequest ::= BIT STRING
{
    callingDevice          ( 0),  -- optional parameters
    calledDevice           ( 1),  -- optional parameters
    routeSelAlgorithmACD   ( 2),  -- optional parameters
    routeSelAlgorithmEmergency ( 3),  -- optional parameters
    routeSelAlgorithmLeastCost ( 4),  -- optional parameters
    routeSelAlgorithmNormal ( 5),  -- optional parameters
    routeSelAlgorithmUserDefined ( 6),  -- optional parameters
    priority               ( 7),  -- optional parameters
    replyTimeout           ( 8),  -- optional parameters
    correlatorData         ( 9),  -- optional parameters
    mediaCallCharacteristics (10),  -- optional parameters
    callCharacteristics     (11),  -- optional parameters
    routedCallInfo          (12),  -- optional parameters
    privateData             (13),  -- optional parameters
    nonCallRelatedRouteing  (14)}  -- misc characteristics

RouteSelect ::= BIT STRING
{
    remainRetriesNoListAvailable ( 0),  -- optional parameters
    remainRetriesNoCountAvailable ( 1),  -- optional parameters
    remainRetriesRetryCount      ( 2),  -- optional parameters
    routeUsed                    ( 3),  -- optional parameters
    correlatorData               ( 4),  -- optional parameters
    privateData                  ( 5)}  -- optional parameters

RouteUsed ::= BIT STRING
{
    callingDevice          ( 0),  -- optional parameters
    domain                ( 1),  -- optional parameters
    correlatorData         ( 2),  -- optional parameters
    privateData            ( 3)}  -- optional parameters

-- 12.4.12
PhysDevServList ::= SEQUENCE
{
    buttonPress          [ 0] IMPLICIT ButtonPress          OPTIONAL,
    getAuditoryApparatusInfo [ 1] IMPLICIT GetAuditoryApparatusInfo OPTIONAL,
    getButtonInformation [ 2] IMPLICIT GetButtonInformation  OPTIONAL,
    getDisplay           [ 3] IMPLICIT GetDisplay            OPTIONAL,
    getHookSwitchStatus  [ 4] IMPLICIT GetHookSwitchStatus   OPTIONAL,
    getLampInfo          [ 5] IMPLICIT GetLampInfo            OPTIONAL,
    getLampMode          [ 6] IMPLICIT GetLampMode            OPTIONAL,
    getMessageWaitingIndicator [ 7] IMPLICIT GetMessageWaitingIndicator OPTIONAL,
    getMicrophoneGain    [ 8] IMPLICIT GetMicrophoneGain     OPTIONAL,
    getMicrophoneMute    [ 9] IMPLICIT GetMicrophoneMute     OPTIONAL,
    getRingerStatus      [10] IMPLICIT GetRingerStatus       OPTIONAL,
    getSpeakerMute       [11] IMPLICIT GetSpeakerMute        OPTIONAL,
    getSpeakerVolume     [12] IMPLICIT GetSpeakerVolume      OPTIONAL,
    setButtonInformation [13] IMPLICIT SetButtonInformation  OPTIONAL,
    setDisplay           [14] IMPLICIT SetDisplay            OPTIONAL,
    setHookSwitchStatus  [15] IMPLICIT SetHookSwitchStatus   OPTIONAL,
    setLampMode          [16] IMPLICIT SetLampMode            OPTIONAL,
    setMessageWaitingIndicator [17] IMPLICIT SetMessageWaitingIndicator OPTIONAL,
    setMicrophoneGain    [18] IMPLICIT SetMicrophoneGain     OPTIONAL,
    setMicrophoneMute    [19] IMPLICIT SetMicrophoneMute     OPTIONAL,
    setRingerStatus      [20] IMPLICIT SetRingerStatus       OPTIONAL,
    setSpeakerMute       [21] IMPLICIT SetSpeakerMute        OPTIONAL,
```

```
setSpeakerVolume          [22] IMPLICIT SetSpeakerVolume          OPTIONAL}

ButtonPress ::= BIT STRING
{
    privateData              ( 0),  -- optional parameters
    privateDataInAck         ( 1),  -- optional parameters
    ackModelMultiStep        ( 2)}  -- misc characteristics

GetAuditoryApparatusInfo ::= BIT STRING
{
    auditoryApparatus        ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    auditoryApparatusTypeSpeakerphone ( 2),  -- optional parameters
    auditoryApparatusTypeHandset   ( 3),  -- optional parameters
    auditoryApparatusTypeHeadset   ( 4),  -- optional parameters
    auditoryApparatusTypeSpeakerOnlyPhone ( 5),  -- optional parameters
    auditoryApparatusTypeeothers   ( 6),  -- optional parameters
    speakerPresent            ( 7),  -- optional parameters
    speakerVolumeSettable      ( 8),  -- optional parameters
    speakerVolumeReadable      ( 9),  -- optional parameters
    speakerMuteSettable        (10),  -- optional parameters
    speakerMuteReadable        (11),  -- optional parameters
    microphonePresent          (12),  -- optional parameters
    microphoneGainSettable     (13),  -- optional parameters
    microphoneGainReadable     (14),  -- optional parameters
    microphoneMuteSettable     (15),  -- optional parameters
    microphoneMuteReadable     (16),  -- optional parameters
    hookswitchSettable         (17),  -- optional parameters
    hookswitchOnHook           (18),  -- optional parameters
    privateDataInAck           (19)}  -- optional parameters

GetButtonInformation ::= BIT STRING
{
    button                    ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    buttonLabelInAck          ( 2),  -- optional parameters
    buttonLabelSettableInAck  ( 3),  -- optional parameters
    buttonFunctionInAck       ( 4),  -- optional parameters
    buttonAssociatedNumberInAck ( 5),  -- optional parameters
    buttonAssociatedNumberSettableInAck ( 6),  -- optional parameters
    listOfLampsInAck          ( 7),  -- optional parameters
    privateDataInAck           ( 8)}  -- optional parameters

GetDisplay ::= BIT STRING
{
    displayID                 ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    characterSetASCII          ( 2),  -- optional parameters
    characterSetUnicode        ( 3),  -- optional parameters
    characterSetProprietary    ( 4),  -- optional parameters
    privateDataInAck           ( 5)}  -- optional parameters

GetHookSwitchStatus ::= BIT STRING
{
    hookSwitch                ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    privateDataInAck          ( 2)}  -- optional parameters

GetLampInfo ::= BIT STRING
{
    lamp                      ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    lampLabelInAck           ( 2),  -- optional parameters
    buttonInAck              ( 3),  -- optional parameters
    lampColorInAck           ( 4),  -- optional parameters
    privateDataInAck          ( 5)}  -- optional parameters

GetLampMode ::= BIT STRING
{
    lamp                      ( 0),  -- optional parameters
    privateData              ( 1),  -- optional parameters
    lampModeBrokenFlutterInAck ( 2),  -- optional parameter
    lampModeFlutterInAck      ( 3),  -- optional parameter
    lampModeOffInAck          ( 4),  -- optional parameter
    lampModeSteadyInAck       ( 5),  -- optional parameter
```



```
    lampModeWinkInAck          ( 6),  -- optional parameter
    lampBrightnessNormal      ( 7),  -- optional parameter
    lampBrightnessDim         ( 8),  -- optional parameter
    lampBrightnessBright      ( 9),  -- optional parameter
    lampColorInAck            (10),  -- optional parameters
    buttonInAck                (11),  -- optional parameters
    privateDataInAck          (12)}  -- optional parameters

GetMessageWaitingIndicator ::= BIT STRING
{
    privateData          ( 0),  -- optional parameter
    deviceForMsgInAck    ( 1),  -- optional parameter
    lampIsPresentInAck   ( 2),  -- optional parameter
    privateDataInAck     ( 3)}  -- optional parameters

GetMicrophoneGain ::= BIT STRING
{
    auditoryApparatus    ( 0),  -- optional parameters
    privateData          ( 1),  -- optional parameters
    micGainAbsInAck      ( 2),  -- optional parameters
    privateDataInAck     ( 3)}  -- optional parameters

GetMicrophoneMute ::= BIT STRING
{
    auditoryApparatus    ( 0),  -- optional parameters
    privateData          ( 1),  -- optional parameters
    privateDataInAck     ( 2)}  -- optional parameters

GetRingerStatus ::= BIT STRING
{
    ringer               ( 0),  -- optional parameters
    privateData          ( 1),  -- optional parameters
    ringCountInAck       ( 2),  -- optional parameters
    ringPatternInAck     ( 3),  -- optional parameters
    ringVolumeInAck      ( 4),  -- optional parameters
    ringVolumeAbsInAck   ( 5),  -- optional parameters
    privateDataInAck     ( 6)}  -- optional parameters

GetSpeakerMute ::= BIT STRING
{
    auditoryApparatus    ( 0),  -- optional parameters
    privateDataInAck     ( 1),  -- optional parameters
    privateData          ( 2)}  -- optional parameters

GetSpeakerVolume ::= BIT STRING
{
    auditoryApparatus    ( 0),  -- optional parameters
    privateData          ( 1),  -- optional parameters
    speakerVolAbsInAck   ( 2),  -- optional parameters
    privateDataInAck     ( 3)}  -- optional parameters

SetButtonInformation ::= BIT STRING
{
    buttonLabel          ( 0),  -- optional parameters
    buttonAssociatedNumber ( 1),  -- optional parameters
    privateData          ( 2),  -- optional parameters
    privateDataInAck     ( 3),  -- optional parameters
    ackModelMultiStep    ( 4)}  -- misc characteristics

SetDisplay ::= BIT STRING
{
    physBaseRowNumber    ( 0),  -- optional parameters
    physColumnRowNumber  ( 1),  -- optional parameters
    offset               ( 2),  -- optional parameters
    privateData          ( 3),  -- optional parameters
    privateDataInAck     ( 4),  -- optional parameters
    supportsModifyingPosition ( 5),  -- misc characteristics
    ackModelMultiStep    ( 6)}  -- misc characteristics

SetHookSwitchStatus ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    ackModelMultiStep    ( 1)}  -- misc characteristics

SetLampMode ::= BIT STRING
{
    lampModeBrokenFlutter ( 0),  -- optional parameter
    lampModeFlutter       ( 1),  -- optional parameter
```

lampModeOff	(2),	-- optional parameter
lampModeSteady	(3),	-- optional parameter
lampModeWink	(4),	-- optional parameter
lampBrightnessNormal	(5),	-- optional parameter
lampBrightnessDim	(6),	-- optional parameter
lampBrightnessBright	(7),	-- optional parameter
lampColorNoColor	(8),	-- optional parameter
lampColorRed	(9),	-- optional parameter
lampColorYellow	(10),	-- optional parameter
lampColorGreen	(11),	-- optional parameter
lampColorBlue	(12),	-- optional parameter
lampColorReserved	(13),	-- optional parameter
lampColorSf0	(14),	-- optional parameters
lampColorSf1	(15),	-- optional parameters
lampColorSf2	(16),	-- optional parameters
lampColorSf3	(17),	-- optional parameters
lampColorSf4	(18),	-- optional parameters
lampColorSf5	(19),	-- optional parameters
lampColorSf6	(20),	-- optional parameters
lampColorSf7	(21),	-- optional parameters
lampColorSf8	(22),	-- optional parameters
lampColorSf9	(23),	-- optional parameters
lampColorSf10	(24),	-- optional parameters
lampColorSf11	(25),	-- optional parameters
lampColorSf12	(26),	-- optional parameters
lampColorSf13	(27),	-- optional parameters
lampColorSf14	(28),	-- optional parameters
lampColorSf15	(29),	-- optional parameters
lampColorSf16	(30),	-- optional parameters
lampColorSf17	(31),	-- optional parameters
lampColorSf18	(32),	-- optional parameters
lampColorSf19	(33),	-- optional parameters
lampColorSf20	(34),	-- optional parameters
lampColorSf21	(35),	-- optional parameters
lampColorSf22	(36),	-- optional parameters
lampColorSf23	(37),	-- optional parameters
lampColorSf24	(38),	-- optional parameters
lampColorSf25	(39),	-- optional parameters
lampColorSf26	(40),	-- optional parameters
lampColorSf27	(41),	-- optional parameters
lampColorSf28	(42),	-- optional parameters
lampColorSf29	(43),	-- optional parameters
lampColorSf30	(44),	-- optional parameters
lampColorSf31	(45),	-- optional parameters
lampColorSf32	(46),	-- optional parameters
lampColorSf33	(47),	-- optional parameters
lampColorSf34	(48),	-- optional parameters
lampColorSf35	(49),	-- optional parameters
lampColorSf36	(50),	-- optional parameters
lampColorSf37	(51),	-- optional parameters
lampColorSf38	(52),	-- optional parameters
lampColorSf39	(53),	-- optional parameters
lampColorSf40	(54),	-- optional parameters
lampColorSf41	(55),	-- optional parameters
lampColorSf42	(56),	-- optional parameters
lampColorSf43	(57),	-- optional parameters
lampColorSf44	(58),	-- optional parameters
lampColorSf45	(59),	-- optional parameters
lampColorSf46	(60),	-- optional parameters
lampColorSf47	(61),	-- optional parameters
lampColorSf48	(62),	-- optional parameters
lampColorSf49	(63),	-- optional parameters
lampColorSf50	(64),	-- optional parameters
lampColorSf51	(65),	-- optional parameters
lampColorSf52	(66),	-- optional parameters
lampColorSf53	(67),	-- optional parameters
lampColorSf54	(68),	-- optional parameters
lampColorSf55	(69),	-- optional parameters

```
lampColorSf56          (70),    -- optional parameters
lampColorSf57          (71),    -- optional parameters
lampColorSf58          (72),    -- optional parameters
lampColorSf59          (73),    -- optional parameters
lampColorSf60          (74),    -- optional parameters
lampColorSf61          (75),    -- optional parameters
lampColorSf62          (76),    -- optional parameters
lampColorSf63          (77),    -- optional parameters
lampColorSf64          (78),    -- optional parameters
lampColorSf65          (79),    -- optional parameters
lampColorSf66          (80),    -- optional parameters
lampColorSf67          (81),    -- optional parameters
lampColorSf68          (82),    -- optional parameters
lampColorSf69          (83),    -- optional parameters
lampColorSf70          (84),    -- optional parameters
lampColorSf71          (85),    -- optional parameters
lampColorSf72          (86),    -- optional parameters
lampColorSf73          (87),    -- optional parameters
lampColorSf74          (88),    -- optional parameters
lampColorSf75          (89),    -- optional parameters
lampColorSf76          (90),    -- optional parameters
lampColorSf77          (91),    -- optional parameters
lampColorSf78          (92),    -- optional parameters
lampColorSf79          (93),    -- optional parameters
lampColorSf80          (94),    -- optional parameters
lampColorSf81          (95),    -- optional parameters
lampColorSf82          (96),    -- optional parameters
lampColorSf83          (97),    -- optional parameters
lampColorSf84          (98),    -- optional parameters
lampColorSf85          (99),    -- optional parameters
lampColorSf86          (100),   -- optional parameters
lampColorSf87          (101),   -- optional parameters
lampColorSf88          (102),   -- optional parameters
lampColorSf89          (103),   -- optional parameters
lampColorSf90          (104),   -- optional parameters
lampColorSf91          (105),   -- optional parameters
lampColorSf92          (106),   -- optional parameters
lampColorSf93          (107),   -- optional parameters
lampColorSf94          (108),   -- optional parameters
lampColorSf95          (109),   -- optional parameters
lampColorSf96          (110),   -- optional parameters
lampColorSf97          (111),   -- optional parameters
lampColorSf98          (112),   -- optional parameters
lampColorSf99          (113),   -- optional parameters
lampColorSf100         (114),   -- optional parameters
privateData            (115),   -- optional parameters
privateDataInAck       (116),   -- optional parameters
ackModelMultiStep      (117)}   -- misc characteristics

SetMessageWaitingIndicator ::= BIT STRING
{
    privateData            ( 0),   -- optional parameters
    privateDataInAck       ( 1),   -- optional parameters
    ackModelMultiStep      ( 2)}   -- misc characteristics

SetMicrophoneGain ::= BIT STRING
{
    microphoneGainAbs      (0),    -- optional parameters
    microphoneGainInc      (1),    -- optional parameters
    privateData            (2),    -- optional parameters
    privateDataInAck       (3),    -- optional parameters
    ackModelMultiStep      (4)}   -- misc characteristics

SetMicrophoneMute ::= BIT STRING
{
    privateData            ( 0),   -- optional parameters
    privateDataInAck       ( 1),   -- optional parameters
    ackModelMultiStep      ( 2)}   -- misc characteristics

SetRingerStatus ::= BIT STRING
{
    ringerModeRinging      ( 0),   -- optional parameters
```

```

    ringerModeNotRinging      ( 1),  -- optional parameters
    ringVolumeAbs             ( 2),  -- optional parameters
    ringVolumeInc             ( 3),  -- optional parameters
    privateData               ( 4),  -- optional parameters
    privateDataInAck          ( 5),  -- optional parameters
    ackModelMultiStep         ( 6)}  -- misc characteristics

SetSpeakerMute ::= BIT STRING
{
    privateData               ( 0),  -- optional parameters
    privateDataInAck          ( 1),  -- optional parameters
    ackModelMultiStep         ( 2)}  -- misc characteristics

SetSpeakerVolume ::= BIT STRING
{
    speakerVolumeAbs          ( 0),  -- optional parameters
    speakerVolumeInc          ( 1),  -- optional parameters
    privateData               ( 2),  -- optional parameters
    privateDataInAck          ( 3),  -- optional parameters
    ackModelMultiStep         ( 4),  -- misc characteristics
    resettedAfterCall         ( 5),  -- misc characteristics
    notSettableWhileActive    ( 6)}  -- misc characteristics

-- 12.4.13
PhysDevEvsList ::= SEQUENCE
{
    buttonInformation          [0] IMPLICIT ButtonInformation      OPTIONAL,
    buttonPress                [1] IMPLICIT ButtonPressEvent      OPTIONAL,
    displayUpdated             [2] IMPLICIT DisplayUpdated        OPTIONAL,
    hookswitch                 [3] IMPLICIT Hookswitch            OPTIONAL,
    lampMode                   [4] IMPLICIT LampMode              OPTIONAL,
    messageWaiting             [5] IMPLICIT MessageWaiting        OPTIONAL,
    microphoneGain             [6] IMPLICIT MicrophoneGain        OPTIONAL,
    microphoneMute             [7] IMPLICIT MicrophoneMute        OPTIONAL,
    ringerStatus               [8] IMPLICIT RingerStatus          OPTIONAL,
    speakerMute                [9] IMPLICIT SpeakerMute           OPTIONAL,
    speakerVolume              [10] IMPLICIT SpeakerVolume        OPTIONAL}

ButtonInformation ::= BIT STRING
{
    buttonLabel                ( 0),  -- optional parameters
    buttonAssociatedNumber      ( 1),  -- optional parameters
    buttonPressIndicator        ( 2),  -- optional parameters
    privateData                ( 3)}  -- optional parameters

ButtonPressEvent ::= BIT STRING
{
    buttonLabel                ( 0),  -- optional parameters
    buttonAssociatedNumber      ( 1),  -- optional parameters
    privateData                ( 2)}  -- optional parameters

DisplayUpdated ::= BIT STRING
{
    characterSetASCII           ( 0),  -- optional parameters
    characterSetUnicode         ( 1),  -- optional parameters
    characterSetProprietary     ( 2),  -- optional parameters
    privateData                ( 3)}  -- optional parameters

Hookswitch ::= BIT STRING
{
    privateData                ( 0)}  -- optional parameters

LampMode ::= BIT STRING
{
    lampModeBrokenFlutter       ( 0),  -- optional parameter
    lampModeFlutter             ( 1),  -- optional parameter
    lampModeOff                 ( 2),  -- optional parameter
    lampModeSteady              ( 3),  -- optional parameter
    lampModeWink                ( 4),  -- optional parameter
    lampBrightnessNormal        ( 5),  -- optional parameter
    lampBrightnessDim           ( 6),  -- optional parameter
    lampBrightnessBright        ( 7),  -- optional parameter
    lampColorNoColor            ( 8),  -- optional parameter
    lampColorRed                ( 9),  -- optional parameter
    lampColorYellow             (10),  -- optional parameter
    lampColorGreen              (11),  -- optional parameter
}
```

lampColorBlue	(12),	-- optional parameter
lampColorReserved	(13),	-- optional parameter
lampColorSf0	(14),	-- optional parameters
lampColorSf1	(15),	-- optional parameters
lampColorSf2	(16),	-- optional parameters
lampColorSf3	(17),	-- optional parameters
lampColorSf4	(18),	-- optional parameters
lampColorSf5	(19),	-- optional parameters
lampColorSf6	(20),	-- optional parameters
lampColorSf7	(21),	-- optional parameters
lampColorSf8	(22),	-- optional parameters
lampColorSf9	(23),	-- optional parameters
lampColorSf10	(24),	-- optional parameters
lampColorSf11	(25),	-- optional parameters
lampColorSf12	(26),	-- optional parameters
lampColorSf13	(27),	-- optional parameters
lampColorSf14	(28),	-- optional parameters
lampColorSf15	(29),	-- optional parameters
lampColorSf16	(30),	-- optional parameters
lampColorSf17	(31),	-- optional parameters
lampColorSf18	(32),	-- optional parameters
lampColorSf19	(33),	-- optional parameters
lampColorSf20	(34),	-- optional parameters
lampColorSf21	(35),	-- optional parameters
lampColorSf22	(36),	-- optional parameters
lampColorSf23	(37),	-- optional parameters
lampColorSf24	(38),	-- optional parameters
lampColorSf25	(39),	-- optional parameters
lampColorSf26	(40),	-- optional parameters
lampColorSf27	(41),	-- optional parameters
lampColorSf28	(42),	-- optional parameters
lampColorSf29	(43),	-- optional parameters
lampColorSf30	(44),	-- optional parameters
lampColorSf31	(45),	-- optional parameters
lampColorSf32	(46),	-- optional parameters
lampColorSf33	(47),	-- optional parameters
lampColorSf34	(48),	-- optional parameters
lampColorSf35	(49),	-- optional parameters
lampColorSf36	(50),	-- optional parameters
lampColorSf37	(51),	-- optional parameters
lampColorSf38	(52),	-- optional parameters
lampColorSf39	(53),	-- optional parameters
lampColorSf40	(54),	-- optional parameters
lampColorSf41	(55),	-- optional parameters
lampColorSf42	(56),	-- optional parameters
lampColorSf43	(57),	-- optional parameters
lampColorSf44	(58),	-- optional parameters
lampColorSf45	(59),	-- optional parameters
lampColorSf46	(60),	-- optional parameters
lampColorSf47	(61),	-- optional parameters
lampColorSf48	(62),	-- optional parameters
lampColorSf49	(63),	-- optional parameters
lampColorSf50	(64),	-- optional parameters
lampColorSf51	(65),	-- optional parameters
lampColorSf52	(66),	-- optional parameters
lampColorSf53	(67),	-- optional parameters
lampColorSf54	(68),	-- optional parameters
lampColorSf55	(69),	-- optional parameters
lampColorSf56	(70),	-- optional parameters
lampColorSf57	(71),	-- optional parameters
lampColorSf58	(72),	-- optional parameters
lampColorSf59	(73),	-- optional parameters
lampColorSf60	(74),	-- optional parameters
lampColorSf61	(75),	-- optional parameters
lampColorSf62	(76),	-- optional parameters
lampColorSf63	(77),	-- optional parameters
lampColorSf64	(78),	-- optional parameters
lampColorSf65	(79),	-- optional parameters

```
lampColorSf66      (80),  -- optional parameters
lampColorSf67      (81),  -- optional parameters
lampColorSf68      (82),  -- optional parameters
lampColorSf69      (83),  -- optional parameters
lampColorSf70      (84),  -- optional parameters
lampColorSf71      (85),  -- optional parameters
lampColorSf72      (86),  -- optional parameters
lampColorSf73      (87),  -- optional parameters
lampColorSf74      (88),  -- optional parameters
lampColorSf75      (89),  -- optional parameters
lampColorSf76      (90),  -- optional parameters
lampColorSf77      (91),  -- optional parameters
lampColorSf78      (92),  -- optional parameters
lampColorSf79      (93),  -- optional parameters
lampColorSf80      (94),  -- optional parameters
lampColorSf81      (95),  -- optional parameters
lampColorSf82      (96),  -- optional parameters
lampColorSf83      (97),  -- optional parameters
lampColorSf84      (98),  -- optional parameters
lampColorSf85      (99),  -- optional parameters
lampColorSf86      (100), -- optional parameters
lampColorSf87      (101), -- optional parameters
lampColorSf88      (102), -- optional parameters
lampColorSf89      (103), -- optional parameters
lampColorSf90      (104), -- optional parameters
lampColorSf91      (105), -- optional parameters
lampColorSf92      (106), -- optional parameters
lampColorSf93      (107), -- optional parameters
lampColorSf94      (108), -- optional parameters
lampColorSf95      (109), -- optional parameters
lampColorSf96      (110), -- optional parameters
lampColorSf97      (111), -- optional parameters
lampColorSf98      (112), -- optional parameters
lampColorSf99      (113), -- optional parameters
lampColorSf100     (114), -- optional parameters
privateData        (115)} -- optional parameters

MessageWaiting ::= BIT STRING
{
    deviceForMsg      ( 0),  -- optional parameters
    privateData       ( 1)}  -- optional parameters

MicrophoneGain ::= BIT STRING
{
    microphoneGainAbs ( 0),  -- optional parameters
    microphoneGainInc ( 1),  -- optional parameters
    privateData       ( 2)}  -- optional parameters

MicrophoneMute ::= BIT STRING
{
    privateData       ( 0)}  -- optional parameters

RingerStatus ::= BIT STRING
{
    ringerModeRinging ( 0),  -- optional parameters
    ringerModeNotRinging ( 1), -- optional parameters
    ringCount         ( 2),  -- optional parameters
    ringPattern        ( 3),  -- optional parameters
    ringVolumeAbs      ( 4),  -- optional parameters
    ringVolumeInc      ( 5),  -- optional parameters
    privateData        ( 6)}  -- optional parameters

SpeakerMute ::= BIT STRING
{
    privateData       ( 0)}  -- optional parameters

SpeakerVolume ::= BIT STRING
{
    speakerVolumeAbs  ( 0),  -- optional parameters
    speakerVolumeInc  ( 1),  -- optional parameters
    privateData        ( 2)}  -- optional parameters
```

```
LogicalServList ::= SEQUENCE
{
    callBackNonCallRel      [ 0] IMPLICIT CallBackNonCallRel      OPTIONAL,
    callBackMsgNonCallRel   [ 1] IMPLICIT CallBackMsgNonCallRel   OPTIONAL,
    cancelCallBack          [ 2] IMPLICIT CancelCallBack         OPTIONAL,
    cancelCallBackMsg       [ 3] IMPLICIT CancelCallBackMsg      OPTIONAL,
    getAgentState           [ 4] IMPLICIT GetAgentState          OPTIONAL,
    getAutoAnswer           [ 5] IMPLICIT GetAutoAnswer          OPTIONAL,
    getAutoWorkMode         [ 6] IMPLICIT GetAutoWorkMode        OPTIONAL,
    getCallerIDStatus       [ 7] IMPLICIT GetCallerIDStatus      OPTIONAL,
    getDoNotDisturb         [ 8] IMPLICIT GetDoNotDisturb        OPTIONAL,
    getForwarding           [ 9] IMPLICIT GetForwarding          OPTIONAL,
    getLastNumberDialed     [10] IMPLICIT GetLastNumberDialed     OPTIONAL,
    getRouteingMode         [11] IMPLICIT GetRouteingMode        OPTIONAL,
    setAgentState           [12] IMPLICIT SetAgentStatus         OPTIONAL,
    setAutoAnswer           [13] IMPLICIT SetAutoAnswer          OPTIONAL,
    setAutoWorkMode         [14] IMPLICIT SetAutoWorkMode        OPTIONAL,
    setCallerIDStatus       [15] IMPLICIT SetCallerIDStatus      OPTIONAL,
    setDoNotDisturb         [16] IMPLICIT SetDoNotDisturb        OPTIONAL,
    setForwarding           [17] IMPLICIT SetForwarding          OPTIONAL,
    setRouteingMode         [18] IMPLICIT SetRouteingMode        OPTIONAL}

CallBackNonCallRel ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    privateDataInAck         ( 1), -- optional parameters
    additionalReqForbidden   ( 2), -- optional parameters
    ackModelMultiStep        ( 3)} -- misc characteristics

CallBackMsgNonCallRel ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    privateDataInAck         ( 1), -- optional parameters
    additionalReqForbidden   ( 2), -- optional parameters
    ackModelMultiStep        ( 3)} -- misc characteristics

CancelCallBack ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    privateDataInAck         ( 1), -- optional parameters
    ackModelMultiStep        ( 2), -- misc characteristics
    supportsClearing         ( 3)} -- misc characteristics

CancelCallBackMsg ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    privateDataInAck         ( 1), -- optional parameters
    ackModelMultiStep        ( 2), -- misc characteristics
    supportsClearing         ( 3)} -- misc characteristics

GetAgentState ::= BIT STRING
{
    acdGroup                 ( 0), -- optional parameters
    privateData              ( 1), -- optional parameters
    agentStateListAgentIDInAck ( 2), -- optional parameters
    agentGroupInAck          ( 3), -- optional parameters
    pendingAgentStateInAck    ( 4), -- optional parameters
    agentStateConditionForcedPauseInAck ( 5), -- optional parameters
    agentStateConditionPauseInAck ( 6), -- optional parameters
    privateDataInAck         ( 7)} -- optional parameters

GetAutoAnswer ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    numberOfRingsInAck       ( 1), -- optional parameters
    privateDataInAck         ( 2)} -- optional parameters

GetAutoWorkMode ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    autoWorkIntervalInAck    ( 1), -- optional parameters
    privateDataInAck         ( 2)} -- optional parameters

GetCallerIDStatus ::= BIT STRING
{
    privateData              ( 0), -- optional parameters
    privateDataInAck         ( 1)} -- optional parameters
```

```
GetDoNotDisturb ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    callOriginParameterInAck    ( 1),    -- optional parameters
    callOriginInternInAck       ( 2),    -- optional parameters
    callOriginExternInAck       ( 3),    -- optional parameters
    callingDeviceListInAck      ( 4),    -- optional parameters
    privateDataInAck            ( 5)}    -- optional parameters

GetForwarding ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    forwardListInAck           ( 1),    -- optional parameters
    forwardListImmediateInAck   ( 2),    -- optional parameters
    forwardListBusyInAck       ( 3),    -- optional parameters
    forwardListDNDInAck        ( 4),    -- optional parameters
    forwardListNoAnsInAck       ( 5),    -- optional parameters
    forwardListBusyIntInAck     ( 6),    -- optional parameters
    forwardListBusyExtInAck     ( 7),    -- optional parameters
    forwardListDNDIntInAck      ( 8),    -- optional parameters
    forwardListDNDExtInAck      ( 9),    -- optional parameters
    forwardListNoAnsIntInAck    (10),    -- optional parameters
    forwardListNoAnsExtInAck    (11),    -- optional parameters
    forwardListImmIntInAck      (12),    -- optional parameters
    forwardListImmExtInAck      (13),    -- optional parameters
    forwardDNInAck              (14),    -- optional parameters
    forwardDefaultInAck         (15),    -- optional parameters
    forwardDefaultTypeAndDNInAck (16),    -- optional parameters
    forwardDefaultTypeInAck     (17),    -- optional parameters
    forwardDefaultDNInAck       (18),    -- optional parameters
    ringCountInAck              (19),    -- optional parameters
    privateDataInAck            (20)}    -- optional parameters

GetLastNumberDialed ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    privateDataInAck           ( 1)}    -- optional parameters

GetRouteingMode ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    privateDataInAck           ( 1)}    -- optional parameters

SetAgentStatus ::= BIT STRING
{
    requestedAgentStateLoggedOn ( 0),    -- optional parameters
    requestedAgentStateLoggedOff ( 1),    -- optional parameters
    requestedAgentStateNotReady ( 2),    -- optional parameters
    requestedAgentStateReady     ( 3),    -- optional parameters
    requestedAgentStateWorkingAfterCall ( 4), -- optional parameters
    agentID                      ( 5),    -- optional parameters
    password                     ( 6),    -- optional parameters
    group                        ( 7),    -- optional parameters
    privateData                  ( 8),    -- optional parameters
    pendingAgentStateWorkingAfterCallInAck ( 9), -- optional parameters
    pendingAgentStateNotReadyInAck (10),    -- optional parameters
    pendingAgentStateNullInAck   (11),    -- optional parameters
    privateDataInAck             (12),    -- optional parameters
    ackModelMultiStep            (13),    -- misc characteristics
    groupDeviceAllowedInReq      (14),    -- misc characteristics
    aCDDeviceAllowedInReq        (15),    -- misc characteristics
    delayTransitionIfBusy        (16),    -- misc characteristics
    delayTransitionIfWorkingAfterCall (17)} -- misc characteristics

SetAutoAnswer ::= BIT STRING
{
    numberOfRings                ( 0),    -- optional parameters
    privateData                  ( 1),    -- optional parameters
    privateDataInAck             ( 2),    -- optional parameters
    ackModelMultiStep            ( 3)}    -- misc characteristics

SetAutoWorkMode ::= BIT STRING
{
    autoWorkInterval             ( 0),    -- optional parameters
```



```
privateData                ( 1),  -- optional parameters
privateDataInAck           ( 2),  -- optional parameters
ackModelMultiStep          ( 3),  -- misc characteristics
groupDeviceAllowedInReq    ( 4),  -- misc characteristics
acdDeviceAllowedInReq      ( 5)}  -- misc characteristics

SetCallerIDStatus ::= BIT STRING
{
    privateData                ( 0),  -- optional parameters
    privateDataInAck           ( 1),  -- optional parameters
    ackModelMultiStep          ( 2)}  -- misc characteristics

SetDoNotDisturb ::= BIT STRING
{
    callOriginationInternal    ( 0),  -- optional parameters
    callOriginationExternal    ( 1),  -- optional parameters
    callingDeviceList          ( 2),  -- optional parameters
    privateData                ( 3),  -- optional parameters
    privateDataInAck           ( 4),  -- optional parameters
    ackModelMultiStep          ( 5)}  -- misc characteristics

SetForwarding ::= BIT STRING
{
    forwardingTypeBusy          ( 0),  -- optional parameters
    forwardingTypeBusyInt       ( 1),  -- optional parameters
    forwardingTypeBusyExt       ( 2),  -- optional parameters
    forwardingTypeDND           ( 3),  -- optional parameters
    forwardingTypeDNDInt        ( 4),  -- optional parameters
    forwardingTypeDNDExt        ( 5),  -- optional parameters
    forwardingTypeNoAns         ( 6),  -- optional parameters
    forwardingTypeNoAnsInt      ( 7),  -- optional parameters
    forwardingTypeNoAnsExt      ( 8),  -- optional parameters
    forwardingTypeImmediate     ( 9),  -- optional parameters
    forwardingTypeImmInt        (10),  -- optional parameters
    forwardingTypeImmExt        (11),  -- optional parameters
    forwardDN                   (12),  -- optional parameters
    ringCount                   (13),  -- optional parameters
    privateData                (14),  -- optional parameters
    privateDataInAck           (15),  -- optional parameters
    ackModelMultiStep          (16)}  -- misc characteristics

SetRouteingMode ::= BIT STRING
{
    privateData                ( 0),  -- optional parameters
    privateDataInAck           ( 1),  -- optional parameters
    ackModelMultiStep          ( 2)}  -- misc characteristics

-- 12.4.15
LogicalEvtsList ::= SEQUENCE
{
    agentBusy                  [0] IMPLICIT AgentBusy          OPTIONAL,
    agentLoggedOff              [1] IMPLICIT AgentLoggedOff     OPTIONAL,
    agentLoggedOn               [2] IMPLICIT AgentLoggedOn      OPTIONAL,
    agentNotReady               [3] IMPLICIT AgentNotReady      OPTIONAL,
    agentReady                  [4] IMPLICIT AgentReady         OPTIONAL,
    agentWorkingAfterCall       [5] IMPLICIT AgentWorkingAfterCall OPTIONAL,
    autoAnswer                  [6] IMPLICIT AutoAnswer        OPTIONAL,
    autoWorkMode                [7] IMPLICIT AutoWorkMode       OPTIONAL,
    callBack                    [8] IMPLICIT CallBackEvent     OPTIONAL,
    callBackMessage             [9] IMPLICIT CallBackMessageEvent OPTIONAL,
    callerIDStatus              [10] IMPLICIT CallerIDStatus    OPTIONAL,
    doNotDisturb                [11] IMPLICIT DoNotDisturb      OPTIONAL,
    forwarding                  [12] IMPLICIT Forwarding        OPTIONAL,
    routeingMode                [13] IMPLICIT RouteingMode      OPTIONAL}

AgentBusy ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    pendingAgentStateWorkingAfterCall ( 2),  -- optional parameters
    pendingAgentStateNotReady   ( 3),  -- optional parameters
    pendingAgentStateReady      ( 4),  -- optional parameters
    pendingAgentStateNull       ( 5),  -- optional parameters
```

```

    cause                                ( 6),    -- optional parameters
    privateData                          ( 7)}    -- optional parameters

AgentLoggedOff ::= BIT STRING
{
    agentID                             ( 0),    -- optional parameters
    acdGroup                             ( 1),    -- optional parameters
    agentPassword                         ( 2),    -- optional parameters
    cause                                ( 3),    -- optional parameters
    privateData                          ( 4)}    -- optional parameters

AgentLoggedOn ::= BIT STRING
{
    agentID                             ( 0),    -- optional parameters
    acdGroup                             ( 1),    -- optional parameters
    agentPassword                         ( 2),    -- optional parameters
    cause                                ( 3),    -- optional parameters
    privateData                          ( 4)}    -- optional parameters

AgentNotReady ::= BIT STRING
{
    agentID                             ( 0),    -- optional parameters
    acdGroup                             ( 1),    -- optional parameters
    cause                                ( 2),    -- optional parameters
    privateData                          ( 3)}    -- optional parameters

AgentReady ::= BIT STRING
{
    agentID                             ( 0),    -- optional parameters
    acdGroup                             ( 1),    -- optional parameters
    cause                                ( 2),    -- optional parameters
    privateData                          ( 3)}    -- optional parameters

AgentWorkingAfterCall ::= BIT STRING
{
    agentID                             ( 0),    -- optional parameters
    acdGroup                             ( 1),    -- optional parameters
    pendingAgentStateNotReady            ( 2),    -- optional parameters
    pendingAgentStateReady               ( 3),    -- optional parameters
    pendingAgentStateNull                ( 4),    -- optional parameters
    cause                                ( 5),    -- optional parameters
    privateData                          ( 6)}    -- optional parameters

AutoAnswer ::= BIT STRING
{
    numberOfRings                        ( 0),    -- optional parameters
    privateData                          ( 1)}    -- optional parameters

AutoWorkMode ::= BIT STRING
{
    privateData                          ( 0)}    -- optional parameters

CallBackEvent ::= BIT STRING
{
    privateData                          ( 0)}    -- optional parameters

CallBackMessageEvent ::= BIT STRING
{
    privateData                          ( 0)}    -- optional parameters

CallerIDStatus ::= BIT STRING
{
    privateData                          ( 0)}    -- optional parameters

DoNotDisturb ::= BIT STRING
{
    callOriginationParameter             ( 0),    -- optional parameters
    callOriginationInternal               ( 1),    -- optional parameters
    callOriginationExternal               ( 2),    -- optional parameters
    callingDeviceList                    ( 3),    -- optional parameters
    privateData                          ( 4)}    -- optional parameters

Forwarding ::= BIT STRING
{
    forwardingTypeBusy                   ( 0),
    forwardingTypeBusyInt                 ( 1),
    forwardingTypeBusyExt                 ( 2),
    forwardingTypeDND                     ( 3),
    forwardingTypeDNDInt                  ( 4),
    forwardingTypeDNDExt                  ( 5),
```

```
forwardingTypeNoAns      ( 6 ),
forwardingTypeNoAnsInt   ( 7 ),
forwardingTypeNoAnsExt   ( 8 ),
forwardingTypeImmediate ( 9 ),
forwardingTypeImmInt     (10 ),
forwardingTypeImmExt     (11 ),
forwardTo                (12 ),
forwardDefaultTypeAndDN  (13 ),
forwardDefaultType       (14 ),
forwardDefaultDN         (15 ),
ringCount                (16 ),
privateData              (17 )}

RouteingMode ::= BIT STRING
{
    privateData          ( 0 )} -- optional parameters

-- 12.4.16

DeviceMaintEvtsList ::= SEQUENCE
{
    backInService        [0] IMPLICIT BackInService    OPTIONAL,
    deviceCapsChanged     [1] IMPLICIT DeviceCapsChanged OPTIONAL,
    outOfService          [2] IMPLICIT OutOfService     OPTIONAL,

BackInService ::= BIT STRING
{
    cause                ( 0 ), -- optional parameters
    privateData          ( 1 )} -- optional parameters

DeviceCapsChanged ::= BIT STRING
{
    cause                ( 0 ), -- optional parameters
    privateData          ( 1 )} -- optional parameters

OutOfService ::= BIT STRING
{
    cause                ( 0 ), -- optional parameters
    privateData          ( 1 )} -- optional parameters

-- 12.4.17
IOServicesServList ::= SEQUENCE
{
    ioRegister           [ 0 ] IMPLICIT IoRegister      OPTIONAL,
    ioRegisterAbort      [ 1 ] IMPLICIT IoRegisterAbort  OPTIONAL,
    ioRegisterCancel     [ 2 ] IMPLICIT IoRegisterCancel  OPTIONAL,
    dataPathResumed      [ 3 ] IMPLICIT DataPathResumed  OPTIONAL,
    dataPathSuspended    [ 4 ] IMPLICIT DataPathSuspended OPTIONAL,
    fastData             [ 5 ] IMPLICIT FastData         OPTIONAL,
    resumeDataPath       [ 6 ] IMPLICIT ResumeDataPath   OPTIONAL,
    sendBroadcastData     [ 7 ] IMPLICIT SendBroadcastData OPTIONAL,
    sendData             [ 8 ] IMPLICIT SendData         OPTIONAL,
    sendMulticastData    [ 9 ] IMPLICIT SendMulticastData OPTIONAL,
    startDataPath        [10] IMPLICIT StartDataPath     OPTIONAL,
    stopDataPath         [11] IMPLICIT StopDataPath      OPTIONAL,
    suspendDataPath      [12] IMPLICIT SuspendDataPath   OPTIONAL,

IoRegister ::= BIT STRING
{
    ioDevice             ( 0 ), -- optional parameters
    privateData          ( 1 ), -- optional parameters
    privateDataInAck     ( 2 ), -- optional parameters
    allIODevices         ( 3 )} -- misc characteristics

IoRegisterAbort ::= BIT STRING
{
    privateData          ( 0 )} -- optional parameters

IoRegisterCancel ::= BIT STRING
{
    privateData          ( 0 ), -- optional parameters
    privateDataInAck     ( 1 )} -- optional parameters

DataPathResumed ::= BIT STRING
{
    privateData          ( 0 ), -- optional parameters
    privateDataInAck     ( 1 )} -- optional parameters
```

```
DataPathSuspended ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck      ( 1)}  -- optional parameters

FastData ::= BIT STRING
{
    objectDevice          ( 0),  -- optional parameters
    objectCall            ( 1),  -- optional parameters
    dataPathTypeText      ( 2),  -- optional parameters
    dataPathTypeVoice     ( 3),  -- optional parameters
    displayAttribPhyBaseRowNumber ( 4),  -- optional parameters
    displayAttribPhyBaseColumnNumber ( 5),  -- optional parameters
    displayAttribOffset   ( 6),  -- optional parameters
    privateData           ( 7),  -- optional parameters
    privateDataInAck      ( 8),  -- optional parameters
    supportsModifyingPosition ( 9)}  -- misc characteristics

ResumeDataPath ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck      ( 1),  -- optional parameters
    sendsDataPathResumed ( 2)}  -- misc characteristics

SendBroadcastData ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    dataPathTypeText     ( 1),  -- optional parameters
    dataPathTypeVoice    ( 2),  -- optional parameters
    displayAttribPhyBaseRowNumber ( 3),  -- optional parameters
    displayAttribPhyBaseColumnNumber ( 4),  -- optional parameters
    displayAttribOffset   ( 5),  -- optional parameters
    privateDataInAck      ( 6),  -- optional parameters
    supportsModifyingPosition ( 7)}  -- misc characteristics

SendData ::= BIT STRING
{
    displayAttribPhyBaseRowNumber ( 0),  -- optional parameters
    displayAttribPhyBaseColumnNumber ( 1),  -- optional parameters
    displayAttribOffset           ( 2),  -- optional parameters
    ioCauseTerminationCharReceived ( 3),  -- optional parameters
    ioCauseCharCountReached       ( 4),  -- optional parameters
    ioCauseTimeout                ( 5),  -- optional parameters
    ioCauseSfTerminated           ( 6),  -- optional parameters
    privateData                   ( 7),  -- optional parameters
    privateDataInAck              ( 8),  -- optional parameters
    supportsModifyingPosition     ( 9)}  -- misc characteristics

SendMulticastData ::= BIT STRING
{
    ioData          ( 0),  -- optional parameters
    displayAttribPhyBaseRowNumber ( 1),  -- optional parameters
    displayAttribPhyBaseColumnNumber ( 2),  -- optional parameters
    displayAttribOffset           ( 3),  -- optional parameters
    privateData                   ( 4),  -- optional parameters
    privateDataInAck              ( 5),  -- optional parameters
    supportsModifyingPosition     ( 6)}  -- misc characteristics

StartDataPath ::= BIT STRING
{
    objectDevice          ( 0),  -- optional parameters
    objectCall            ( 1),  -- optional parameters
    dataPathDirectionCfToObject ( 2),  -- optional parameters
    dataPathDirectionObjectToCf ( 3),  -- optional parameters
    dataPathDirectionBidirectional ( 4),  -- optional parameters
    dataPathTypeText      ( 5),  -- optional parameters
    dataPathTypeVoice     ( 6),  -- optional parameters
    numberOfCharsToCollect ( 7),  -- optional parameters
    terminationChar       ( 8),  -- optional parameters
    timeout               ( 9),  -- optional parameters
    privateData           (10),  -- optional parameters
    numberOfCharsToCollectInAck (11),  -- optional parameters
    terminationCharInAck  (12),  -- optional parameters
    timeoutInAck          (13),  -- optional parameters
    privateDataInAck      (14)}  -- optional parameters
```

```
StopDataPath ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

SuspendDataPath ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

-- 12.4.18

DataCollectionServList ::= SEQUENCE
{
    dataCollected        [ 0] IMPLICIT DataCollected        OPTIONAL,
    dataCollectionResumed [ 1] IMPLICIT DataCollectionResumed  OPTIONAL,
    dataCollectionSuspended [ 2] IMPLICIT DataCollectionSuspended  OPTIONAL,
    resumeDataCollection  [ 3] IMPLICIT ResumeDataCollection    OPTIONAL,
    startDataCollection   [ 4] IMPLICIT StartDataCollection     OPTIONAL,
    stopDataCollection    [ 5] IMPLICIT StopDataCollection      OPTIONAL,
    suspendDataCollection [ 6] IMPLICIT SuspendDataCollection   OPTIONAL}

DataCollected ::= BIT STRING
{
    digitsDuration          ( 0),  -- optional parameters
    digitsPauseDuration     ( 1),  -- optional parameters
    toneDetectedBeep        ( 2),  -- optional parameters
    toneDetectedBilling     ( 3),  -- optional parameters
    toneDetectedBusy        ( 4),  -- optional parameters
    toneDetectedCarrier     ( 5),  -- optional parameters
    toneDetectedConfirmation ( 6),  -- optional parameters
    toneDetectedDial        ( 7),  -- optional parameters
    toneDetectedFaxCNG      ( 8),  -- optional parameters
    toneDetectedHold        ( 9),  -- optional parameters
    toneDetectedHowler      (10),  -- optional parameters
    toneDetectedIntrusion   (11),  -- optional parameters
    toneDetectedModemCNG    (12),  -- optional parameters
    toneDetectedPark        (13),  -- optional parameters
    toneDetectedRecordWarning (14), -- optional parameters
    toneDetectedReorder     (15),  -- optional parameters
    toneDetectedRingback    (16),  -- optional parameters
    toneDetectedSilence     (17),  -- optional parameters
    toneDetectedSitVC       (18),  -- optional parameters
    toneDetectedSitIC       (19),  -- optional parameters
    toneDetectedSitRO       (20),  -- optional parameters
    toneDetectedSitNC       (21),  -- optional parameters
    toneDetectedSf0         (22),  -- optional parameters
    toneDetectedSf1         (23),  -- optional parameters
    toneDetectedSf2         (24),  -- optional parameters
    toneDetectedSf3         (25),  -- optional parameters
    toneDetectedSf4         (26),  -- optional parameters
    toneDetectedSf5         (27),  -- optional parameters
    toneDetectedSf6         (28),  -- optional parameters
    toneDetectedSf7         (29),  -- optional parameters
    toneDetectedSf8         (30),  -- optional parameters
    toneDetectedSf9         (31),  -- optional parameters
    toneDetectedSf10        (32),  -- optional parameters
    toneDetectedOther       (33),  -- optional parameters
    toneFrequency           (34),  -- optional parameters
    toneDuration            (35),  -- optional parameters
    tonePauseDuration       (36),
    connectionInfo          (37),  -- optional parameters
    dcollCauseFushCharReceived (38), -- optional parameters
    dcollCauseCharCountReached (39), -- optional parameters
    dcollCauseTimeout       (40),  -- optional parameters
    dcollCauseSFTerminated  (41),  -- optional parameters
    privateData             (42),  -- optional parameters
    privateDataInAck        (43)}  -- optional parameters

DataCollectionResumed ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
```

```
privateDataInAck      ( 1)}  -- optional parameters

DataCollectionSuspended ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

ResumeDataCollection ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

StartDataCollection ::= BIT STRING
{
    objectDevice      ( 0),  -- optional parameters
    objectCall        ( 1),  -- optional parameters
    dataCollectionTypeDigits ( 2),  -- optional parameters
    dataCollectionTypeTones ( 3),  -- optional parameters
    digitsReportingCriteriaNumChars ( 4),  -- optional parameters
    digitsReportingCriteriaFlushChar ( 5),  -- optional parameters
    digitsReportingCriteriaTimeout ( 6),  -- optional parameters
    privateData      ( 7),  -- optional parameters
    privateDataInAck ( 8)}  -- optional parameters

StopDataCollection ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

SuspendDataCollection ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

-- 12.4.19

VoiceUnitServList ::= SEQUENCE
{
    concatenateMsg      [ 0] IMPLICIT ConcatenateMsg  OPTIONAL,
    deleteMsg          [ 1] IMPLICIT DeleteMsg        OPTIONAL,
    playMsg             [ 2] IMPLICIT PlayMsg          OPTIONAL,
    queryVoiceAttrib    [ 3] IMPLICIT QueryVoiceAttrib OPTIONAL,
    recordMsg           [ 4] IMPLICIT RecordMsg        OPTIONAL,
    reposition          [ 5] IMPLICIT Reposition       OPTIONAL,
    resume              [ 6] IMPLICIT Resume           OPTIONAL,
    review              [ 7] IMPLICIT Review           OPTIONAL,
    setVoiceAttrib      [ 8] IMPLICIT SetVoiceAttrib   OPTIONAL,
    stop                [ 9] IMPLICIT Stop             OPTIONAL,
    suspend             [10] IMPLICIT Suspend          OPTIONAL,
    synthesizeMsg       [11] IMPLICIT SynthesizeMsg    OPTIONAL}

ConcatenateMsg ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

DeleteMsg ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1)}  -- optional parameters

PlayMsg ::= BIT STRING
{
    duration              ( 0),  -- optional parameters
    terminationParameter ( 1),  -- optional parameters
    terminationDurationExceeded ( 2),  -- optional parameters
    terminationDTMFDigitDetected ( 3),  -- optional parameters
    terminationEndOfSpeechDetected ( 4),  -- optional parameters
    terminationSpeech     ( 5),  -- optional parameters
    privateData          ( 6),  -- optional parameters
    privateDataInAck     ( 7),  -- optional parameters
    multipleMsgsSimultaneously ( 8)}  -- miscellaneous characteristics

QueryVoiceAttrib ::= BIT STRING
{
    attribToQueryEncodingAlgorithm ( 0),  -- optional parameters
    attribToQuerySamplingRate      ( 1),  -- optional parameters
    attribToQueryDuration          ( 2),  -- optional parameters
```

```

    attribToQueryFilename          ( 3),  -- optional parameters
    attribToQueryCurrentPosition   ( 4),  -- optional parameters
    attribToQueryCurrentSpeed      ( 5),  -- optional parameters
    attribToQueryCurrentVolume     ( 6),  -- optional parameters
    attribToQueryCurrentLevel      ( 7),  -- optional parameters
    attribToQueryCurrentState      ( 8),  -- optional parameters
    connection                     ( 9),  -- optional parameters
    duration                       (10),  -- optional parameters
    terminationParameter           (11),  -- optional parameters
    terminationDurationExceeded    (12),  -- optional parameters
    terminationDTMFDigitDetected   (13),  -- optional parameters
    terminationEndOfSpeechDetected (14),  -- optional parameters
    terminationSpeech              (15),  -- optional parameters
    privateData                    (16),  -- optional parameters
    attribInAckEncodingAlgorithmADPCM6K (17), -- optional parameters
    attribInAckEncodingAlgorithmADPCM8K (18), -- optional parameters
    attribInAckEncodingAlgorithmMuLawPCM6K (19), -- optional parameters
    attribInAckEncodingAlgorithmALawPCM6K (20), -- optional parameters
    attribInAckSamplingRate        (21),  -- optional parameters
    attribInAckDuration            (22),  -- optional parameters
    attribInAckFilename            (23),  -- optional parameters
    attribInAckCurrentPosition     (24),  -- optional parameters
    attribInAckCurrentSpeed        (25),  -- optional parameters
    attribInAckCurrentVolumeAbs    (26),  -- optional parameters
    attribInAckCurrentGain         (27),  -- optional parameters
    attribInAckCurrentState        (28),  -- optional parameters
    privateDataInAck               (29)}  -- optional parameters

RecordMsg ::= BIT STRING
{
    samplingRate          ( 0),  -- optional parameters
    encodingAlgorithmADPCM6K ( 1),  -- optional parameters
    encodingAlgorithmADPCM8K ( 2),  -- optional parameters
    encodingAlgorithmMuLawPCM6K ( 3),  -- optional parameters
    encodingAlgorithmALawPCM6K ( 4),  -- optional parameters
    maxDuration           ( 5),  -- optional parameters
    terminationParameter  ( 6),  -- optional parameters
    terminationDurationExceeded ( 7),  -- optional parameters
    terminationDTMFDigitDetected ( 8),  -- optional parameters
    terminationEndOfDataDetected ( 9),  -- optional parameters
    terminationSpeechDetected (10),  -- optional parameters
    privateData           (11),  -- optional parameters
    privateDataInAck      (12)}  -- optional parameters

Reposition ::= BIT STRING
{
    periodOfRepositionStartOfMsg ( 0),  -- optional parameters
    periodOfRepositionEndOfMsg   ( 1),  -- optional parameters
    periodOfRepositionRelativePointer ( 2),  -- optional parameters
    msgToReposition              ( 3),  -- optional parameters
    privateData                  ( 4),  -- optional parameters
    privateDataInAck             ( 5)}  -- optional parameters

Resume ::= BIT STRING
{
    msgToResume ( 0),  -- optional parameters
    duration    ( 1),  -- optional parameters
    privateData ( 2),  -- optional parameters
    privateDataInAck ( 3)}  -- optional parameters

Review ::= BIT STRING
{
    periodToResumeStartOfMsg ( 0),  -- optional parameters
    periodToResumeLengthOfReview ( 1),  -- optional parameters
    privateData              ( 2),  -- optional parameters
    privateDataInAck         ( 3)}  -- optional parameters

SetVoiceAttrib ::= BIT STRING
{
    currentSpeed ( 0),  -- optional parameters
    currentVolumeAbs ( 1),  -- optional parameters
    currentVolumeInc ( 2),  -- optional parameters
    periodToResumeStartOfMsg ( 3),  -- optional parameters

```

```
periodToResumeLengthOfReview      ( 4),  -- optional parameters
currentGain                        ( 5),  -- optional parameters
message                            ( 6),  -- optional parameters
privateData                        ( 7),  -- optional parameters
privateDataInAck                   ( 8)}  -- optional parameters

Stop ::= BIT STRING
{
    privateData                    ( 0),  -- optional parameters
    privateDataInAck               ( 1)}  -- optional parameters

Suspend ::= BIT STRING
{
    message                        ( 0),  -- optional parameters
    privateData                    ( 1),  -- optional parameters
    privateDataInAck               ( 2)}  -- optional parameters

SynthesizeMsg ::= BIT STRING
{
    genderMale                     ( 0),  -- optional parameters
    genderFemale                   ( 1),  -- optional parameters
    privateData                    ( 2),  -- optional parameters
    privateDataInAck               ( 3)}  -- optional parameters

-- 12.4.20

VoiceUnitEvsList ::= SEQUENCE
{
    play                           [ 0] IMPLICIT Play                OPTIONAL,
    record                         [ 1] IMPLICIT Record              OPTIONAL,
    review                         [ 2] IMPLICIT ReviewEvent          OPTIONAL,
    stop                           [ 3] IMPLICIT StopEvent            OPTIONAL,
    suspendPlay                    [ 4] IMPLICIT SuspendPlay          OPTIONAL,
    suspendRecord                  [ 5] IMPLICIT SuspendRecord        OPTIONAL,
    voiceAttribChanged             [ 6] IMPLICIT VoiceAttribChanged    OPTIONAL}

Play ::= BIT STRING
{
    length                         ( 0),  -- optional parameters
    currentPosition                ( 1),  -- optional parameters
    speed                          ( 2),  -- optional parameters
    cause                          ( 3),  -- optional parameters
    servicesPermitted              ( 4),  -- optional parameters
    privateData                    ( 5)}  -- optional parameters

Record ::= BIT STRING
{
    length                         ( 0),  -- optional parameters
    currentPosition                ( 1),  -- optional parameters
    speed                          ( 2),  -- optional parameters
    cause                          ( 3),  -- optional parameters
    servicesPermitted              ( 4),  -- optional parameters
    privateData                    ( 5)}  -- optional parameters

ReviewEvent ::= BIT STRING
{
    length                         ( 0),  -- optional parameters
    currentPosition                ( 1),  -- optional parameters
    cause                          ( 2),  -- optional parameters
    servicesPermitted              ( 3),  -- optional parameters
    privateData                    ( 4)}  -- optional parameters

StopEvent ::= BIT STRING
{
    length                         ( 0),  -- optional parameters
    currentPosition                ( 1),  -- optional parameters
    speed                          ( 2),  -- optional parameters
    cause                          ( 3),  -- optional parameters
    servicesPermitted              ( 4),  -- optional parameters
    privateData                    ( 5)}  -- optional parameters

SuspendPlay ::= BIT STRING
{
    length                         ( 0),  -- optional parameters
    currentPosition                ( 1),  -- optional parameters
    cause                          ( 2),  -- optional parameters
    servicesPermitted              ( 3),  -- optional parameters
```



```
privateData          ( 4)} -- optional parameters

SuspendRecord ::= BIT STRING
{
    length              ( 0), -- optional parameters
    currentPosition     ( 1), -- optional parameters
    cause               ( 2), -- optional parameters
    servicesPermitted   ( 3), -- optional parameters
    privateData         ( 4)} -- optional parameters

VoiceAttribChanged ::= BIT STRING
{
    playVolumeAbs       ( 0), -- optional parameters
    playVolumeInc       ( 1), -- optional parameters
    recordGain          ( 2), -- optional parameters
    speed               ( 3), -- optional parameters
    currentPosition     ( 4), -- optional parameters
    cause               ( 5), -- optional parameters
    privateData         ( 6)} -- optional parameters

-- 12.4.21

CDRServList ::= SEQUENCE
{
    cdrNotification      [ 0] IMPLICIT CdrNotification      OPTIONAL,
    cdrReport            [ 1] IMPLICIT CdrReport            OPTIONAL,
    sendStoredCDRs       [ 2] IMPLICIT SendStoredCDRs       OPTIONAL,
    startCDRTransmission [ 3] IMPLICIT StartCDRTransmission OPTIONAL,
    stopCDRTransmission  [ 4] IMPLICIT StopCDRTransmission  OPTIONAL }

CdrNotification ::= BIT STRING
{
    cdrReasonTimeout      ( 0), -- optional parameters
    cdrReasonThresholdReached ( 1), -- optional parameters
    cdrReasonOther        ( 2), -- optional parameters
    privateData           ( 3), -- optional parameters
    privateDataInAck      ( 4)} -- optional parameters

CdrReport ::= BIT STRING
{
    cdrReasonTimeout      ( 0), -- optional parameters
    cdrReasonThresholdReached ( 1), -- optional parameters
    cdrReasonOther        ( 2), -- optional parameters
    recordNumber          ( 3), -- optional parameter
    recordCreationTime     ( 4), -- optional parameter
    callingDevice         ( 5), -- optional parameter
    calledDevice          ( 6), -- optional parameter
    assocCallingDevice     ( 7), -- optional parameter
    assocCalledDevice     ( 8), -- optional parameter
    netwCallingDevice     ( 9), -- optional parameter
    netwCalledDevice      (10), -- optional parameter
    callCharacteristics    (11), -- optional parameter
    mediaCallCharacteristics (12), -- optional parameter
    chargedDeviceOperator  (13), -- optional parameter
    chargedDeviceNonOperator (14), -- optional parameters
    recordedCall          (15), -- optional parameters
    nodeNumberArea0       (16), -- optional parameters
    nodeNumberArea1       (17), -- optional parameters
    nodeNumberArea2       (18), -- optional parameters
    tarifTable            (19), -- optional parameters
    connectionStart       (20), -- optional parameters
    connectionEnd         (21), -- optional parameters
    connectionDuration    (22), -- optional parameters
    accessCode            (23), -- optional parameters
    carrier               (24), -- optional parameters
    selectedRoute         (25), -- optional parameters
    billingIndicatorNormalCharging (26), -- optional parameters
    billingIndicatorReverseCharging (27), -- optional parameters
    billingIndicatorCreditCardCharging (28), -- optional parameters
    billingIndicatorCallForwarding (29), -- optional parameters
    billingIndicatorCallDeflection (30), -- optional parameters
    billingIndicatorCallTransfer (31), -- optional parameters
    billingIndicatorOther  (32), -- optional parameters
```

```
chargingInfo                                (33),    -- optional parameters
suppServiceInfoNormalCall                   (34),    -- optional parameters
suppServiceInfoConsultationCall             (35),    -- optional parameters
suppServiceInfoTransferCall                 (36),    -- optional parameters
suppServiceInfoCallCompletion               (37),    -- optional parameters
suppServiceInfoCallForwarding               (38),    -- optional parameters
suppServiceInfoCallDiversion                (39),    -- optional parameters
suppServiceInfoConferencing                 (40),    -- optional parameters
suppServiceInfoIntrusion                    (41),    -- optional parameters
suppServiceInfoUserUserInfo                 (42),    -- optional parameters
suppServiceInfoOther                        (43),    -- optional parameters
reasonForTermNormalClearing                 (44),    -- optional parameters
reasonForTermUnsuccessfulCallAttempt        (45),    -- optional parameters
reasonForTermAbnormalTermination            (46),    -- optional parameters
reasonForTermCallTransferred                (47),    -- optional parameters
reasonForTermOther                          (48),    -- optional parameters
authCode                                    (49),    -- optional parameters
accountInfo                                 (50),    -- optional parameters
deviceCategory                              (51),    -- optional parameters
namedDeviceTypes                           (52),    -- optional parameters
operatorDevice                              (53),    -- optional parameters
lastStoredCDRReportSent                     (54),    -- optional parameters
privateData                                 (55),    -- optional parameters
privateDataInAck                            (56)}    -- optional parameters

SendStoredCDRs ::= BIT STRING
{
    timePeriod            ( 0),    -- optional parameters
    privateData            ( 1),    -- optional parameters
    privateDataInAck       ( 2)}    -- optional parameters

StartCDRTransmission ::= BIT STRING
{
    transferModeTransferAtEndOfCall          ( 0),    -- optional parameters
    transferModeTransferOnRequest            ( 1),    -- optional parameters
    transferModeTransferOnThresholdReached   ( 2),    -- optional parameters
    privateData                    ( 3),    -- optional parameters
    privateDataInAck                ( 4)}    -- optional parameters

StopCDRTransmission ::= BIT STRING
{
    cdrTermReasonEndOfData          ( 0),    -- optional parameters
    cdrTermReasonError              ( 1),    -- optional parameters
    cdrTermReasonThresholdReached    ( 2),    -- optional parameters
    cdrTermReasonOther              ( 3),    -- optional parameter
    privateData                     ( 4),    -- optional parameter
    privateDataInAck                ( 5),    -- optional parameter
    swFunctionSupportsSending        ( 6),    -- miscellaneous characteristics
    swFunctionSupportsReceiving      ( 7)}    -- miscellaneous characteristics

-- 12.4.22

VendorSpecificServList ::= SEQUENCE
{
    escapeRegister                [ 0] IMPLICIT EscapeRegister          OPTIONAL,
    escapeRegisterCancel          [ 1] IMPLICIT EscapeRegisterCancel    OPTIONAL,
    escapeRegisterAbort           [ 2] IMPLICIT EscapeRegisterAbort      OPTIONAL,
    escape                        [ 3] IMPLICIT Escape                   OPTIONAL,
    privateDataVersionSelection   [ 4] IMPLICIT PrivateDataVersionSelection OPTIONAL }

EscapeRegister ::= BIT STRING
{
    privateData            (0),    -- optional parameters
    privateDataInAck       (1)}    -- optional parameters

EscapeRegisterCancel ::= BIT STRING
{
    privateData            (0),    -- optional parameters
    privateDataInAck       (1)}    -- optional parameters

EscapeRegisterAbort ::= BIT STRING
{
    privateData            (0),    -- optional parameters
    privateDataInAck       (1)}    -- optional parameters
```

```
Escape ::= BIT STRING
{
    privateDataInAck          ( 0),  -- optional parameters
    swFunctionSupportsSending ( 1),  -- misc characteristics
    swFunctionSupportsReceiving ( 2)} -- misc characteristics

PrivateDataVersionSelection ::= BIT STRING
{
    privateDataInAck          ( 0)} -- optional parameters

-- 12.4.23
VendorSpecificEvtsList ::= SEQUENCE
{
    privateEvent [0] IMPLICIT PrivateEvent OPTIONAL}

PrivateEvent ::= BIT STRING

-- other Types

DeviceIDFormat ::= BIT STRING
{
    dialableDigitsAsterix      ( 0),
    dialableDigitsHash         ( 1),
    dialableDigitsABCD         ( 2),
    dialableDigitsExclamation ( 3),
    dialableDigitsP            ( 4),
    dialableDigitsT            ( 5),
    dialableDigitsComma        ( 6),
    dialableDigitsW            ( 7),
    dialableDigitsAt           ( 8),
    dialableDigitsDollar       ( 9),
    dialableDigitsSemicolon    (10),
    sFReprExclamation          (11),
    sFReprEt                    (12),
    sFReprSlash                (13),
    sFReprPercent              (14),
    sFReprNM                    (15),
    sFReprGeneric              (16),
    sFReprImplicitTON          (17),
    sFReprPubTONUnkown         (18),
    sFReprPubTONInternal       (19),
    sFReprPubTONNational       (20),
    sFReprPubTONSubscriber     (21),
    sFReprPubTONAbbreviated    (22),
    sFReprPriTONUnknown        (23),
    sFReprPriTONLevel3         (24),
    sFReprPriTONLevel2         (25),
    sFReprPriTONLevel1         (26),
    sFReprPriTONLocal          (27),
    sFReprPriTONAbbreviated    (28),
    sFReprOther                (29),
    deviceNumber               (30)}

SwDomainFeatures ::= BIT STRING
{
    isForwardingBefore          ( 0),
    isForwardingAfter           ( 1),
    swFunctionDefaultSettings   ( 2),
    userSpecific                ( 3),
    userSpecificDefaultFowardingType ( 4),
    userSpecificDefaultForwardDestination ( 5),
    negativeAcknowledgment      ( 6),
    supportFailedWithAssConn     ( 7),
    supportFailedWithoutAssConn  ( 8),
    supportFailedWithAssConnNotReportet ( 9),
    recall                      (10),
    callBack                    (11),
    extCallsIncoming            (12),
    extCallsOutgoing            (13),
    prompting                    (14)}
```

```
SwAppearanceAddressability ::= BIT STRING
{
    nonAddressable    (0),
    addressable       (1)}

SwAppearanceTypes ::= BIT STRING
{
    selectedStandard      (0),
    basicStandard         (1),
    basicBridged          (2),
    exclusiveBridged      (3),
    independentSharedBridged (4),
    interDependentSharedBridged (5)}

IgnoreUnsupportedParameters ::= ENUMERATED
{
    ignoreParameters    (0),
    rejectMessage       (1)}

PauseTime ::= INTEGER (1..2000)

TimeStampMode ::= BIT STRING
{
    allEvents      (0),
    allAcks        (1),
    allServReqs    (2)}

MiscMonitorCaps ::= BIT STRING
{
    groupInclusivModel    (0),
    groupExclusiveModel   (1),
    monitorPhysicalElement (2),
    acdDeviceInclusiv     (3),
    acdDeviceExclusiv     (4)
}

MaxLengthParameters ::= SEQUENCE
{
    accountInfo      INTEGER (0..32),
    authCode         INTEGER (0..32),
    agentID          INTEGER (0..32),
    agentPassword    INTEGER (0..32),
    callIDInConnectionID INTEGER (0..8),
    correlatorData   INTEGER (0..32),
    privateData      INTEGER,
    deviceIdentifiers INTEGER (0..128),
    userData         INTEGER (0..256),
    buttonLabel      INTEGER (0..64),
    lampLabel        INTEGER (0..64),
    charsToBeSent    INTEGER (0..64)}

FilterThreshold ::= SEQUENCE
{
    getLogicalDeviceInformation    INTEGER,
    getPhysicalDeviceInformation   INTEGER,
    getSwitchingFunctionCaps      INTEGER,
    getSwitchingFunctionDevices   INTEGER,
    switchingFunctionDevices       INTEGER,
    changeSystemStatusFilter      INTEGER,
    systemStatusRegister          INTEGER,
    systemStatusRegisterAbort     INTEGER,
    systemStatusRegisterCancel    INTEGER,
    requestSystemStatus           INTEGER,
    systemStatus                  INTEGER,
    switchingFunctionCapsChanged   INTEGER,
    switchingFunctionDevsChanged   INTEGER,
    changeMonitorFilter           INTEGER,
    monitorStart                  INTEGER,
    monitorStop                   INTEGER,
    snapshotCall                  INTEGER,
    snapshotDevice                INTEGER,
    snapshotCallData              INTEGER,
    snapshotDeviceData            INTEGER,
    acceptCall                    INTEGER,
```

alternateCall	INTEGER,
answerCall	INTEGER,
callBackCallRelated	INTEGER,
callBackMessageCallRelated	INTEGER,
campOnCall	INTEGER,
clearCall	INTEGER,
clearConnection	INTEGER,
conferenceCall	INTEGER,
consultationCall	INTEGER,
deflectCall	INTEGER,
dialDigits	INTEGER,
directedPickupCall	INTEGER,
groupPickupCall	INTEGER,
holdCall	INTEGER,
intrudeCall	INTEGER,
joinCall	INTEGER,
makeCall	INTEGER,
makePredictiveCall	INTEGER,
parkCall	INTEGER,
reconnectCall	INTEGER,
retrieveCall	INTEGER,
singleStepConferenceCall	INTEGER,
singleStepTransferCall	INTEGER,
transferCall	INTEGER,
associateData	INTEGER,
cancelTelephonyTone	INTEGER,
generateDigits	INTEGER,
generateTelephonyTone	INTEGER,
sendUserInformation	INTEGER,
startDTMFDigitsCollection	INTEGER,
startTelephonyTonesCollection	INTEGER,
stopDTMFDigitsCollection	INTEGER,
stopTelephonyTonesCollection	INTEGER,
attachMediaService	INTEGER,
detachMediaService	INTEGER,
routeRegister	INTEGER,
routeRegisterAbort	INTEGER,
routeRegisterCancel	INTEGER,
reRoute	INTEGER,
routeEnd	INTEGER,
routeReject	INTEGER,
routeRequest	INTEGER,
routeSelect	INTEGER,
routeUsed	INTEGER,
buttonPress	INTEGER,
getAuditoryApparatusInfo	INTEGER,
getButtonInformation	INTEGER,
getDisplay	INTEGER,
getHookswitchStatus	INTEGER,
getLampInformation	INTEGER,
getLampMode	INTEGER,
getMicrophoneGain	INTEGER,
getMicrophoneMute	INTEGER,
getMessageWaitingIndicator	INTEGER,
getRingerStatus	INTEGER,
getSpeakerMute	INTEGER,
getSpeakerVolume	INTEGER,
setButtonInformation	INTEGER,
setDisplay	INTEGER,
setHookswitchStatus	INTEGER,
setLampMode	INTEGER,
setMsgWaitingIndicator	INTEGER,
setMicrophoneGain	INTEGER,
setMicrophoneMute	INTEGER,
setRingerStatus	INTEGER,
setSpeakerMute	INTEGER,
setSpeakerVolume	INTEGER,
callBackMessageNonCallRelated	INTEGER,

callBackNonCallRelated	INTEGER,
cancelCallBack	INTEGER,
cancelCallBackMessage	INTEGER,
getAgentState	INTEGER,
getAutoAnswer	INTEGER,
getAutoWorkMode	INTEGER,
getCallerIDStatus	INTEGER,
getDoNotDisturb	INTEGER,
getForwarding	INTEGER,
getLastNumberDialed	INTEGER,
getRouteingMode	INTEGER,
setAgentState	INTEGER,
setAutoAnswer	INTEGER,
setAutoWorkMode	INTEGER,
setCallerIDStatus	INTEGER,
setDoNotDisturb	INTEGER,
setForwarding	INTEGER,
setRouteingMode	INTEGER,
backInService	INTEGER,
deviceCaosChanged	INTEGER,
outOfService	INTEGER,
ioRegister	INTEGER,
ioRegisterAbort	INTEGER,
ioRegisterCancel	INTEGER,
dataPathResumed	INTEGER,
dataPathSuspended	INTEGER,
fastData	INTEGER,
resumeDataPath	INTEGER,
sendBroadcastData	INTEGER,
sendData	INTEGER,
sendMulticastData	INTEGER,
startDataPath	INTEGER,
stopDataPath	INTEGER,
suspendDataPath	INTEGER,
concatenateMsg	INTEGER,
deleteMsg	INTEGER,
playMsg	INTEGER,
queryVoiceAttribute	INTEGER,
recordMsg	INTEGER,
reposition	INTEGER,
resume	INTEGER,
review	INTEGER,
setVoiceAttribute	INTEGER,
stop	INTEGER,
suspend	INTEGER,
synthesizeMsg	INTEGER,
cDRNotification	INTEGER,
cDRReport	INTEGER,
sendStoredCDRs	INTEGER,
startCDRTransmission	INTEGER,
stopCDRTransmission	INTEGER,
escapeRegister	INTEGER,
escapeRegisterAbort	INTEGER,
escapeRegisterCancel	INTEGER,
escape	INTEGER,
privateDataVersion	INTEGER}

```
MediaServiceCapsList ::= SEQUENCE OF SEQUENCE
{
    mediaServiceType      MediaServiceType,
    mediaServiceVersion    INTEGER
    mediaServiceInstance  MediaServiceInstanceID OPTIONAL,
    connectionMode        ConnectionModeBMap   OPTIONAL,
    mediaStreamIDSupported BOOLEAN}

```

```
DeviceCategory ::= ENUMERATED
{
    acd                ( 0 ),
    group              ( 1 ),
    networkInterface   ( 2 ),

```

```

    park                ( 3),
    routeingDevice      ( 4),
    station             ( 5),
    voiceUnit           ( 6),
    other               ( 7)}

GroupDeviceAttributes ::= BIT STRING
{
    acd      ( 0),
    hunt     ( 1),
    pick     ( 2),
    other    ( 3)}

NamedDeviceTypes ::= ENUMERATED
{
    acd                ( 0),
    acdGroup           ( 1),
    button             ( 2),
    buttonGroup        ( 3),
    conferenceBridge   ( 4),
    line               ( 5),
    lineGroup          ( 6),
    operator            ( 7),
    operatorGroup      ( 8),
    parkingDevice      ( 9),
    station            (10),
    stationGroup       (11),
    trunk              (12),
    trunkGroup         (13),
    other              (14),
    otherGroup         (15)}

ACDModels ::= BIT STRING
{
    visibleACDRelatedDevices      (0),
    nonVisibleACDRelatedDevices   (1)}

AgentLogOnModels ::= BIT STRING
{
    logOnToACDDevice              ( 0),
    logOnToACDGroupExplOneStep    ( 1),
    logOnToACDGroupExplTwoSteps   ( 2),
    logOnToACDImplOneStep         ( 3)}

AppearanceType ::= ENUMERATED
{
    selectedStandard              ( 0),
    basicStandard                 ( 1),
    basicBridged                  ( 2),
    exclusiveBridged              ( 3),
    independentSharedBridged      ( 4),
    interdependentSharedBridged   ( 5)}

TransAndConfSetup ::= BIT STRING
{
    consultationCall              ( 0),
    holdCallMakeCall              ( 1),
    alternateCall                 ( 2),
    twoCallsInHold                ( 3),
    twoCallsInConnected           ( 4)}

END -- of CSTA-capability-exchange
```

9.11 Call Detail Record

```
CSTA-call-detail-record
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-detail-record( 132) }

DEFINITIONS ::=
BEGIN

EXPORTS
CDRCrossRefID, CDRInfo, CDRReason, CDRTermReason, CDRTimePeriod,
CDRTransferMode;

IMPORTS
DeviceID, CalledDeviceID, CallingDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
TimeInfo FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
DeviceCategory, NamedDeviceTypes FROM CSTA-capability-exchange
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) capability-exchange( 131) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

CDRCrossRefID ::= OCTET STRING (SIZE(0..4))

CDRReason ::= ENUMERATED
{
  timeout              (0),
  thresholdReached     (1),
  other                (2)}

CDRInfo ::= SEQUENCE OF CDRInformationItem

CDRInformationItem ::= SEQUENCE
{
  recordNumber          INTEGER (1..128)                OPTIONAL,
  recordCreationTime    TimeInfo,                       OPTIONAL,
  callingDevice         CallingDeviceID                  OPTIONAL,
  calledDevice          CalledDeviceID                   OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID       OPTIONAL,
  associatedCalledDevice AssociatedCalledDeviceID         OPTIONAL,
  networkCallingDevice  NetworkCallingDeviceID           OPTIONAL,
  networkCalledDevice   NetworkCalledDeviceID            OPTIONAL,
  callCharacteristics   [0] IMPLICIT CallCharacteristics OPTIONAL,
  mediaCallCharacteristics [1] IMPLICIT MediaCallCharacteristics OPTIONAL,
  chargedDevice         [2] ChargedDevice                OPTIONAL,
  recordedCall          ConnectionID                     OPTIONAL,
  nodeNumber            [3] IMPLICIT NodeNumber          OPTIONAL,
  tariffTable           [4] IMPLICIT INTEGER             OPTIONAL,
  connectionStart       [5] IMPLICIT TimeInfo            OPTIONAL,
  connectionEnd         [6] IMPLICIT TimeInfo            OPTIONAL,
```



```

connectionDuration      [7] IMPLICIT INTEGER      OPTIONAL,
accessCode              [8] IMPLICIT INTEGER      OPTIONAL,
carrier                 [9] IMPLICIT INTEGER      OPTIONAL,
selectedRoute           [10] IMPLICIT INTEGER     OPTIONAL,
billingID               [11] IMPLICIT BillingID    OPTIONAL,
chargingInfo            [12] IMPLICIT ChargingInfo OPTIONAL,
supplServiceInfo        [13] IMPLICIT SupplServiceInfo OPTIONAL,
reasonForTerm           [14] IMPLICIT ReasonForTerm OPTIONAL,
authCode                [15] IMPLICIT AuthCode    OPTIONAL,
accountInfo             [16] IMPLICIT AccountInfo OPTIONAL,
deviceCategory          [17] IMPLICIT DeviceCategory OPTIONAL,
namedDeviceTypes        [18] IMPLICIT NamedDeviceTypes OPTIONAL,
operatorDevice           [19] DeviceID            OPTIONAL}

ChargedDevice ::= CHOICE
{
    operator          [0] IMPLICIT DeviceID,
    nonOperator       [1] IMPLICIT DeviceID}

NodeNumber ::= SEQUENCE
{
    area0    [0] IMPLICIT INTEGER OPTIONAL,
    area1    [1] IMPLICIT INTEGER OPTIONAL,
    area2    [2] IMPLICIT INTEGER OPTIONAL}

BillingID ::= ENUMERATED
{
    normalCharging          (0),
    reverseCharging         (1),
    creditCardCharging      (2),
    callForwarding          (3),
    callDeflection          (4),
    callTransfer            (5),
    other                   (6)}

SupplServiceInfo ::= BIT STRING
{
    normalCall              (0),
    consultationCall        (1),
    transferCall            (2),
    callCompletion          (3),
    callForwarding          (4),
    callDiversion           (5),
    conferencing            (6),
    intrusion               (7),
    userUserInfo            (8),
    other                   (9)}

ReasonForTerm ::= ENUMERATED
{
    normalClearing          (0),
    unsuccessfulCallAttempt (1),
    abnormalTermination     (2),
    callTransferred         (3),
    other                   (4)}

CDRTimePeriod ::= SEQUENCE
{
    beginningOfCDR    TimeInfo,
    endOfCDR          TimeInfo}

CDRTransferMode ::= ENUMERATED
{
    transferAtEndOfCall      (0),
    transferOnRequest        (1),
    transferOnThresholdReached (2)}

CDRTermReason ::= ENUMERATED
{
    endOfDataDetected       (0),
    errorDetected           (1),
    thresholdReached        (2),
    other                   (3)}

END -- of CSTA-call-detail-record
```

9.12 Charge information

```
CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }

DEFINITIONS ::=
BEGIN

EXPORTS
ChargingInfo;

ChargingInfo ::= SEQUENCE
{
    numberUnits          NumberUnits,
    typeOfChargingInfo   ENUMERATED
    {
        subTotal        (0),
        total            (1)
    }
}

NumberUnits ::= CHOICE
{
    numberOfChargeUnits   [0] IMPLICIT NumberOfChargingUnits,
    numberOfCurrencyUnits [1] IMPLICIT NumberOfCurrencyUnits}

NumberOfChargingUnits ::= SEQUENCE OF SEQUENCE
{
    chargingUnits   INTEGER,
    typeOfUnits     OCTET STRING OPTIONAL }

NumberOfCurrencyUnits ::= SEQUENCE
{
    currencyType      OCTET STRING,          -- size 0 indicates default currency
    currencyAmount     INTEGER,
    currencyMultiplier ENUMERATED
    {
        oneThousandth      (0),
        oneHundredth        (1),
        oneTenth            (2),
        one                 (3),
        ten                 (4),
        hundred             (5),
        thousand            (6)
    }
}

END -- of CSTA-charge-info
```

9.13 Data call types

```
CSTA-data-call-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-call-types( 134) }

DEFINITIONS ::=
BEGIN

EXPORTS
NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList;

NumberOfChannels      ::= INTEGER

MaxChannelBind        ::= INTEGER

ConnectionRateList ::= SEQUENCE OF INTEGER

DelayToleranceList ::= SEQUENCE OF INTEGER

END      -- of CSTA-data-call-types
```

9.14 Escape types

```
CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) }

DEFINITIONS ::=
BEGIN
EXPORTS
EscapeRegisterID;

EscapeRegisterID ::= [0] OCTET STRING (SIZE(0..4))

END -- of CSTA-escape-types
```

9.15 Media services

```
CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }

DEFINITIONS ::=
BEGIN

EXPORTS
ConnectionInformation, ConnectionMode, ConnectionModeBMap, MediaCallCharacteristics,
MediaServiceInstanceID, MediaServiceType, MediaStreamID, MediaClass;

MediaServiceType ::= ENUMERATED
{
  cstaVoiceUnit                               ( 0),
  dataModem                                   ( 1),
  digitalDataIsochronousIeee1394              ( 2),
  digitalDataIsochronousGeoport               ( 3),
  digitalDataIsochronousIeeeAtm               ( 4),
  digitalDataIsochronousIeeeIsdn              ( 5),
  digitalDataApi                               ( 6),
  ectfS100MediaServicesDefault                ( 7),
  ectfS100MediaServicesAppServices            ( 8),
  cstaIVRScript1                              ( 9),
  cstaIVRScript2                             (10),
  cstaIVRScript3                             (11),
  cstaIVRScript4                             (12),
  cstaIVRScript5                             (13),
  cstaIVRScript6                             (14),
  cstaIVRScript7                             (15),
  cstaIVRScript8                             (16),
  cstaIVRScript9                             (17),
  cstaIVRScript10                            (18),
  liveSoundCaptureAnalog                     (19),
  liveSoundTransmitAnalog                     (20),
  liveSoundCaptureIeee1394                    (21),
  liveSoundTransmitIeee1394                   (22),
  liveSoundCaptureTransmitGeoport             (23),
  liveSoundCaptureTransmitAtm                 (24),
  liveSoundCaptureTransmitISDN                (25),
  soundCaptureTransmitADPCM                   (26),
  soundCaptureTransmitApi                     (27),
  usb                                          (28),
  sfSpecific1                                 (29),
  sfSpecific2                                 (30),
  sfSpecific3                                 (31),
  sfSpecific4                                 (32),
  sfSpecific5                                 (33),
  sfSpecific6                                 (34),
  sfSpecific7                                 (35),
  sfSpecific8                                 (36),
  sfSpecific9                                 (37),
  sfSpecific10                                (38)}

MediaStreamID ::= OCTET STRING
MediaServiceInstanceID ::= OCTET STRING (SIZE(0..64))

ConnectionInformation ::= SEQUENCE
{
  flowDirection          ENUMERATED
  {
    transmit              (0),
    receive                (1),
    transmitAndReceive    (2)
  } OPTIONAL,
  numberOfChannels        INTEGER      DEFAULT 1 }

ConnectionMode ::= ENUMERATED
{
  consultationConference      (0),
  consultationConferenceHold  (1),
```

```

deflect                (2),
directedPickup         (3),
join                   (4),
singleStepConference   (5),
singleStepConferenceHold (6),
singleStepTransfer     (7),
transfer               (8),
direct                 (9)}

ConnectionModeBMap ::= BIT STRING
{
    consultationConference   (0),
    consultationConferenceHold (1),
    deflect                 (2),
    directedPickup          (3),
    join                    (4),
    singleStepConference     (5),
    singleStepConferenceHold (6),
    singleStepTransfer       (7),
    transfer                 (8),
    direct                  (9)}

MediaCallCharacteristics ::= SEQUENCE
{
    mediaClass             MediaClass,
    connectionRate         [0] IMPLICIT INTEGER OPTIONAL,
                                -- value 0 indicates that
                                -- the connection rate is
                                -- unknown
    bitrate                [1] IMPLICIT ENUMERATED
                                {
                                    constant (0),
                                    variable (1)} DEFAULT 0,
    delayTolerance         [2] IMPLICIT INTEGER OPTIONAL,
    switchingSubDomainCCIEType [3] IMPLICIT ENUMERATED {
                                isdn          (0),
                                atm           (1),
                                isoEthernet (2),
                                rsvp         (3),
                                other        (4)
                                } OPTIONAL,
    switchingSubDomainInformationElements OCTET STRING OPTIONAL
    -- is mandatory, if the switchingSubDomainCCIEType is present,
    -- should be ignored otherwise
}

MediaClass ::= BIT STRING
{
    voice                (0),
    data                 (1),
    image                (2),
    audio                (4),
    other                (3),
    notKnown             (5)}

END      -- of CSTA-media-services

```

9.16 Physical device features

```
CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) }

DEFINITIONS ::=
BEGIN

EXPORTS
AuditoryApparatusID, AuditoryApparatusList, ButtonID, CharacterSet, ContentsOfDisplay, DisplayID,
LampBrightness, LampColor, LampID, LampMode, MicGainAbs, MicrophoneGain, RingerID, RingMode,
VolAbs, Volume, HookswitchID;

AuditoryApparatusList ::= SEQUENCE OF
  SEQUENCE {
    auditoryApparatus AuditoryApparatusID,
    auditoryApparatusType ENUMERATED {
      speakerphone (0),
      handset (1),
      headset (2),
      speakerOnlyPhone (3),
      other (4)
    },
    speaker BIT STRING {
      present (0),
      volumeSettable (1),
      volumeReadable (2),
      muteSettable (3),
      muteReadable (4)
    },
    microphone BIT STRING {
      present (0),
      gainSettable (1),
      gainReadable (2),
      muteSettable (3),
      muteReadable (4)
    },
    hookswitch BIT STRING {
      hookswitchSettable (0),
      hookswitchOnHook (1)
    },
    hookswitchID HookswitchID
  }

AuditoryApparatusID ::= OCTET STRING (SIZE(0..4))

ButtonID ::= OCTET STRING (SIZE(0..4))

CharacterSet ::= ENUMERATED
{
  ascii (0),
  unicode (1),
  proprietary (2)
}

DisplayID ::= OCTET STRING (SIZE(0..4))

HookswitchID ::= OCTET STRING (SIZE(0..4))

LampBrightness ::= ENUMERATED
{
  unspecified (0),
  dim (1),
  bright (2)
}
```

```
LampColor ::= INTEGER
{
    noColor (0),
    red      (1),
    yellow   (2),
    green     (3),
    blue      (4),
    unknown  (5)} (0..100)

LampID ::= OCTET STRING (SIZE(0..4))

LampMode ::= ENUMERATED
{
    brokenFlutter (0),
    flutter       (1),
    off           (2),
    steady        (3),
    wink          (4)}

MicrophoneGain ::= CHOICE
{
    micGainAbs    MicGainAbs,
    micGainInc    MicGainInc}

MicGainInc ::= ENUMERATED
{
    increment      (0),
    decrement      (1)}

MicGainAbs ::= INTEGER (0..100)

RingerID ::= OCTET STRING (SIZE(0..4))

RingMode ::= ENUMERATED
{
    ringing      (0),
    notRinging   (1)}

Volume ::= CHOICE
{
    volAbs    VolAbs,
    volInc    VolInc}

VolInc ::= ENUMERATED
{
    increment      (0),
    decrement      (1)}

VolAbs ::= INTEGER (0..100)

END -- of CSTA-physical-device-feature
```


9.17 Data Collection

```
CSTA-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collection( 138) }

DEFINITIONS ::=
BEGIN

EXPORTS
DcollCrossRefID;

DcollCrossRefID ::= OCTET STRING (SIZE(0..4))

END -- of CSTA-data-collection
```

9.18 Event Cause

```
CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }

DEFINITIONS ::=
BEGIN

EXPORTS
EventCause;

EventCause ::= ENUMERATED
-- a general list of cause codes
--
--
-- Present in Added in Added in
-- Version 1 Version2 Version3
{
    aCDBusy (57),
    aCDForward (58),
    aCDSaturated (59),
    activeParticipation (1),
    alertTimeExpired (60),
    alternate (2),
    autoWork (61),
    blocked (35),
    busy (3),
    callBack (4),
    callCancelled (5),
    callForward (9),
    callForwardImmediate (6),
    callForwardBusy (7),
    callForwardNoAnswer (8),
    callNotAnswered (10),
    callPickup (11),
    campOn (12),
    campOnTrunks (62),
    characterCountReached (36),
    conference (63),
    consultation (37),
    destDetected (64),
    destNotObtainable (13),
    destOutOfOrder (65),
    distributed (38),
    distributionDelay (66),
    doNotDisturb (14),
    dTMFDigitDetected (39),
    durationExceeded (40),
    endOfMessageDetected (41),
    enteringDistribution (42),
    forcedPause (43),
    forcedTransition (67),
    incompatibleDestination (15),
    intrude (68),
    invalidAccountCode (16),
    invalidNumberFormat (69),
    joinCall (70),
    keyOperation (17),
    keyOperationInUse (71),
    lockout (18),
    maintenance (19),
    makeCall (44),
    makePredictiveCall (72),
    messageDurationExceeded (73),
    messageSizeExceeded (45),
    multipleAlerting (74),
    multipleQueuing (75),
    networkCongestion (20),
    networkDialling (76),
    networkNotObtainable (21),
    networkOutOfOrder (77),
```

```
networkSignal                (46),
newCall                      (22),
nextMessage                  (47),
noAvailableAgents           (23),
normal                      (78),
normalClearing               (48),
noSpeechDetected             (49),
notAvaliableBearerService    (79),
notSupportedBearerService    (80),
numberChanged                (50),
numberUnallocated            (81),
overflow                     (26),
override                     (24),
park                         (25),
queueCleared                 (82),
recall                      (27),
redirected                   (28),
remainsInQueue               (83),
reorderTone                  (29),
reserved                     (84),
resourcesNotAvailable        (30),
selectedTrunkBusy            (85),
silentParticipation          (31),
singleStepConference         (51),
singleStepTransfer           (52),
speechDetected               (53),
suspend                      (86),
switchingFunctionTerminated  (54),
terminationCharacterReceived (55),
timeout                     (56),
transfer                     (32),
trunksBusy                   (33),
unauthorisedBearerService    (87)}
-- voiceUnitInitiator        (34) }
```

END -- of event-cause-definitions

9.19 Error Value

```
CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }

DEFINITIONS ::=
BEGIN

EXPORTS
UniversalFailure, universalFailure, ErrorValue;

IMPORTS

ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)};

universalFailure ERROR
  PARAMETER      UniversalFailure
  ::= 1

ErrorValue ::= UniversalFailure

UniversalFailure ::= CHOICE
{
  operation          [0] OperationErrors,
  security            [1] SecurityErrors,
  stateIncompatibility [2] StateIncompatibilityErrors,
  systemResourceAvailability [3] SystemResourceAvailabilityErrors,
  subscribedResourceAvailability [4] SubscribedResourceAvailabilityErrors,
  performanceManagement [5] PerformanceManagementErrors,
  privateData         [6] PrivateDataInfoErrors,
  unspecified         [7] UnspecifiedErrors}

OperationErrors ::= ENUMERATED
{
  generic
  atLeastOneConditionalParameterNotProvided
  featureAlreadySet
  invalidMsgID
  invalidParameterValue
  invalidAccountCode
  invalidAgentGroup
  invalidAgentIdentifier
  invalidAgentPassword
  invalidAgentState
  invalidAlertTime
  invalidAllocationState
  invalidAuthCode
  invalidAutoAnswer
  invalidBitRate
  invalidButtonIdentifier
  invalidCallType
  invalidConnectionRate
  invalidConsultPurpose
  invalidCorrelatorData
  invalidCrossRefID
  invalidDelayTolerance
  invalidDestination
  invalidDestinationDetect
  invalidDoNotDisturb
  invalidEscapeCrossRefID
  invalidFeature
  invalidFile
  invalidFlowDirection
  invalidForwardingDestination
  invalidForwardingFlag
  invalidForwardingType
  invalidHookswitchType
  invalidHookswitchComponent
  --
  in CSTA2
  ( 1),
  (29),
  (30),
  (25),
  (31),
  (21),
  (32),
  (33),
  (34),
  (35),
  (36),
  (16),
  (22),
  (37),
  (38),
  (39),
  (42),
  (43),
  (44),
  (20),
  (17),
  (45),
  (14),
  (46),
  (47),
  (48),
  (15),
  (28),
  (49),
  ( 7),
  (51),
  (52),
  (53),
  (54),
  added in CSTA3
```

invalidLampMode		(55),
invalidLampID		(56),
invalidMessageWaitingSetting		(57),
invalidMicrophoneGain		(58),
invalidMicrophoneMute		(59),
invalidMonitorCrossRefID		(60),
invalidMonitorFilter		(61),
invalidMonitorObject		(62),
invalidMonitorType		(63),
invalidNumberOfChannels		(64),
invalidParticipationType		(65),
invalidRemainRetry		(66),
invalidRingCount		(67),
invalidRingPattern		(68),
invalidRingVolume		(69),
invalidRouteingAlgorithm		(70),
invalidRouteingCrossRefID		(71),
invalidRouteRegistrationCrossRefID		(72),
invalidSpeakerVolume		(73),
invalidSpeakerMute		(74),
invalidSwitchingSubdomainCharsType		(75),
invalidObjectType	(18),	
invalidActiveCallObject		(76),
invalidCalledDeviceObjectType		(77),
invalidCallingDeviceObjectType		(78),
invalidCallToBePickedUpObjectType		(79),
invalidCallToDivertObjectType		(80),
invalidCallToParkObjectType		(81),
invalidDestinationDeviceObject		(195),
invalidHeldCallObject		(82),
invalidMonitorObjectType		(83),
invalidParkToObjectType		(84),
messageIDRequired	(26),	
notDifferentDevices		(85),
notSameDevice		(86),
objectNotKnown	(4),	
invalidCallID	(11),	
invalidActiveCallID		(87),
invalidHeldCallID		(88),
invalidConnectionID	(13),	
invalidActiveConnectionID		(89),
invalidHeldConnectionID		(90),
invalidDeviceID	(12),	
invalidActiveDeviceID		(91),
invalidCalledDeviceID	(6),	
invalidCallingDeviceID	(5),	
invalidCallToParkDeviceID		(92),
invalidDestinationDeviceID		(93),
invalidDivertingDeviceID		(94),
invalidHeldDeviceID		(95),
invalidParkToDeviceID		(96),
invalidPickUpDeviceID		(97),
parameterNotSupported		(98),
accountCodeNotSupported		(99),
agentGroupNotSupported		(100),
agentPasswordNotSupported		(101),
agentStateNotSupported		(102),
alertTimeNotSupported		(103),
allocationNotSupported		(104),
authorisationCodeNotSupported		(105),
autoAnswerNotSupported		(106),
bitRateNotSupported		(107),
buttonNotSupported		(108),
callTypeNotSupported		(109),
charactersToSendNotSupported		(110),
connectionRateNotSupported		(111),
connectionReservationNotSupported		(112),
consultPurposeNotSupported		(113),

correlatorDataNotSupported	(114),
delayToleranceNotSupported	(115),
destinationDetectNotSupported	(116),
digitModeNotSupported	(117),
errorValueNotSupported	(118),
flowDirectionNotSupported	(119),
forwardingDestinationNotSupported	(120),
lampNotSupported	(121),
monitorTypeNotSupported	(122),
numberOfChannelsNotSupported	(123),
parameterTypeNotSupported	(124),
priorityNotSupported	(125),
privateDataNotSupported	(126),
pulseDurationNotSupported	(127),
pulseRateNotSupported	(128),
remainRetryNotSupported	(129),
ringCountNotSupported	(130),
routeUsedNotSupported	(131),
securityNotSupported	(132),
swSubdomainCCIETypeNotSupported	(133),
toneDurationNotSupported	(134),
sysStatRegIDNotSupported	(135),
userDataNotSupported	(136),
privilegeViolationSpecifiedDevice(8),	
privilegeViolationActiveDevice	(137),
privilegeViolationCalledDevice(9),	
privilegeViolationCallingDevice(10),	
privilegeViolationCallToParkDevice	(138),
privilegeViolationDestinationDevice	(139),
privilegeViolationOnDivertingDevice	(140),
privilegeViolationHeldDevice	(141),
privilegeViolationOnParkToDevice	(142),
privilegeViolationPickUpDevice	(143),
routeingTimerExpired	(144),
requestIncompatibleWithObject	(2),
requestIncompatibleWithConnection	(145),
requestIncompatibleWithActiveConnection	(146),
requestIncompatibleWithHeldConnection	(147),
requestIncompatibleWithDevice	(148),
requestIncompatibleWithCalledDevice	(24),
requestIncompatibleWithCallingDevice	(23),
requestIncompatibleWithSubjectDevice	(149),
requestIncompatibleWithActiveDevice	(150),
requestIncompatibleWithCallToParkDevice	(151),
requestIncompatibleWithDestinationDevice	(152),
requestIncompatibleWithDivertingDevice	(153),
requestIncompatibleWithHeldDevice	(154),
requestIncompatibleWithMedia	(27),
requestIncompatibleWithParkToDevice	(155),
requestIncompatibleWithPickupDevice	(156),
serviceNotSupported	(50),
securityViolation	(19),
valueOutOfRange	(3),
agentStateOutOfRange	(157),
alertTimeOutOfRange	(158),
allocationOutOfRange	(159),
autoAnswerOutOfRange	(160),
bitRateOutOfRange	(161),
callTypeOutOfRange	(162),
connectionRateOutOfRange	(163),
connectionReservoationOutOfRange	(164),
consultPurposeOutOfRange	(165),
correlatorDataOutOfRange	(166),
delayToleranceOutOfRange	(167),
destinationDetectOutOfRange	(168),
digitModeOutOfRange	(169),
doNotDisturbOutOfRange	(170),
flowDirectionOutOfRange	(171),

```
forwardingFlagOutOfRange (172),
forwardingTypeOutOfRange (173),
hookswitchComponentOutOfRange (174),
hookswitchTypeOutOfRange (175),
lampModeOutOfRange (176),
messageWaitingSettingOutOfRange (177),
micGainOutOfRange (178),
micMuteOutOfRange (179),
monitorTypeOutOfRange (180),
numberOfChannelsOutOfRange (181),
participationTypeOutOfRange (182),
pulseDurationOutOfRange (183),
pulseRateOutOfRange (184),
ringCountOutOfRange (185),
ringPatternOutOfRange (186),
ringVolumnOutOfRange (187),
routeingAlgorithmOutOfRange (188),
speakerMuteOutOfRange (189),
speakerVolumeOutOfRange (190),
switchingCcittTypeOutOfRange (191),
systemStatusOutOfRange (192),
toneCharacterOutOfRange (193),
toneDurationOutOfRange (194)}

SecurityErrors ::= ENUMERATED
{
    generic ( 0),
    sequenceNumberViolated ( 1),
    timeStampViolated ( 2),
    securityInfoViolated ( 4)}

StateIncompatibilityErrors ::= ENUMERATED
{
    generic ( 1),
    invalidObjectState ( 2),
    invalidDeviceState (15),
    connectedCallExists (16),
    invalidActiveDeviceState (17),
    invalidCalledDeviceState (18),
    invalidCallingDeviceState (19),
    invalidCallToParkDeviceState (20),
    invalidDestinationDeviceState (21),
    invalidDivertingDeviceState (22),
    invalidHeldDeviceState (23),
    invalidParkToDeviceState (24),
    invalidConnectionState (25),
    invalidActiveConnectionState (26),
    invalidConnectionIDForActiveCall ( 3),
    invalidHeldConnectionState (27),
    noActiveCall ( 4),
    noCallToAnswer ( 8),
    noCallToClear ( 6),
    noCallToComplete ( 9),
    noConnectionToClear ( 7),
    noHeldCall ( 5),
    incorrectMsgState (28),
    beginningOfMsg (13),
    endOfMsg (12),
    msgSuspended (14),
    notAbleToPlay (10),
    notAbleToResume (11)}

SystemResourceAvailabilityErrors ::= ENUMERATED
{
    generic ( 1),
    resourceBusy ( 2),
    internalResourceBusy ( 3),
    classifierBusy ( 9),
    noMediaChannelsAvailable (10),
    channelsInUseForBridgedDevices (11),
    channelsInUseForData (12),
```

```
toneDetectorBusy                (13),
toneGeneratorBusy               (14),
networkBusy                     ( 5),
resourceOutOfService            ( 4),
deviceOutOfService              (15),
activeDeviceOutOfService        (16),
calledDeviceOutOfService        (17),
callingDeviceOutOfService       (18),
callToParkDeviceOutOfService    (19),
destinationDeviceOutOfService   (20),
divertingDeviceOutOfService     (21),
heldDeviceOutOfService          (22),
parkToDeviceOutOfService        (23),
pickupDeviceOutOfService        (24),
networkOutOfService             ( 6),
otherResourceOutOfService       (25),
resourceLimitExceeded           (26),
overallMonitorLimitExceeded     ( 7),
conferenceMemberLimitExceeded   ( 8),
registrationLimitExceeded       (27)}

SubscribedResourceAvailabilityErrors ::= ENUMERATED
{
    generic                ( 1),
    objectMonitorLimitExceeded ( 2),
    trunkLimitExceeded      ( 3),
    outstandingReqLimitExceeded ( 4),
    objectRegistrationLimitExceeded ( 5)}

PerformanceManagementErrors ::= ENUMERATED
{
    generic                (1),
    performanceLimitExceeded (2)}

PrivateDataInfoErrors ::= ENUMERATED
{
    cSTAPrivateDataInfoError(1)}

UnspecifiedErrors ::= NULL

END -- of CSTA-error-definition
```


10 Event Report Service

```
CSTA-event-report-definitions
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-report-definitions( 21) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
CallClearedEvent FROM CSTA-call-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-cleared-event( 22) }
ConferencedEvent FROM CSTA-conferenced-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) conferenced-event( 23) }
ConnectionClearedEvent FROM CSTA-connection-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-cleared-event( 24) }
DeliveredEvent FROM CSTA-delivered-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) delivered-event( 25) }
DivertedEvent FROM CSTA-diverted-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) diverted-event( 26) }
EstablishedEvent FROM CSTA-established-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) established-event( 27) }
FailedEvent FROM CSTA-failed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) failed-event( 28) }
HeldEvent FROM CSTA-held-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) held-event( 29) }
NetworkReachedEvent FROM CSTA-network-reached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) network-reached-event( 30) }
OriginatedEvent FROM CSTA-originated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) originated-event( 31) }
QueuedEvent FROM CSTA-queued-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) queued-event( 32) }
RetrievedEvent FROM CSTA-retrieved-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) retrieved-event( 33) }
ServiceInitiatedEvent FROM CSTA-service-initiated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) service-initiated-event( 34) }
TransferredEvent FROM CSTA-transferred-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) transferred-event( 35) }
AutoAnswerEvent FROM CSTA-auto-answer-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) auto-answer-event( 40) }
CallInformationEvent FROM CSTA-call-information-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-information-event( 41) }
DoNotDisturbEvent FROM CSTA-do-not-disturb-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) do-not-disturb-event( 42) }
ForwardingEvent FROM CSTA-forwarding-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) forwarding-event( 43) }
MessageWaitingEvent FROM CSTA-message-waiting-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) message-waiting-event( 44) }
```

```
MicrophoneMuteEvent FROM CSTA-microphone-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-mute-event( 45) }
SpeakerMuteEvent FROM CSTA-speaker-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-mute-event( 46) }
SpeakerVolumeEvent FROM CSTA-speaker-volume-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-volume-event( 47) }
AgentBusyEvent FROM CSTA-agent-busy-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-busy-event( 56) }
AgentLoggedOnEvent FROM CSTA-logged-on-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) logged-on-event( 51) }
AgentLoggedOffEvent FROM CSTA-logged-off-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) logged-off-event( 52) }
AgentNotReadyEvent FROM CSTA-not-ready-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) not-ready-event( 53) }
AgentReadyEvent FROM CSTA-ready-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) ready-event( 54) }
AgentWorkingAfterCallEvent FROM CSTA-working-after-call-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) working-after-call-event( 55) }
BackInServiceEvent FROM CSTA-back-in-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) back-in-service-event( 61) }
OutOfServiceEvent FROM CSTA-out-of-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) out-of-service-event( 62) }
PrivateEvent FROM CSTA-private-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) private-event( 71) }
PlayEvent FROM CSTA-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) play( 75) }
RecordEvent FROM CSTA-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) record( 76) }
ReviewEvent FROM CSTA-review-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) review( 77) }
StopEvent FROM CSTA-stop-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop( 78) }
SuspendPlayEvent FROM CSTA-suspend-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-play( 79) }
SuspendRecordEvent FROM CSTA-suspend-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-record( 80) }
VoiceAttributesChangeEvent FROM CSTA-voice-attributes-change-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) voice-attributes-change-event( 74) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
BridgedEvent FROM CSTA-bridged-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) bridged-event( 224) }
DigitsDialedEvent FROM CSTA-digits-dialed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
```

```

        standard( 0) csta3( 285) digits-dialed-event( 225) }
NetworkCapabilitiesChangedEvent FROM CSTA-network-capabilities-changed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) network-capabilities-changed-event( 226) }
OfferedEvent FROM CSTA-offered-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) offered-event( 227) }
ChargingEvent FROM CSTA-charging-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) charging-event( 240) }
DigitsGeneratedEvent FROM CSTA-digits-generated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) digits-generated-event( 241) }
TelephonyTonesGeneratedEvent FROM CSTA-telephony-tones-generated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) telephony-tones-generated-event( 242) }
ServiceCompletionFailureEvent FROM CSTA-service-completion-failure-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) service-completion-failure-event( 243) }
MediaAttachedEvent FROM CSTA-media-attached-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-attached-event( 246) }
MediaDetachedEvent FROM CSTA-media-detached-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-detached-event( 247) }
ButtonInformationEvent FROM CSTA-button-information-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-information-event( 283) }
ButtonPressEvent FROM CSTA-button-press-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-press-event( 284) }
DisplayUpdatedEvent FROM CSTA-display-updated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) display-updated-event( 285) }
HookswitchEvent FROM CSTA-hookswitch-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) hookswitch-event( 286) }
LampModeEvent FROM CSTA-lamp-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) lamp-mode-event( 287) }
MicrophoneGainEvent FROM CSTA-microphone-gain-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-gain-event( 288) }
RingerStatusEvent FROM CSTA-ringer-status-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) ringer-status-event( 289) }
AutoWorkModeEvent FROM CSTA-auto-work-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) auto-work-mode-event( 326) }
CallBackEvent FROM CSTA-call-back-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-back-event( 327) }
CallBackMessageEvent FROM CSTA-call-back-message-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-back-message-event( 328) }
CallerIDStatusEvent FROM CSTA-caller-id-status-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) caller-id-status-event( 329) }
RouteingModeEvent FROM CSTA-routeing-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) routeing-mode-event( 332) }
DeviceCapsChangedEvent FROM CSTA-device-capabilities-changed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-capabilities-changed-event( 334) }
;

cSTAEventReport      OPERATION ::=
{
    ARGUMENT          CSTAEventReportArgument

```

```

        ALWAYS RESPONDS      FALSE
        CODE                  local:21
    }

CSTAEventReportArgument ::= SEQUENCE
{
    crossRefIdentifier      MonitorCrossRefID,
    eventSpecificInfo      EventSpecificInfo,
    extensions              CSTACommonArguments OPTIONAL}

EventSpecificInfo ::= CHOICE
{
    callControlEvents      [0] CallControlServAndEvents,
    callAssociatedEvents    [1] CallAssociationEvents,
    mediaAttachmentEvents  [2] MediaAttachmentEvents,
    physicalDeviceEvents    [3] PhysicalDeviceEvents,
    logicalDeviceEvents     [4] LogicalDeviceEvents,
    deviceMaintenanceEvents [5] DeviceMaintenanceEvents,
    voiceUnitEvents         [6] VoiceUnitEvents,
    vendorSpecEvents        [7] VendorSpecEvents}

CallControlEvents ::= CHOICE
{
    bridged                  [ 0] IMPLICIT BridgedEvent,
    callCleared              [ 1] IMPLICIT CallClearedEvent,
    conferenced              [ 2] IMPLICIT ConferencedEvent,
    connectionCleared        [ 3] IMPLICIT ConnectionClearedEvent,
    delivered                [ 4] IMPLICIT DeliveredEvent,
    digitsDialed             [ 5] IMPLICIT DigitsDialedEvent,
    diverted                 [ 6] IMPLICIT DivertedEvent,
    established              [ 7] IMPLICIT EstablishedEvent,
    failed                   [ 8] IMPLICIT FailedEvent,
    held                     [ 9] IMPLICIT HeldEvent,
    networkCapabilitiesChanged [10] IMPLICIT NetworkCapabilitiesChangedEvent,
    networkReached           [11] IMPLICIT NetworkReachedEvent,
    offered                  [12] IMPLICIT OfferedEvent,
    originated               [13] IMPLICIT OriginatedEvent,
    queued                   [14] IMPLICIT QueuedEvent,
    retrieved                [15] IMPLICIT RetrievedEvent,
    serviceInitiated         [16] IMPLICIT ServiceInitiatedEvent,
    transferred              [17] IMPLICIT TransferredEvent}

CallAssociatedEvents ::= CHOICE
{
    callInformation          [ 0] IMPLICIT CallInformationEvent,
    charging                 [ 1] IMPLICIT ChargingEvent,
    digitsGeneratedEvent     [ 2] IMPLICIT DigitsGeneratedEvent,
    telephonyTonesGeneratedEvent [ 3] IMPLICIT TelephonyTonesGeneratedEvent,
    serviceCompletionFailure [ 4] IMPLICIT ServiceCompletionFailureEvent}

MediaAttachmentEvents ::= CHOICE
{
    mediaAttached            [ 0] IMPLICIT MediaAttachedEvent,
    mediaDetached           [ 1] IMPLICIT MediaDetachedEvent}

PhysicalDeviceFeatureEvents ::= CHOICE
{
    buttonInformation        [ 0] IMPLICIT ButtonInformationEvent,
    buttonPress              [ 1] IMPLICIT ButtonPressEvent,
    displayUpdated           [ 2] IMPLICIT DisplayUpdatedEvent,
    hookswitch               [ 3] IMPLICIT HookswitchEvent,
    lampMode                 [ 4] IMPLICIT LampModeEvent,
    messageWaiting           [ 5] IMPLICIT MessageWaitingEvent,
    microphoneGain           [ 6] IMPLICIT MicrophoneGainEvent,
    microphoneMute           [ 7] IMPLICIT MicrophoneMuteEvent,
    ringerStatus             [ 8] IMPLICIT RingerStatusEvent,
    speakerMute              [ 9] IMPLICIT SpeakerMuteEvent,
    speakerVolume            [10] IMPLICIT SpeakerVolumeEvent}

LogicalDeviceFeatureEvents ::= CHOICE
{
    agentBusy                [ 0] IMPLICIT AgentBusyEvent,
    agentLoggedOn            [ 1] IMPLICIT AgentLoggedOnEvent,
    agentLoggedOff           [ 2] IMPLICIT AgentLoggedOffEvent,
}
```

```
agentNotReady      [ 3] IMPLICIT AgentNotReadyEvent,
agentReady         [ 4] IMPLICIT AgentReadyEvent,
agentWorkingAfterCall [ 5] IMPLICIT AgentWorkingAfterCallEvent,
autoAnswer        [ 6] IMPLICIT AutoAnswerEvent,
autoWorkMode      [ 7] IMPLICIT AutoWorkModeEvent,
callBack          [ 8] IMPLICIT CallBackEvent,
callBackMessage    [ 9] IMPLICIT CallBackMessageEvent,
callerIDStatus     [10] IMPLICIT CallerIDStatusEvent,
doNotDisturb      [11] IMPLICIT DoNotDisturbEvent,
forwarding         [12] IMPLICIT ForwardingEvent,
routeingMode       [13] IMPLICIT RouteingModeEvent}

DeviceMaintenanceEvents ::= CHOICE
{
    backInService      [ 0] IMPLICIT BackInServiceEvent,
    deviceCapabilityChanged [ 1] IMPLICIT DeviceCapsChangedEvent,
    outOfService       [ 2] IMPLICIT OutOfServiceEvent}

VoiceUnitEvents ::= CHOICE
{
    play              [ 0] IMPLICIT PlayEvent,
    record            [ 1] IMPLICIT RecordEvent,
    review            [ 2] IMPLICIT ReviewEvent,
    stop              [ 3] IMPLICIT StopEvent,
    suspendPlay       [ 4] IMPLICIT SuspendPlayEvent,
    suspendRecord     [ 5] IMPLICIT SuspendRecordEvent,
    voiceAttributesChange [ 6] IMPLICIT VoiceAttributesChangeEvent}

VendorSpecEvents ::= CHOICE
{
    privateEvent      [ 0] IMPLICIT PrivateEvent}

END -- of CSTA-event-report-definitions
```

11 Capability exchange services

11.1 Services

11.1.1 Get logical device information

```
CSTA-get-logical-device-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-logical-device-information( 201) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorFilter, MonitorMediaClass FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, ACDModels, AgentLogOnModels,
  AppearanceType, MiscMonitorCaps, TransAndConfSetup, MediaServiceCapsList,
  RouteingServList, LogDevServList, LogDevEvtsList
FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) }
NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList
FROM CSTA-data-call-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-call-types( 134) };

getLogicalDeviceInformation OPERATION ::=
{
  ARGUMENT    GetLogicalDeviceInformationArgument
  RESULT      GetLogicalDeviceInformationResult
  ERRORS      {universalFailure}
  CODE        local:201
}

GetLogicalDeviceInformationArgument ::= SEQUENCE
{
  device          DeviceID,
  extensions      CSTACommonArgumentsOPTIONAL}

GetLogicalDeviceInformationResult ::= SEQUENCE
{
  deviceCategory          [ 0] IMPLICIT DeviceCategory          DEFAULT station,
  groupDeviceAttributes   [ 1] IMPLICIT GroupDeviceAttributes OPTIONAL,
  namedDeviceTypes        [ 2] IMPLICIT NamedDeviceTypes        OPTIONAL,
  shortFormDeviceID       [ 3] DeviceID                          OPTIONAL,
  hasPhysicalElement      BOOLEAN,
  acdModels               ACDModels,
  agentLogOnModels        [ 4] IMPLICIT AgentLogOnModels        OPTIONAL,
  appearanceAddressable   BOOLEAN,
  appearanceType          AppearanceType,
  appearanceList          [ 5] IMPLICIT SEQUENCE OF IA5String OPTIONAL,
  otherPhysicalDeviceList [ 6] IMPLICIT SEQUENCE OF DeviceID OPTIONAL,
  miscMonitorCaps         [ 7] IMPLICIT MiscMonitorCaps         OPTIONAL,
  associatedGroupList     [ 8] IMPLICIT SEQUENCE OF DeviceID OPTIONAL,
  maxCallbacks            [ 9] IMPLICIT INTEGER                  OPTIONAL,
  maxAutoAnswerRings     [10] IMPLICIT INTEGER                  OPTIONAL,
  maxActiveCalls          [11] IMPLICIT INTEGER                  OPTIONAL,
```

maxHeldCalls	[12]	IMPLICIT INTEGER	OPTIONAL,
maxFwdSettings	[13]	IMPLICIT INTEGER	OPTIONAL,
maxDevicesInConf	[14]	IMPLICIT INTEGER	OPTIONAL,
transAndConfSetup	[15]	IMPLICIT TransAndConfSetup	OPTIONAL,
deviceOnDeviceMonitorFilter	[16]	IMPLICIT MonitorFilter	OPTIONAL,
deviceOnConnectionMonitorFilter	[17]	IMPLICIT MonitorFilter	OPTIONAL,
callOnDeviceMonitorFilter	[18]	IMPLICIT MonitorFilter	OPTIONAL,
callOnConnectionMonitorFilter	[19]	IMPLICIT MonitorFilter	OPTIONAL,
mediaClassSupport	[20]	IMPLICIT MonitorMediaClass	OPTIONAL,
mediaServiceCapsList	[21]	IMPLICIT MediaServiceCapsList	OPTIONAL,
connectionRateList	[22]	IMPLICIT ConnectionRateList	OPTIONAL,
delayToleranceList	[23]	IMPLICIT DelayToleranceList	OPTIONAL,
numberOfChannels	[24]	IMPLICIT NumberOfChannels	OPTIONAL,
maxChannelBind	[25]	IMPLICIT MaxChannelBind	OPTIONAL,
routeingServList	[26]	IMPLICIT RouteingServList	OPTIONAL,
logDevServList	[27]	IMPLICIT LogDevServList	OPTIONAL,
logDevEvtsList	[28]	IMPLICIT LogDevEvtsList	OPTIONAL,
extensions		CSTACommonArguments	OPTIONAL}

-- The parameters groupDeviceAttributes, agentLogOnModels, appearanceList,
-- otherPhysicalDeviceList, associatedGroupList, deviceOnDeviceMonitorFilter,
-- deviceOnConnectionMonitorFilter,
-- callOnDeviceMonitorFilter, callOnConnectionMonitorFilter, routeingServList, logDevServList and
-- logDevEvtsList are conditional. Refer to ECMA 269, 13.1.1 for conditions.

END -- of CSTA-get-logical-device-information

11.1.2 Get physical device information

```
CSTA-get-physical-device-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-physical-device-information( 202) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorFilter FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, PhysDevServList, PhysDevEvtsList
FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

getPhysicalDeviceInformation OPERATION ::=
{
  ARGUMENT    GetPhysicalDeviceInformationArgument
  RESULT      GetPhysicalDeviceInformationResult
  ERRORS      {universalFailure}
  CODE        local:202
}

GetPhysicalDeviceInformationArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments    OPTIONAL}

GetPhysicalDeviceInformationResult ::= SEQUENCE
{
  deviceCategory      [ 0] IMPLICIT DeviceCategory      DEFAULT sta-
tion,
  groupDeviceAttributes      [ 1] IMPLICIT GroupDeviceAttributes    OPTIONAL,
  namedDeviceTypes           [ 2] IMPLICIT NamedDeviceTypes         OPTIONAL,
  hasLogicalElement          BOOLEAN,
  otherLogicalDeviceList     [ 3] IMPLICIT SEQUENCE OF DeviceID     OPTIONAL,
  deviceModelName            [ 4] IMPLICIT IA5String (SIZE(0..64))   OPTIONAL,
  deviceOnDeviceMonitorFilter [ 5] IMPLICIT MonitorFilter           OPTIONAL,
  deviceOnConnectionMonitorFilter [ 6] IMPLICIT MonitorFilter        OPTIONAL,
  callOnDeviceMonitorFilter   [ 7] IMPLICIT MonitorFilter           OPTIONAL,
  callOnConnectionMonitorFilter [ 8] IMPLICIT MonitorFilter          OPTIONAL,
  maxDisplays                [ 9] IMPLICIT INTEGER                 OPTIONAL,
  maxButtons                 [10] IMPLICIT INTEGER                 OPTIONAL,
  maxLamps                   [11] IMPLICIT INTEGER                 OPTIONAL,
  maxRingPatterns            [12] IMPLICIT INTEGER                 OPTIONAL,
  physDevServList            [13] IMPLICIT PhysDevServList          OPTIONAL,
  physDevEvtsList            [14] IMPLICIT PhysDevEvtsList          OPTIONAL,
  extensions                  CSTACommonArguments                OPTIONAL}

-- The parameters groupDeviceAttributes, deviceOnDeviceMonitorFilter,
-- deviceOnConnectionMonitorFilter,
-- callOnDeviceMonitorFilter, callOnConnectionMonitorFilter, physDevServList and
-- physDevEvtsList are conditional. Refer to ECMA 269, 13.1.2 for conditions.

END -- of CSTA-get-physical-device-information
```


11.1.3 Get switching function capabilities

```
CSTA-get-switching-function-capabilities
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-switching-function-capabilities( 203) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
MonitorMediaClass, MonitorFilter FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
TimeInfo FROM CSTA-security
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) security( 128) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-control( 130) }
ACDModels, CapExchangeServList, DeviceIDFormat, FilterThreshold,
IgnoreUnsupportedParameters, CallControlServList, CallControlEvtsList,
CallAssociatedServList, CallAssociatedEvtsList, MediaServList, MediaEvtsList,
RouteingServList, PhysDevEvtsList, PhysDevServList, LogicalEvtsList, LogicalServList,
DeviceMaintEvtsList, IOServicesServList, DataCollectionServList, VoiceUnitServList,
VoiceUnitEvtsList, CDRServList, VendorSpecificServList, VendorSpecificEvtsList,
MaxLengthParameters, TransAndConfSetup, MediaServiceCapsList, MiscMonitorCaps,
MonitoringServList, PauseTime, SnapshotServList, SwAppearanceAddressability,
SwAppearanceTypes, SwDomainFeatures, SystemStatusServList, TimeStampMode
  FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) }
NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList
  FROM CSTA-data-call-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-call-types( 134) };

getSwitchingFunctionCapabilities OPERATION ::=
{
  ARGUMENT    GetSwitchingFunctionCapsArgument
  RESULT      GetSwitchingFunctionCapsResult
  ERRORS      {universalFailure}
  CODE        local:203
}

GetSwitchingFunctionCapsArgument ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

GetSwitchingFunctionCapsResult ::= SEQUENCE
{
  switchingSubDomainName      IA5String (SIZE(0..64)),
  manufacturerName            IA5String (SIZE(0..64)),
  profiles                     Profiles,
  deviceIDFormat               DeviceIDFormat,
  swDomainFeatures              SwDomainFeatures,
  swAppearanceAddressability    SwAppearanceAddressability,
  swAppearanceTypes             SwAppearanceTypes,
  ignoreUnsupportedParameters   IgnoreUnsupportedParameters,
  callCharacteristicsSupported  [0] IMPLICIT CallCharacteristics      OPTIONAL,
  mediaClassSupport             [1] IMPLICIT MonitorMediaClass        OPTIONAL,
  numberOfChannels              [2] IMPLICIT NumberOfChannels          OPTIONAL,
```

maxChannelBind	[3] IMPLICIT MaxChannelBind	OPTIONAL,
miscMediaCallCharacteristics	[4] IMPLICIT MiscMediaCallCharacteristics	OPTIONAL,
connectionRateList	[5] IMPLICIT ConnectionRateList	OPTIONAL,
delayToleranceList	[6] IMPLICIT DelayToleranceList	OPTIONAL,
pauseTime	[7] IMPLICIT PauseTime	OPTIONAL,
currentTime	[8] IMPLICIT TimeInfo	OPTIONAL,
messageSeqNumbers	[9] IMPLICIT MessageSeqNumbers	OPTIONAL,
timeStampMode	[10] IMPLICIT TimeStampMode	OPTIONAL,
securityMode	[11] IMPLICIT SecurityMode	OPTIONAL,
securityFormat	[12] IMPLICIT SecurityFormat	OPTIONAL,
privateDataFormat	[13] IMPLICIT SecurityFormat	OPTIONAL,
transAndConfSetup	[14] IMPLICIT TransAndConfSetup	OPTIONAL,
monitorFilterItems	[15] IMPLICIT MonitorFilterItems	OPTIONAL,
miscMonitorCaps	[16] IMPLICIT MiscMonitorCaps	OPTIONAL,
correlatorDataSupported	[17] IMPLICIT BOOLEAN	OPTIONAL,
dynamicFeatureSupported	[18] IMPLICIT DynamicFeatureSupported	OPTIONAL,
aCDModels	[19] IMPLICIT ACDModels	OPTIONAL,
agentLogOnModels	[20] IMPLICIT AgentLogOnModels	OPTIONAL,
agentStateModels	[21] IMPLICIT AgentStateModels	OPTIONAL,
connectionView	ConnectionView,	
maxLengthParameters	MaxLengthParameters,	
servEvsList	[22] IMPLICIT ServEvsList	OPTIONAL,
privateDataVersionList	[23] IMPLICIT PrivateDataVersionList	OPTIONAL,
systemStatusTimer	[24] IMPLICIT INTEGER (0..180)	OPTIONAL,
simpleThreshold	[25] IMPLICIT INTEGER	OPTIONAL,
filterThreshold	[26] IMPLICIT FilterThreshold	OPTIONAL,
mediaServiceCapsList	[27] IMPLICIT MediaServiceCapsList	OPTIONAL,
extensions	CSTACCommonArguments	OPTIONAL}

MonitorFilterItems ::= SEQUENCE

{	deviceOnDeviceMonitorFilter	[0] IMPLICIT MonitorFilter	OPTIONAL,
	deviceOnConnectionMonitorFilter	[1] IMPLICIT MonitorFilter	OPTIONAL,
	callOnDeviceMonitorFilter	[2] IMPLICIT MonitorFilter	OPTIONAL,
	callOnConnectionMonitorFilter	[3] IMPLICIT MonitorFilter	OPTIONAL}

MessageSeqNumbers ::= BIT STRING

{	allEvents	(0),
	allAcks	(1),
	allServReqs	(2)}

SecurityMode ::= ENUMERATED

{	allEvents	(0),
	allAcks	(1),
	allServReqs	(2)}

SecurityFormat ::= BIT STRING

{	octetStringFromSF	(0),
	otherTypeFromSF	(1),
	octetStringToSF	(2),
	otherTypeToSF	(3)}

Profiles ::= BIT STRING

{	basicTelephonyProfile	(0),
	routeingProfile	(1)}

DynamicFeatureSupported ::= ENUMERATED

{	none	(0),
	all	(1),
	some	(2)}

AgentLogOnModels ::= BIT STRING

{	logOnACDDevice	(0),
	logOnACDGroupExplOneStep	(1),
	logOnACDGroupExplTwoSteps	(2),
	logOnACDGroupImplOneStep	(3)}

AgentStateModels ::= BIT STRING

```
{
    multiState                (0),
    multiStateSemiIndependentLinked (1),
    agentOriented              (2)}

ConnectionView ::= ENUMERATED
{
    fixed      (0),
    local      (1)}

ServEvsList ::= SEQUENCE
{
    capExchangeServList [ 0] IMPLICIT CapExchangeServList      OPTIONAL,
    systemServList      [ 1] IMPLICIT SystemStatusServList     OPTIONAL,
    monitoringServList  [ 2] IMPLICIT MonitoringServList        OPTIONAL,
    snapshotServList    [ 3] IMPLICIT SnapshotServList          OPTIONAL,
    callControlServList [ 4] IMPLICIT CallControlServList        OPTIONAL,
    callControlEvsList  [ 5] IMPLICIT CallControlEvsList         OPTIONAL,
    callAssociatedServList [ 6] IMPLICIT CallAssociatedServList   OPTIONAL,
    callAssociatedEvsList [ 7] IMPLICIT CallAssociatedEvsList     OPTIONAL,
    mediaServList       [ 8] IMPLICIT MediaServList              OPTIONAL,
    mediaEvsList        [ 9] IMPLICIT MediaEvsList               OPTIONAL,
    routeingServList    [10] IMPLICIT RouteingServList           OPTIONAL,
    physDevServList     [11] IMPLICIT PhysDevServList            OPTIONAL,
    physDevEvsList      [12] IMPLICIT PhysDevEvsList             OPTIONAL,
    logicalServList     [13] IMPLICIT LogicalServList            OPTIONAL,
    logicalEvsList      [14] IMPLICIT LogicalEvsList             OPTIONAL,
    deviceMaintEvsList  [15] IMPLICIT DeviceMaintEvsList         OPTIONAL,
    iOServicesServList [16] IMPLICIT IOServicesServList          OPTIONAL,
    dataCollectionServList [17] IMPLICIT DataCollectionServList   OPTIONAL,
    voiceUnitServList   [18] IMPLICIT VoiceUnitServList          OPTIONAL,
    voiceUnitEvsList    [19] IMPLICIT VoiceUnitEvsList           OPTIONAL,
    cdrServList         [20] IMPLICIT CDRServList                OPTIONAL,
    vendorSpecificServList [21] IMPLICIT VendorSpecificServList   OPTIONAL,
    vendorSpecificEvsList [22] IMPLICIT VendorSpecificEvsList     OPTIONAL}

StatusReportingServList ::= SEQUENCE
{
    monitoringServices [ 0] IMPLICIT MonitoringServList OPTIONAL,
    snapshotServices  [ 1] IMPLICIT SnapshotServList  OPTIONAL,
    systemServices    [ 2] IMPLICIT SystemStatusServList OPTIONAL}

MiscMediaCallCharacteristics ::= BIT STRING
{
    supportAdjustment (0) }

PrivateDataVersionList ::= SEQUENCE OF INTEGER

END -- of CSTA-get-switching-function-capabilities
```

11.1.4 Get switching function devices

```
CSTA-get-switching-function-devices
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-switching-function-devices( 204) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

getSwitchingFunctionDevices OPERATION ::=
{
  ARGUMENT    GetSwitchingFunctionDevicesArgument
  RESULT      GetSwitchingFunctionDevicesResult
  ERRORS      {universalFailure}
  CODE        local:204
}

GetSwitchingFunctionDevicesArgument ::= SEQUENCE
{
  requestedDeviceID          DeviceID          OPTIONAL,
  requestedDeviceCategory    ReqDeviceCategory OPTIONAL,
  extensions                 CSTACCommonArguments OPTIONAL}

GetSwitchingFunctionDevicesResult ::= SEQUENCE
{
  serviceCrossRefID          ServiceCrossRefID,
  extensions                 CSTACCommonArguments OPTIONAL}

ReqDeviceCategory ::= ENUMERATED
{
  acd                        ( 0),
  groupACD                   ( 1),
  groupHunt                   ( 2),
  groupPick                   ( 3),
  groupOther                  ( 4),
  networkInterface           ( 5),
  park                        ( 6),
  routeingDevice              ( 7),
  station                     ( 8),
  voiceUnit                   ( 9),
  other                       (10)}

END -- of CSTA-get-switching-function-devices
```

11.1.5 Switching function devices

```
CSTA-switching-function-devices
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-devices( 205) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID, DeviceCategory, NamedDeviceTypes FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

switchingFunctionDevices OPERATION ::=
{
  ARGUMENT      SwitchingFunctionDevicesArgument
  ERRORS        {universalFailure}
  CODE          local:205
}

SwitchingFunctionDevicesArgument ::= SEQUENCE
{
  serviceCrossRefID      ServiceCrossRefID,
  segmentID              INTEGER              OPTIONAL,
  lastSegment            BOOLEAN,
  deviceList             DeviceList,
  extensions             CSTACommonArguments OPTIONAL}

DeviceList ::= SEQUENCE OF SEQUENCE
{
  deviceID      DeviceID,
  deviceCategory [0] IMPLICIT DeviceCategory      DEFAULT station,
  namedDeviceTypes [1] IMPLICIT NamedDeviceTypes  OPTIONAL,
  deviceAttributes DeviceAttributes                OPTIONAL,
  deviceName      IA5String (SIZE(0..64))         OPTIONAL}

DeviceAttributes ::= BIT STRING
{
  mediaAccessDevice ( 0),
  routeingDevice    ( 1),
  groupACD          ( 2),
  groupHunt         ( 3),
  groupPick         ( 4)}

END -- of CSTA-switching-function-devices
```

12 System services

12.1 Registration services

12.1.1 Change system status filter

```
CSTA-change-system-status-filter
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) change-system-status-filter( 206) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

changeSysStatFilter OPERATION ::=
{
    ARGUMENT      ChangeSysStatFilterArg
    RESULT        ChangeSysStatFilterRes
    ERRORS        {universalFailure}
    CODE          local: 206
}

ChangeSysStatFilterArg ::= SEQUENCE
{
    sysStatRegisterID      SysStatRegisterID,
    requestedStatusFilter   SystemStatus,
    extensions              CSTACommonArguments      OPTIONAL}

ChangeSysStatFilterRes ::= SEQUENCE
{
    actualStatusFilter       SystemStatus,
    extensions              CSTACommonArguments      OPTIONAL}

END -- of CSTA-change-system-status-filter
```

12.1.2 System register

```
CSTA-system-register
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-register( 207) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

systemRegister OPERATION ::=
{
  ARGUMENT      SystemRegisterArgument
  RESULT        SystemRegisterResult
  ERRORS        {universalFailure}
  CODE          local: 207
}

SystemRegisterArgument ::= SEQUENCE
{
  requestTypes      RequestTypes,
  requestedStatusFilter  StatusFilter          OPTIONAL,
  extensions        CSTACommonArguments      OPTIONAL}

SystemRegisterResult ::= SEQUENCE
{
  sysStatRegisterID  SysStatRegisterID,
  actualStatusFilter  StatusFilter          OPTIONAL,
  extensions          CSTACommonArguments  OPTIONAL}

StatusFilter ::= BIT STRING
{
  initializing      ( 0),
  enabled           ( 1),
  normal            ( 2),
  messageLost       ( 3),
  disabled          ( 4),
  partiallyDisabled ( 5),
  overloadImminent  ( 6),
  overloadReached   ( 7),
  overloadRelieved  ( 8)}

RequestTypes ::= BIT STRING
{
  systemStatus      (0),
  requestSystemStatus (1)}

-- The parameters requestedStatusFilter and actualStatusFilter are
-- conditional. Refer to ECMA 269, 14.1.2 for conditions

END -- of CSTA-system-register
```

12.1.3 System register abort

```
CSTA-system-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) system-register-abort( 208) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

systemRegisterAbort OPERATION ::=
{
    ARGUMENT          SystemRegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 208
}

SystemRegisterAbortArgument ::= SEQUENCE
{
    sysStatRegisterID  SysStatRegisterID,
    extensions         CSTACommonArguments    OPTIONAL}

END -- of CSTA-system-register-abort
```


12.1.4 System register cancel

```
CSTA-system-register-cancel
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-register-cancel( 209) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
;

systemRegisterCancel OPERATION ::=
{
  ARGUMENT      SystemRegisterCancelArgument
  RESULT        SystemRegisterCancelResult
  ERRORS        {universalFailure}
  CODE          local: 209
}

SystemRegisterCancelArgument ::= SEQUENCE
{
  sysStatRegisterID      SysStatRegisterID,
  extensions              CSTACCommonArguments      OPTIONAL}

SystemRegisterCancelResult ::= CHOICE
{
  extensions      CSTACCommonArguments,
  noData          NULL}

END -- of CSTA-system-register-cancel
```

12.2 Services

12.2.1 Request system status

```
CSTA-request-system-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) request-system-status( 210) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

requestSysStat OPERATION ::=
{
  ARGUMENT      RequestSysStatArg
  RESULT        RequestSysStatRes
  ERRORS        {universalFailure}
  CODE          local: 210
}

RequestSysStatArg ::= SEQUENCE
{
  sysStatRegisterID      SysStatRegisterID      OPTIONAL,
  extensions              CSTACommonArguments    OPTIONAL}

RequestSysStatRes ::= SEQUENCE
{
  systemStatus            SystemStatus,
  extensions              CSTACommonArguments    OPTIONAL}

-- The parameter sysStatRegisterID is conditional. Refer to ECMA 269, clause
-- 14.2.1 for conditions.

END -- of CSTA-request-system-status
```

12.2.2 System status

```
CSTA-system-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-status( 211) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

systemStatus OPERATION ::=
{
  ARGUMENT      SystemStatusArg
  RESULT        SystemStatusRes
  ERRORS        {universalFailure}
  CODE          local: 211
}

SystemStatusArg ::= SEQUENCE
{
  sysStatRegisterID      SysStatRegisterID      OPTIONAL,
  systemStatus           SystemStatus,
  extensions             CSTACCommonArguments   OPTIONAL}

SystemStatusRes ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData     NULL}

END -- of CSTA-system-status
```

12.2.3 Switching function capabilities changed

```
CSTA-switching-function-capabilities-changed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-capabilities-changed( 212) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

swFunctionCapsChanged OPERATION ::=
{
  ARGUMENT      SwFunctionCapsChangedArg
  RESULT        SwFunctionCapsChangedRes
  ERRORS        {universalFailure}
  CODE          local: 212
}

SwFunctionCapsChangedArg ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

SwFunctionCapsChangedRes ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-switching-function-capabilities-changed
```

12.2.4 Switching function devices changed

```
CSTA-switching-function-devices-changed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-devices-changed( 213) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

swFunctionDevicesChanged OPERATION ::=
{
  ARGUMENT      SwFunctionDevicesChangedArg
  RESULT        SwFunctionDevicesChangedRes
  ERRORS        {universalFailure}
  CODE          local: 213
}

SwFunctionDevicesChangedArg ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

SwFunctionDevicesChangedRes ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-switching-function-devices-changed
```

13 Monitoring services

13.1 Services

13.1.1 Change monitor filter

```
CSTA-change-monitor-filter
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) change-monitor-filter( 102) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorFilter, MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

changeMonitorFilter      OPERATION ::=
{
    ARGUMENT      ChangeMonitorFilterArgument
    RESULT        ChangeMonitorFilterResult
    ERRORS        {universalFailure}
    CODE          local: 72
}

ChangeMonitorFilterArgument ::=
SEQUENCE
{crossRefIdentifier      MonitorCrossRefID,
 requestedFilterList      MonitorFilter,
 extensions               CSTACommonArguments      OPTIONAL}

ChangeMonitorFilterResult ::=
SEQUENCE
{actualFilterList        MonitorFilter      OPTIONAL,
 extensions              CSTACommonArguments      OPTIONAL}

-- The actualFilterList is optional, if it is identical to the
-- requestedFilterList on the service request, otherwise it is mandatory.

END -- of CSTA-change-monitor-filter
```

13.1.2 Monitor start

```
CSTA-monitor-start
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) monitor-start( 101) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorObject, MonitorFilter, MonitorType, MonitorMediaClass,
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

monitorStart      OPERATION ::=
{
    ARGUMENT      MonitorStartArgument
    RESULT        MonitorStartResult
    ERRORS        { universalFailure }
    CODE          local: 71
}

MonitorStartArgument ::= SEQUENCE
{
    monitorObject          MonitorObject,
    requestedMonitorFilter [0] IMPLICIT MonitorFilter      OPTIONAL,
    monitorType            MonitorType                      OPTIONAL,
    requestedMonitorMediaClass [1] IMPLICIT MonitorMediaClass OPTIONAL,
    extensions             CSTACCommonArguments            OPTIONAL}

MonitorStartResult ::= SEQUENCE
{
    crossRefIdentifier      MonitorCrossRefID,
    actualmonitorFilter     [0] IMPLICIT MonitorFilter      OPTIONAL,
    actualMonitorMediaClass [1] IMPLICIT MonitorMediaClass  OPTIONAL,
    monitorExistingCalls    BOOLEAN                       OPTIONAL,
    extensions              CSTACCommonArguments            OPTIONAL}

END -- of CSTA-monitor-start
```

13.1.3 Monitor stop

```
CSTA-monitor-stop
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) monitor-stop( 103) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

monitorStop      OPERATION ::=
{
    ARGUMENT      MonitorStopArgument
    RESULT        MonitorStopResult
    ERRORS        {universalFailure}
    CODE          local: 73
}

MonitorStopArgument ::=
    SEQUENCE
    {crossRefIdentifier      MonitorCrossRefID,
     extensions              CSTACCommonArguments      OPTIONAL}

MonitorStopResult ::=
    CHOICE
    {extensions              CSTACCommonArguments,
     noData                  NULL}

END -- of CSTA-monitor-stop
```


14 Snapshot services

14.1 Services

14.1.1 Snapshot call

```
CSTA-snapshot-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) snapshot-call( 105) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CallingDeviceID, CalledDeviceID, AssociatedCallingDeviceID,
AssociatedCalledDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
SnapshotCallData FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
ServiceCrossRefID FROM CSTA-capability-exchange
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) capability-exchange( 131) }
MediaCallCharacteristics FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

snapshotCall      OPERATION ::=
{
    ARGUMENT      SnapshotCallArgument
    RESULT        SnapshotCallResult
    ERRORS        {universalFailure}
    CODE          local: 75
}

SnapshotCallArgument ::=
SEQUENCE
{snapshotObject      ConnectionID,
 extensions          CSTACCommonArguments OPTIONAL}

SnapshotCallResult ::=
SEQUENCE
{CHOICE
    {serviceCrossRefID [0] IMPLICIT ServiceCrossRefID,
     snapshotData      SnapshotCallData},
 mediaCallCharacteristics MediaCallCharacteristics OPTIONAL,
 callCharacteristics    CallCharacteristics OPTIONAL,
 callingDevice          CallingDeviceID OPTIONAL,
 calledDevice           CalledDeviceID OPTIONAL,
 associatedCallingDeviceID AssociatedCallingDeviceID OPTIONAL,
 associatedCalledDeviceID AssociatedCalledDeviceID OPTIONAL,
 correlatorData         [1] IMPLICIT CorrelatorData OPTIONAL,
 extensions             CSTACCommonArguments OPTIONAL}
```

```
-- The parameters associatedCallingDeviceID, associatedCalledDeviceID and correlatorData  
-- are conditional. Refer to ECMA 269, 16.1.1 for conditions.
```

```
END -- of CSTA-snapshot-call
```

14.1.2 Snapshot device

```
CSTA-snapshot-device
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-device( 104) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM Device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
SnapshotDeviceData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotDevice OPERATION ::=
{
  ARGUMENT      SnapshotDeviceArgument
  RESULT        SnapshotDeviceResult
  ERRORS        {universalFailure}
  CODE          local: 74
}

SnapshotDeviceArgument ::=
SEQUENCE
{snapshotObject DeviceID,
 extensions      CSTACommonArguments      OPTIONAL}

SnapshotDeviceResult ::=
SEQUENCE
{CHOICE
  {serviceCrossRefID      ServiceCrossRefID,
   snapshotData           SnapshotDeviceData},
 extensions               CSTACommonArguments      OPTIONAL}

END -- of CSTA-snapshot-device
```

14.1.3 Snapshot calldata

```
CSTA-snapshot-call-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-call-data(106) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SnapshotCallData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotCallData      OPERATION ::=
{
  ARGUMENT          SnapshotCallDataArgument
  ERRORS            {universalFailure}
  ALWAYS RESPONDS   FALSE
  CODE              local: 76
}

SnapshotCallDataArgument ::=
SEQUENCE
{serviceCrossRefID   ServiceCrossRefID,
 segmentID           INTEGER              OPTIONAL,
 lastSegment         BOOLEAN,
 snapshotData        SnapshotCallData,
 extensions          CSTACommonArguments  OPTIONAL}
```

END -- of CSTA-snapshot-call-data

14.1.4 Snapshot devicedata

```
CSTA-snapshot-device-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-device-data(107) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SnapshotDeviceData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotDeviceData      OPERATION ::=
{
  ARGUMENT          SnapshotDeviceDataArgument
  ERRORS            {universalFailure}
  ALWAYS RESPONDS   FALSE
  CODE              local: 77
}

SnapshotDeviceDataArgument ::=
SEQUENCE
{serviceCrossRefID    ServiceCrossRefID,
 segmentID            INTEGER                OPTIONAL,
 lastSegment          BOOLEAN,
 snapshotData         SnapshotDeviceData,
 extensions           CSTACommonArguments    OPTIONAL}
```

END -- of CSTA-snapshot-device-data

15 Call control services and events

15.1 Services

15.1.1 Accept call

```
CSTA-accept-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) accept-call( 214) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

acceptCall OPERATION ::=
{
    ARGUMENT      AcceptCallArgument
    RESULT        AcceptCallResult
    ERRORS        {universalFailure}
    CODE          local: 214
}

AcceptCallArgument ::= SEQUENCE
    {
        callToBeAccepted      ConnectionID,
        correlatorData         CorrelatorData OPTIONAL,
        userData               UserData OPTIONAL,
        extensions              CSTACommonArguments OPTIONAL}

AcceptCallResult ::= CHOICE
    {
        extensions      CSTACommonArguments,
        noData          NULL}

END -- of CSTA-accept-call
```

15.1.2 Alternate call

```
CSTA-alternate-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) alternate-call( 1) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConsultOptions FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }

;

alternateCall      OPERATION ::=
{
    ARGUMENT      AlternateCallArgument
    RESULT        AlternateCallResult
    ERRORS        {universalFailure}
    CODE          local: 1
}

AlternateCallArgument ::= SEQUENCE
{
    heldCall      ConnectionID,
    activeCall    ConnectionID,
    connectionReservation    BOOLEAN                OPTIONAL,
    consultOptions    ConsultOptions                DEFAULT unrestricted,
    extensions      CSTACommonArguments            OPTIONAL}

AlternateCallResult ::=CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-alternate-call
```

15.1.3 Answer call

```
CSTA-answer-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) answer-call( 2) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

answerCall OPERATION ::=
{
    ARGUMENT    AnswerCallArgument
    RESULT      AnswerCallResult
    ERRORS      {universalFailure}
    CODE        local: 2
}

AnswerCallArgument ::=
    SEQUENCE
    {
        callToBeAnswered          ConnectionID,
        correlatorData             CorrelatorData
        userData                   UserData
        extensions                 CSTACommonArguments
    }

AnswerCallResult ::=
    CHOICE
    {extensions    CSTACommonArguments,
     noData        NULL}

END -- of CSTA-answer-call
```


15.1.4 Call back call-related

```
CSTA-call-back-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-call-related( 215) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-control( 130) };

callBack OPERATION ::=
{
  ARGUMENT    CallBackArgument
  RESULT      CallBackResult
  ERRORS      {universalFailure}
  CODE        local: 215
}

CallBackArgument ::=
  SEQUENCE
  {
    callbackConnection      ConnectionID,
    callCharacteristics      CallCharacteristics      OPTIONAL,
    extensions               CSTACommonArguments      OPTIONAL}

CallBackResult ::=
  SEQUENCE
  {
    targetDevice      DeviceID      OPTIONAL,
    -- mandatory, if the switching function supports
    -- the Cancel Call Back service
    extensions        CSTACommonArguments      OPTIONAL}

END -- of CSTA-call-back-call-related
```

15.1.5 Call back message call-related

```
CSTA-call-back-message-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-call-related( 216) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackMessage OPERATION ::=
{
  ARGUMENT    CallBackMessageArgument
  RESULT      CallBackMessageResult
  ERRORS      {universalFailure}
  CODE        local: 216
}

CallBackMessageArgument ::=
SEQUENCE
{
  callbackMessageConnection      ConnectionID,
  extensions                     CSTACommonArguments OPTIONAL}

CallBackMessageResult ::=
SEQUENCE
{
  targetDevice      DeviceID      OPTIONAL,
  -- mandatory, if the switching function supports
  -- the Cancel Call Back Message service
  extensions        CSTACommonArguments OPTIONAL}

END -- of CSTA-call-back-message-call-related
```

15.1.6 Camp on call

```

CSTA-camp-on-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) camp-on-call( 217) }

DEFINITIONS ::=
BEGIN
IMPORTS

OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

camponCall OPERATION ::=
{
    ARGUMENT      CamponCallArgument
    RESULT        CamponCallResult
    ERRORS        {universalFailure}
    CODE          local: 217
}

CamponCallArgument ::=
    SEQUENCE
    {
        camponConnection      ConnectionID,
        extensions             CSTACommonArguments      OPTIONAL}

CamponCallResult ::=
    CHOICE
    {
        extensions             CSTACommonArguments,
        noData                 NULL      }

END -- of CSTA-camp-on-call

```

15.1.7 Clear call

```
CSTA-clear-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) clear-call( 4) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

clearCall          OPERATION ::=
{
    ARGUMENT      ClearCallArgument
    RESULT        ClearCallResult
    ERRORS        {universalFailure}
    CODE          local: 4
}

ClearCallArgument ::=
    SEQUENCE
    {
        callToBeCleared ConnectionID,
        userData         UserData         OPTIONAL,
        extensions       CSTACommonArguments OPTIONAL}

ClearCallResult ::=
    CHOICE
    {extensions      CSTACommonArguments,
     noData          NULL}

END -- of CSTA-clear-call
```

15.1.8 Clear Connection

```

CSTA-clear-connection
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) clear-connection( 5) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

clearConnection OPERATION ::=
{
    ARGUMENT      ClearConnectionArgument
    RESULT        ClearConnectionResult
    ERRORS        {universalFailure}
    CODE          local: 5
}

ClearConnectionArgument ::=
SEQUENCE
{connectionToBeCleared  ConnectionID,
 correlatorData         CorrelatorData          OPTIONAL,
 userData              UserData                OPTIONAL,
 extensions             CSTACCommonArguments    OPTIONAL}

ClearConnectionResult ::=
CHOICE
{extensions             CSTACCommonArguments,
 noData                 NULL}

END -- of CSTA-clear-connection

```

15.1.9 Conference call

```
CSTA-conference-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) conference-call( 6) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

conferenceCall OPERATION ::=
{
  ARGUMENT    ConferenceCallArgument
  RESULT      ConferenceCallResult
  ERRORS      {universalFailure}
  CODE        local: 6
}

ConferenceCallArgument ::=
SEQUENCE
{
  heldCall      ConnectionID,
  activeCall    ConnectionID,
  extensions    CSTACommonArguments OPTIONAL}

ConferenceCallResult ::=
SEQUENCE
{
  conferenceCall      ConnectionID,
  connections         [0] IMPLICIT ConnectionList OPTIONAL,
  conferenceCallInfo  [1] IMPLICIT ConnectionInformation OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-conference-call
```

15.1.10 Consultation call

```
CSTA-consultation-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) consultation-call( 7) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ConsultOptions FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

consultationCall OPERATION ::=
{
  ARGUMENT ConsultationCallArgument
  RESULT ConsultationCallResult
  ERRORS {universalFailure}
  CODE local: 7
}

ConsultationCallArgument ::= SEQUENCE
{
  existingCall [0] IMPLICIT ConnectionID,
  consultedDevice [1] DeviceID,
  connectionReservation [2] IMPLICIT BOOLEAN OPTIONAL,
  accountCode [3] IMPLICIT AccountInfo OPTIONAL,
  authCode [4] IMPLICIT AuthCode OPTIONAL,
  correlatorData [5] IMPLICIT CorrelatorData OPTIONAL,
  userData [6] IMPLICIT UserData OPTIONAL,
  callCharacteristics [7] IMPLICIT CallCharacteristics OPTIONAL,
  mediaCallCharacteristics [8] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callingConnectionInfo [9] IMPLICIT ConnectionInformation OPTIONAL,
  consultOptions [10] IMPLICIT ConsultOptions DEFAULT unrestricted,
  extensions CSTACommonArguments OPTIONAL}

ConsultationCallResult ::= SEQUENCE
{
  initiatedCall ConnectionID,
  mediaCallCharacteristics [0] IMPLICIT MediaCallCharacteristics OPTIONAL,
  -- shall be provided, if the MediaCallCharacteristics have been
  -- adjusted
  initiatedCallInfo [1] IMPLICIT ConnectionInformation OPTIONAL,
  extensions CSTACommonArguments OPTIONAL}

END -- of CSTA-consultation-call
```

15.1.11 Deflect call

```
CSTA-deflect-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) deflect-call( 218) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

deflectCall    OPERATION ::=
{
    ARGUMENT    DeflectCallArgument
    RESULT      DeflectCallResult
    ERRORS      {universalFailure}
    CODE        local: 218
}

DeflectCallArgument ::=
SEQUENCE
{
    callToBeDiverted      ConnectionID,
    newDestination        DeviceID,
    correlatorData        CorrelatorData        OPTIONAL,
    userData              UserData              OPTIONAL,
    extensions            CSTACommonArguments    OPTIONAL}

DeflectCallResult ::=
CHOICE
{extensions      CSTACommonArguments,
 noData          NULL}

END -- of CSTA-deflect-call
```


15.1.12 Dial digits

```
CSTA-dial-digits
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) dial-digits( 219) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM Device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

dialDigits      OPERATION ::=
{
    ARGUMENT      DialDigitsArgument
    RESULT        DialDigitsResult
    ERRORS        {universalFailure}
    CODE          local: 219
}

DialDigitsArgument ::=
    SEQUENCE
    {
        diallingConnection          ConnectionID,
        diallingSequence             DeviceID,
        correlatorData               CorrelatorData          OPTIONAL,
        extensions                   CSTACommonArguments     OPTIONAL}

DialDigitsResult ::=
    CHOICE
    {extensions      CSTACommonArguments,
     noData          NULL}

END -- of CSTA-dial-digits
```

15.1.13 Directed pickup call

```
CSTA-directed-pickup-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) directed-pickup-call( 220) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

directedPickupCall      OPERATION ::=
{
  ARGUMENT    DirectedPickupCallArgument
  RESULT      DirectedPickupCallResult
  ERRORS      {universalFailure}
  CODE        local: 220
}

DirectedPickupCallArgument ::=
SEQUENCE
{
  callToBePickedUp      ConnectionID,
  requestingDevice       DeviceID,
  correlatorData         CorrelatorData      OPTIONAL,
  userData               UserData            OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

DirectedPickupCallResult ::=
SEQUENCE
{
  pickedCall      ConnectionID      OPTIONAL,
  pickedCallInfo  ConnectionInformation OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-directed-pickup-call
```

15.1.14 Group pickup call

```
CSTA-group-pickup-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) group-pickup-call( 221) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

groupPickupCall OPERATION ::=
{
  ARGUMENT    GroupPickupCallArgument
  RESULT      GroupPickupCallResult
  ERRORS      {universalFailure}
  CODE        local: 221
}

GroupPickupCallArgument ::=
SEQUENCE
{
  newDestination DeviceID,
  pickGroup      DeviceID          OPTIONAL,
  correlatorData CorrelatorData    OPTIONAL,
  userData       UserData          OPTIONAL,
  extensions     CSTACommonArguments OPTIONAL}

GroupPickupCallResult ::=
SEQUENCE
{
  pickedCall      ConnectionID      OPTIONAL,
  pickedCallInfo  ConnectionInformation OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-group-pickup-call
```

15.1.15 Hold call

```
CSTA-hold-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) hold-call( 9) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

holdCall      OPERATION ::=
{
  ARGUMENT      HoldCallArgument
  RESULT        HoldCallResult
  ERRORS        {universalFailure}
  CODE          local: 9
}

HoldCallArgument ::=
SEQUENCE
{callToBeHeld      ConnectionID,
 connectionReservation BOOLEAN          OPTIONAL,
 extensions        CSTACCommonArguments OPTIONAL}

HoldCallResult ::=
CHOICE
{extensions        CSTACCommonArguments,
 noData            NULL}

END -- of CSTA-hold-call
```

15.1.16 Intrude call

```
CSTA-intrude-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) intrude-call( 222) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
ParticipationType, UserData FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

intrudeCall OPERATION ::=
{
  ARGUMENT    IntrudeCallArgument
  RESULT      IntrudeCallResult
  ERRORS      {universalFailure}
  CODE        local: 222
}

IntrudeCallArgument ::= SEQUENCE
{
  intrude          ConnectionID,
  participationType ParticipationType   DEFAULT active,
  userData         UserData             OPTIONAL,
  extensions       CSTACommonArguments OPTIONAL}

IntrudeCallResult ::= SEQUENCE
{
  conferencedCall ConnectionID          OPTIONAL,
  -- mandatory, if the Intrude Call service creates a new
  -- ConnectionID for the calling device; not provided otherwise
  conferencedCallInfo ConnectionInformation OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-intrude-call
```

15.1.17 Join call

```
CSTA-join-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) join-call( 223) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, ParticipationType, UserData
FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) }
AutoOriginate FROM CSTA-call-control
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-control( 130) };

joinCall OPERATION ::=
{
  ARGUMENT    JoinCallArgument
  RESULT      JoinCallResult
  ERRORS      {universalFailure}
  CODE        local: 223
}

JoinCallArgument ::= SEQUENCE
{
  activeCall          ConnectionID,
  joiningDevice        DeviceID,
  autoOriginate        [0] IMPLICIT AutoOriginate          DEFAULT prompt,
  participationType    [1] IMPLICIT ParticipationType        DEFAULT active,
  accountCode          [2] IMPLICIT AccountInfo              OPTIONAL,
  authCode             [3] IMPLICIT AuthCode                  OPTIONAL,
  correlatorData       [4] IMPLICIT CorrelatorData            OPTIONAL,
  userData             UserData                                OPTIONAL,
  extensions           CSTACommonArguments                    OPTIONAL}

JoinCallResult ::= SEQUENCE
{
  conferencedCall      ConnectionID,
  conferencedCallInfo   ConnectionInformation              OPTIONAL,
  extensions           CSTACommonArguments                  OPTIONAL}

END -- of CSTA-join-call
```

15.1.18 Make call

```
CSTA-make-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) make-call( 10) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
AutoOriginate, CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

makeCall      OPERATION ::=
{
  ARGUMENT    MakeCallArgument
  RESULT      MakeCallResult
  ERRORS      {universalFailure}
  CODE        local: 10
}

MakeCallArgument ::= SEQUENCE
{
  callingDevice          DeviceID,
  calledDirectoryNumber  DeviceID,
  accountCode            [0] IMPLICIT AccountInfo          OPTIONAL,
  authCode               [1] IMPLICIT AuthCode              OPTIONAL,
  autoOriginate          [3] IMPLICIT AutoOriginate         DEFAULT prompt,
  correlatorData         [2] IMPLICIT CorrelatorData         OPTIONAL,
  userData               UserData                            OPTIONAL,
  callCharacteristics     CallCharacteristics                OPTIONAL,
  mediaCallCharacteristics [4] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callingConnectionInfo   [5] IMPLICIT ConnectionInformation OPTIONAL,
  extensions              CSTACommonArguments                OPTIONAL}

MakeCallResult ::= SEQUENCE
{
  callingDevice          ConnectionID,
  mediaCallCharacteristics [0] IMPLICIT MediaCallCharacteristics OPTIONAL,
  -- mandatory, if the call characteristics have been adjusted.
  initiatedCallInfo      [1] IMPLICIT ConnectionInformation  OPTIONAL,
  extensions              CSTACommonArguments                OPTIONAL}

END -- of CSTA-make-call
```

15.1.19 Make predictive call

```
CSTA-make-predictive-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) make-predictive-call( 11) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM
CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
AutoOriginate, CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

makePredictiveCall          OPERATION ::=
{
  ARGUMENT    MakePredictiveCallArgument
  RESULT      MakePredictiveCallResult
  ERRORS      { universalFailure }
  CODE        local: 11
}

MakePredictiveCallArgument ::= SEQUENCE
{
  callingDevice          DeviceID,
  calledDirectoryNumber  DeviceID,
  signallingDetection    [0] IMPLICIT SignallingDetection    OPTIONAL,
  destinationDetection  [1] IMPLICIT DestinationDetection    OPTIONAL,
  defaultAction          [2] IMPLICIT DefaultAction          OPTIONAL,
  accountCode            [3] IMPLICIT AccountInfo            OPTIONAL,
  authCode               [4] IMPLICIT AuthCode               OPTIONAL,
  autoOriginate          [5] IMPLICIT AutoOriginate          DEFAULT prompt,
  alertTime              [6] IMPLICIT INTEGER               OPTIONAL,
  correlatorData         [7] IMPLICIT CorrelatorData         OPTIONAL,
  callCharacteristics    [8] IMPLICIT CallCharacteristics    OPTIONAL,
  userData               UserData                            OPTIONAL,
  extensions              CSTACCommonArguments              OPTIONAL
}

MakePredictiveCallResult ::= SEQUENCE
{
  initiatedCall          ConnectionID,
  initiatedCallInfo      ConnectionInformation              OPTIONAL,
  extensions              CSTACCommonArguments              OPTIONAL
}

SignallingDetection ::= SEQUENCE
{
  signallingCondition    SignallingCondition,
  signallingConditionsAction SignallingConditionsAction
}

SignallingCondition ::= ENUMERATED
{
  callDelivered          (0),

```



```
        callEstablished          (1)}

SignallingConditionsAction ::= ENUMERATED
{
    destinationDetection    (0),
    remainConnected         (1)}

DestinationDetection ::= SEQUENCE OF SEQUENCE
{
    destinationCondition    DestinationCondition,
    detectionAction         DetectionAction}

DestinationCondition ::= ENUMERATED
{
    humanVoice              (0),
    answeringMachine        (1),
    facsimileMachine        (2)}

DefaultAction ::= DetectionAction

DetectionAction ::= ENUMERATED
{
    clearCalledConnection    (0),
    remainConnected          (1)}

END -- of CSTA-make-predictive-call
```

15.1.20 Park call

```
CSTA-park-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) park-call( 18) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

parkCall
      OPERATION ::=
{
  ARGUMENT      ParkCallArgument
  RESULT        ParkCallResult
  ERRORS        {universalFailure}
  CODE          local: 18
}

ParkCallArgument ::=
  SEQUENCE
  {
    parking          ConnectionID,
    parkTo           DeviceID,
    correlatorData   CorrelatorData      OPTIONAL,
    extensions       CSTACommonArguments OPTIONAL}

ParkCallResult ::=
  SEQUENCE
  {
    parkedTo         ConnectionID      OPTIONAL,
    extensions       CSTACommonArguments OPTIONAL}

END -- of CSTA-park-call
```

15.1.21 Reconnect call

```
CSTA-reconnect-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) reconnect-call( 13) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

reconnectCall      OPERATION ::=
{
    ARGUMENT      ReconnectCallArgument
    RESULT        ReconnectCallResult
    ERRORS        {universalFailure}
    CODE          local: 13
}

ReconnectCallArgument ::= SEQUENCE
{
    activeCall  ConnectionID,
    heldCall    ConnectionID,
    extensions  CSTACommonArguments OPTIONAL}

ReconnectCallResult ::=
CHOICE
{extensions          CSTACommonArguments,
 noData              NULL}

END -- of CSTA-reconnect-call
```

15.1.22 Retrieve call

```
CSTA-retrieve-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) retrieve-call( 14) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

retrieveCall          OPERATION ::=
{
  ARGUMENT      RetrieveCallArgument
  RESULT        RetrieveCallResult
  ERRORS        {universalFailure}
  CODE          local: 14
}

RetrieveCallArgument ::=
  SEQUENCE
  {
    callToBeRetrieved      ConnectionID,
    extensions              CSTACommonArguments OPTIONAL}

RetrieveCallResult ::=
  CHOICE
  {extensions      CSTACommonArguments,
   noData          NULL}

END -- of CSTA-retrieve-call
```

15.1.23 Single step conference call

```
CSTA-single-step-conference
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) single-step-conference( 20) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, ParticipationType, UserData
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

singleStepConf OPERATION ::=
{
  ARGUMENT      SingleStepConfArgument
  RESULT        SingleStepConfResult
  ERRORS        {universalFailure}
  CODE          local: 20
}

SingleStepConfArgument ::=
SEQUENCE
{activeCall          ConnectionID,
 deviceToJoin        DeviceID,
 participationType    ParticipationType          DEFAULT active,
 accountCode          [0] IMPLICIT AccountInfo    OPTIONAL,
 authCode             [1] IMPLICIT AuthCode        OPTIONAL,
 correlatorData       [2] IMPLICIT CorrelatorData  OPTIONAL,
 userData             UserData                    OPTIONAL,
 extensions           CSTACommonArguments          OPTIONAL}

SingleStepConfResult ::=
SEQUENCE
{
  conferencedCall ConnectionID,
  conferencedCallInfo ConnectionInformation  OPTIONAL,
  extensions       CSTACommonArguments      OPTIONAL}

END -- of CSTA-single-step-conference
```

15.1.24 Single step transfer call

```
CSTA-single-step-transfer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) single-step-conference( 50) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
AccountInfo, AuthCode, CorrelatorData, UserData
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

singleStepTrans OPERATION ::=
{
  ARGUMENT    SingleStepTransArgument
  RESULT      SingleStepTransResult
  ERRORS      {universalFailure}
  CODE        local: 50
}

SingleStepTransArgument ::=
SEQUENCE
{activeCall      ConnectionID,
 transferredTo   DeviceID,
 accountCode     [0] IMPLICIT AccountInfo      OPTIONAL,
 authCode        [1] IMPLICIT AuthCode          OPTIONAL,
 correlatorData  [2] IMPLICIT CorrelatorData    OPTIONAL,
 userData        UserData                      OPTIONAL,
 extensions      CSTACommonArguments           OPTIONAL}

SingleStepTransResult ::= SEQUENCE
{transferredCall ConnectionID,
 connections     [0] IMPLICIT ConnectionList    OPTIONAL,
 transferredCallInfo [1] IMPLICIT ConnectionInformation OPTIONAL,
 extensions      CSTACommonArguments           OPTIONAL}

END -- of CSTA-single-step-transfer
```

15.1.25 Transfer call

```
CSTA-transfer-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) transfer-call( 16) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) }
;

transferCall      OPERATION ::=
{
    ARGUMENT      TransferCallArgument
    RESULT        TransferCallResult
    ERRORS        {universalFailure}
    CODE          local: 16
}

TransferCallArgument ::= SEQUENCE
{
    heldCall      ConnectionID,
    activeCall    ConnectionID,
    extensions    CSTACommonArguments OPTIONAL}

TransferCallResult ::= SEQUENCE
{
    transferredCallConnectionID,
    connections    [0] IMPLICIT ConnectionList          OPTIONAL,
    transferredCallInfo    [1] IMPLICIT ConnectionInformation OPTIONAL,
    extensions      CSTACommonArguments                  OPTIONAL}

END -- of CSTA-transfer-call
```

15.2 Events

15.2.1 Bridged

```
CSTA-bridged-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) bridged-event( 224) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

BridgedEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    bridgedConnection      ConnectionID,
    bridgedAppearance      SubjectDeviceID,
    localConnectionInfo    LocalConnectionState      OPTIONAL,
    correlatorData          [0] IMPLICIT CorrelatorData  OPTIONAL,
    userData                UserData                  OPTIONAL,
    cause                   EventCause,
    servicesPermitted       [1] IMPLICIT ServicesPermitted  OPTIONAL,
    mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics  OPTIONAL,
    callCharacteristics     [3] IMPLICIT CallCharacteristics  OPTIONAL,
    bridgedConnectionInfo   [4] IMPLICIT ConnectionInformation  OPTIONAL,
    extensions              CSTACommonArguments        OPTIONAL}

-- The parameters localConnectionInfo, userData and servicesPermitted are
-- conditional. Refer to ECMA 269, 17.2.1.1 for conditions

END -- of CSTA-bridged-event
```


15.2.2 Call cleared

```
CSTA-call-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-cleared-event( 22) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

CallClearedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  clearedCall            ConnectionID,
  correlatorData         [1] IMPLICIT CorrelatorData      OPTIONAL,
  userData               UserData                          OPTIONAL,
  cause                  EventCause,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [3] IMPLICIT CallCharacteristics  OPTIONAL,
  extensions              CSTACommonArguments              OPTIONAL}

-- The parameter userData is conditional. Refer to ECMA 269, 17.2.3.1 for
-- conditions.

END -- of CSTA-call-cleared-event
```

15.2.3 Conferenced

```
CSTA-conferenced-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) conferenced-event( 23) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState, ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ConferencedEvent ::= SEQUENCE
{
  monitorCrossRefID          MonitorCrossRefID,
  primaryOldCall              ConnectionID,
  secondaryOldCall            ConnectionID OPTIONAL,
  conferencingDevice          SubjectDeviceID,
  addedParty                  SubjectDeviceID,
  conferenceConnections       ConnectionList,
  localConnectionInfo         LocalConnectionState OPTIONAL,
  correlatorData               [1] IMPLICIT CorrelatorData OPTIONAL,
  userData                    UserData OPTIONAL,
  cause                       EventCause,
  servicesPermitted           [2] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics     [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics          [4] IMPLICIT CallCharacteristics OPTIONAL,
  extensions                   [5] IMPLICIT CSTACommonArguments OPTIONAL}

-- The parameters secondaryOldCall, localConnectionInfo, correlatorData, userData
-- and servicesPermitted are conditional. Refer to ECMA 269, 17.2.3.1 for
-- conditions

END -- of CSTA-conferenced-event
```

15.2.4 Connection cleared

```
CSTA-connection-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-cleared-event( 24) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ConnectionClearedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  droppedConnection      ConnectionID,
  releasingDevice        SubjectDeviceID,
  localConnectionInfo    LocalConnectionState OPTIONAL,
  correlatorData          [0] IMPLICIT CorrelatorData OPTIONAL,
  userData               UserData OPTIONAL,
  chargingInfo            [1] IMPLICIT ChargingInfo OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [2] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [4] IMPLICIT CallCharacteristics OPTIONAL,
  droppedConnectionInfo   [5] IMPLICIT ConnectionInformation OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, userData and servicesPermitted are
-- conditional. Refer to ECMA 269, 17.2.4.1 for conditions

END -- of CSTA-connection-cleared-event
```

15.2.5 Delivered

```
CSTA-delivered-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) delivered-event( 25) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DeliveredEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  alertingDevice         SubjectDeviceID,
  callingDevice          CallingDeviceID,
  calledDevice           CalledDeviceID,
  lastRedirectionDevice  RedirectionDeviceID,
  originatingNIDConnection ConnectionID
  localConnectionInfo    LocalConnectionState
  correlatorData         [0] IMPLICIT CorrelatorData
  userData              UserData
  cause                 EventCause,
  servicesPermitted     [1] IMPLICIT ServicesPermitted
  networkCallingDevice   NetworkCallingDeviceID
  networkCalledDevice    NetworkCalledDeviceID
  associatedCallingDevice AssociatedCallingDeviceID
  associatedCalledDevice AssociatedCalledDeviceID
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics
  callCharacteristics    [3] IMPLICIT CallCharacteristics
  connectionInfo         [4] IMPLICIT ConnectionInformation
  extensions              CSTACommonArguments
}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted, associatedCallingDevice and associatedCalledDevice are
-- conditional. Refer to ECMA 269, 17.2.5.1 for conditions.

END -- of CSTA-delivered-event
```

15.2.6 Digits dialed

```
CSTA-digits-dialed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) digits-dialed-event( 225) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, DeviceID, AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DigitsDialedEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    dialingConnection      ConnectionID,
    dialingDevice          SubjectDeviceID,
    dialingSequence        DeviceID,
    localConnectionInfo    LocalConnectionState OPTIONAL,
    correlatorData         [0] IMPLICIT CorrelatorData OPTIONAL,
    cause                  EventCause,
    servicesPermitted      [1] IMPLICIT ServicesPermitted OPTIONAL,
    networkCallingDevice   NetworkCallingDeviceID OPTIONAL,
    networkCalledDevice    NetworkCalledDeviceID OPTIONAL,
    associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
    associatedCalledDevice AssociatedCalledDeviceID OPTIONAL,
    dialingConnectionInfo  [2] IMPLICIT ConnectionInformation OPTIONAL,
    callCharacteristics     [3] IMPLICIT CallCharacteristics OPTIONAL,
    extensions             CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, servicesPermitted,
-- associatedCallingDevice and associatedCalledDevice are conditional.
-- Refer to ECMA 269, 17.2.6.1 for conditions.

END -- of CSTA-digits-dialed-event
```

15.2.7 Diverted

```
CSTA-diverted-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) diverted-event( 26) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID , CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DivertedEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    divertingDevice        SubjectDeviceID,
    newDestination         SubjectDeviceID,
    callingDevice          CallingDeviceID      OPTIONAL,
    calledDevice           CalledDeviceID       OPTIONAL,
    lastRedirectionDevice   RedirectionDeviceID,
    localConnectionInfo    LocalConnectionState OPTIONAL,
    correlatorData         [0] IMPLICIT CorrelatorData OPTIONAL,
    userData               UserData             OPTIONAL,
    cause                  EventCause,
    servicesPermitted      [1] IMPLICIT ServicesPermitted OPTIONAL,
    mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
    callCharacteristics    [3] IMPLICIT CallCharacteristics OPTIONAL,
    connectionInfo         [4] IMPLICIT ConnectionInformation OPTIONAL,
    networkCallingDevice    NetworkCallingDeviceID OPTIONAL,
    networkCalledDevice     NetworkCalledDeviceID OPTIONAL,
    associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
    associatedCalledDevice  AssociatedCalledDeviceID OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

-- The parameters callingDevice, calledDevice, localConnectionInfo,
-- correlatorData, userData, servicesPermitted, associatedCallingDevice
-- and associatedCalledDevice are conditional. Refer to ECMA 269, 17.2.7.1
-- for conditions.

END -- of diverted-event
```

15.2.8 Established

```
CSTA-established-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) established-event( 27) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CalledDeviceID, CallingDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

EstablishedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  establishedConnection  ConnectionID,
  answeringDevice        SubjectDeviceID,
  callingDevice           CallingDeviceID,
  calledDevice            CalledDeviceID,
  lastRedirectionDevice   RedirectionDeviceID,
  originatingNIDConnection ConnectionID OPTIONAL,
  localConnectionInfo     LocalConnectionState OPTIONAL,
  correlatorData           [1] IMPLICIT CorrelatorData OPTIONAL,
  userData                 UserData OPTIONAL,
  cause                   EventCause,
  servicesPermitted        [2] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice     NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice      NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice  AssociatedCallingDeviceID OPTIONAL,
  associatedCalledDevice   AssociatedCalledDeviceID OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [4] IMPLICIT CallCharacteristics OPTIONAL,
  establishedConnectionInfo [5] IMPLICIT ConnectionInformation OPTIONAL,
  extensions               CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted, associatedCallingDevice and associatedCalledDevice are
-- conditional. Refer to ECMA 269, 17.2.8.1 for conditions.

END -- of CSTA-established-event
```

15.2.9 Failed

```
CSTA-failed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) failed-event( 28) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

FailedEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  failedConnection       ConnectionID,
  failingDevice           SubjectDeviceID,
  callingDevice           CallingDeviceID,
  calledDevice            CalledDeviceID,
  lastRedirectionDevice   RedirectionDeviceID,
  originatingNIDConnection ConnectionID OPTIONAL,
  localConnectionInfo     LocalConnectionState OPTIONAL,
  correlatorData           [0] IMPLICIT CorrelatorData OPTIONAL,
  userData                UserData OPTIONAL,
  cause                   EventCause,
  servicesPermitted        [1] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice     NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice      NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice   AssociatedCallingDeviceID OPTIONAL,
  associatedCalledDevice    AssociatedCalledDeviceID OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [3] IMPLICIT CallCharacteristics OPTIONAL,
  establishedConnectionInfo [4] IMPLICIT ConnectionInformation OPTIONAL,
  extensions                CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted, associatedCallingDevice and associatedCalledDevice are
-- conditional. Refer to ECMA 269, 17.2.9.1 for conditions.

END -- of CSTA-failed-event
```


15.2.10 Held

```
CSTA-held-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) held-event( 29) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

HeldEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  heldConnection      ConnectionID,
  holdingDevice        SubjectDeviceID,
  localConnectionInfo  LocalConnectionState OPTIONAL,
  correlatorData       [0] IMPLICIT CorrelatorData OPTIONAL,
  cause                EventCause,
  servicesPermitted     [1] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics   [3] IMPLICIT CallCharacteristics OPTIONAL,
  heldConnectionInfo    [4] IMPLICIT ConnectionInformation OPTIONAL,
  extensions            CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo and servicesPermitted are conditional.
-- Refer to ECMA 269, 17.2.10.1 for conditions

END -- of CSTA-held-event
```

15.2.11 Network capabilities changed

```
CSTA-network-capabilities-changed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) network-capabilities-changed-event( 226) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CalledDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, NetworkCapability, ProgressIndicator, ServicesPermitted
FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

NetworkCapabilitiesChangedEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    outboundConnection     ConnectionID,
    networkInterfaceUsed   SubjectDeviceID,
    calledDevice           CalledDeviceID,
    progressIndicator      ProgressIndicator,
    localConnectionInfo    LocalConnectionState OPTIONAL,
    correlatorData         CorrelatorData        OPTIONAL,
    userData               UserData              OPTIONAL,
    networkCapability      [0] IMPLICIT NetworkCapability OPTIONAL,
    cause                  EventCause,
    servicesPermitted      [1] IMPLICIT ServicesPermitted OPTIONAL,
    mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
    callCharacteristics    [3] IMPLICIT CallCharacteristics OPTIONAL,
    outboundConnectionInfo [4] IMPLICIT ConnectionInformation OPTIONAL,
    extensions             CSTACommonArguments  OPTIONAL
}

-- The parameters localConnectionInfo, correlatorData, userData and
-- servicesPermitted are conditional. Refer to ECMA 269, 17.2.11.1 for
-- conditions.

END -- of CSTA-network-capabilities-changed-event
```

15.2.12 Network reached

```
CSTA-network-reached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) network-reached-event( 30) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, NetworkCapability, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

NetworkReachedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  outboundConnection     ConnectionID,
  networkInterfaceUsed   SubjectDeviceID,
  callingDevice          CallingDeviceID,
  calledDevice           CalledDeviceID,
  lastRedirectionDevice  RedirectionDeviceID,
  originatingNIDConneciton ConnectionID OPTIONAL,
  localConnectionInfo    LocalConnectionState OPTIONAL,
  correlatorData         [0] IMPLICIT CorrelatorData OPTIONAL,
  userData              UserData OPTIONAL,
  networkCapability      [1] IMPLICIT NetworkCapability OPTIONAL,
  cause                 EventCause,
  servicesPermitted      [2] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics    [4] IMPLICIT CallCharacteristics OPTIONAL,
  outboundConnectionInfo [5] IMPLICIT ConnectionInformation OPTIONAL,
  networkCallingDevice   NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice    NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
  extensions             CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted and associatedCallingDevice are conditional. Refer to
-- ECMA 269, 17.2.12.1 for conditions.

END -- of CSTA-network-reached-event
```

15.2.13 Offered

```
CSTA-offered-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) offered-event( 227) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

OfferedEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    offeredConnection      ConnectionID,
    offeredDevice          SubjectDeviceID,
    callingDevice          CallingDeviceID,
    calledDevice           CalledDeviceID,
    lastRedirectionDevice   RedirectionDeviceID,
    originatingNIDConnection ConnectionID OPTIONAL,
    localConnectionInfo     LocalConnectionState OPTIONAL,
    correlatorData          CorrelatorData OPTIONAL,
    userData               UserData OPTIONAL,
    cause                  EventCause,
    servicesPermitted       [0] IMPLICIT ServicesPermitted OPTIONAL,
    networkCallingDevice    NetworkCallingDeviceID OPTIONAL,
    networkCalledDevice     NetworkCalledDeviceID OPTIONAL,
    associatedCallingDevice  AssociatedCallingDeviceID OPTIONAL,
    associatedCalledDevice  AssociatedCalledDeviceID OPTIONAL,
    mediaCallCharacteristics [1] IMPLICIT MediaCallCharacteristics OPTIONAL,
    callCharacteristics     [2] IMPLICIT CallCharacteristics OPTIONAL,
    offeredConnectionInfo   [3] IMPLICIT ConnectionInformation OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted, associatedCallingDevice and associatedCalledDevice are
-- conditional. Refer to ECMA 269, 17.2.13.1 for conditions.

END -- of CSTA-offered-event
```

15.2.14 Originated

```
CSTA-originated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) originated-event( 31) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
DeviceID, CallingDeviceID, CalledDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

OriginatedEvent ::= SEQUENCE
{
    monitorCrossRefID          MonitorCrossRefID,
    originatedConnection        ConnectionID,
    subjectDevice               SubjectDeviceID,
    calledDevice                CalledDeviceID,
    originatingDevice           DeviceID
                                OPTIONAL,
    localConnectionInfo         LocalConnectionState
                                OPTIONAL,
    correlatorData              [2] IMPLICIT CorrelatorData
                                OPTIONAL,
    cause                       EventCause,
    servicesPermitted           [3] IMPLICIT ServicesPermitted
                                OPTIONAL,
    networkCallingDevice        NetworkCallingDeviceID
                                OPTIONAL,
    networkCalledDevice         NetworkCalledDeviceID
                                OPTIONAL,
    associatedCallingDevice      AssociatedCallingDeviceID
                                OPTIONAL,
    associatedCalledDevice       AssociatedCalledDeviceID
                                OPTIONAL,
    mediaCallCharacteristics     [4] IMPLICIT MediaCallCharacteristics
                                OPTIONAL,
    callCharacteristics         [5] IMPLICIT CallCharacteristics
                                OPTIONAL,
    originatedConnectionInfo     [6] IMPLICIT ConnectionInformation
                                OPTIONAL,
    extensions                  CSTACCommonArguments
                                OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, servicesPermitted,
-- associatedCallingDevice and associatedCalledDevice are conditional. Refer
-- to ECMA 269, 17.2.14.1 for conditions.

END -- of CSTA-originated-event
```

15.2.15 Queued

```
CSTA-queued-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) queued-event( 32) }
DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
CalledDeviceID, CallingDeviceID, RedirectionDeviceID, SubjectDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

QueuedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  queuedConnection       ConnectionID,
  queue                  SubjectDeviceID,
  callingDevice           CallingDeviceID,
  calledDevice            CalledDeviceID,
  lastRedirectionDevice   RedirectionDeviceID,
  numberQueued            [0] IMPLICIT INTEGER OPTIONAL,
  callsInFront            [1] IMPLICIT INTEGER OPTIONAL,
  localConnectionInfo     LocalConnectionState OPTIONAL,
  correlatorData          [2] IMPLICIT CorrelatorData OPTIONAL,
  userData                UserData OPTIONAL,
  cause                   EventCause,
  servicesPermitted       [3] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice     NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice      NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice  AssociatedCallingDeviceID OPTIONAL,
  associatedCalledDevice   AssociatedCalledDeviceID OPTIONAL,
  mediaCallCharacteristics [4] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [5] IMPLICIT CallCharacteristics OPTIONAL,
  queuedConnectionInfo     [6] IMPLICIT ConnectionInformation OPTIONAL,
  extensions               CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData, userData,
-- servicesPermitted, associatedCallingDevice and associatedCalledDevice are
-- conditional. Refer to ECMA 269, 17.2.15.1 for conditions.

END -- of CSTA-queued-event
```

15.2.16 Retrieved

```
CSTA-retrieved-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) retrieved-event( 33) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

RetrievedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  retrievedConnection     ConnectionID,
  retrievingDevice        SubjectDeviceID,
  localConnectionInfo     LocalConnectionState OPTIONAL,
  correlatorData          [0] IMPLICIT CorrelatorData OPTIONAL,
  cause                   EventCause,
  servicesPermitted       [1] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [3] IMPLICIT CallCharacteristics OPTIONAL,
  retrievedConnectionInfo [4] IMPLICIT ConnectionInformation OPTIONAL,
  extensions               CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo and servicesPermitted are conditional.
-- Refer to ECMA 269, 17.2.16.1 for conditions.

END -- of CSTA-retrieved-event
```

15.2.17 Service initiated

```
CSTA-service-initiated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) service-initiated-event( 34) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, AssociatedCallingDeviceID, NetworkCalledDeviceID,
NetworkCallingDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ServiceInitiatedEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  initiatedConnection    ConnectionID,
  initiatingDevice       SubjectDeviceID,
  localConnectionInfo    LocalConnectionState OPTIONAL,
  correlatorData         [0] IMPLICIT CorrelatorData OPTIONAL,
  cause                  EventCause,
  servicesPermitted      [1] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics    [3] IMPLICIT CallCharacteristics OPTIONAL,
  initiatedConnectionInfo [4] IMPLICIT ConnectionInformation OPTIONAL,
  networkCallingDevice   NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice    NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

-- The parameters localConnectionInfo, correlatorData,
-- servicesPermitted and associatedCallingDevice are conditional.
-- Refer to ECMA 269, 17.2.17.1 for conditions.

END -- of CSTA-service-initiated-event
```


15.2.18 Transferred

```
CSTA-transferred-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) transferred-event( 35) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState, ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

TransferredEvent ::=
SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  primaryOldCall          ConnectionID,
  secondaryOldCall        [0] IMPLICIT ConnectionID      OPTIONAL,
  transferringDevice      SubjectDeviceID,
  transferredToDevice      SubjectDeviceID,
  transferredConnections  [1] IMPLICIT ConnectionList,
  localConnectionInfo     LocalConnectionState           OPTIONAL,
  correlatorData          [2] IMPLICIT CorrelatorData     OPTIONAL,
  userData                UserData                       OPTIONAL,
  chargingInfo            [3] IMPLICIT ChargingInfo       OPTIONAL,
  cause                   EventCause,
  servicesPermitted       [4] IMPLICIT ServicesPermitted  OPTIONAL,
  mediaCallCharacteristics [5] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [6] IMPLICIT CallCharacteristics OPTIONAL,
  extensions              CSTACommonArguments            OPTIONAL}

-- The parameters secondaryOldCall, localConnectionInfo, correlatorData, userData
-- and servicesPermitted are conditional. Refer to ECMA 269, 17.2.18.1 for conditions.

END -- of CSTA-transferred-event
```

16 Call associated features

16.1 Services

16.1.1 Associate data

```
CSTA-associate-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) associate-data( 230) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types(129) }
CallQualifyingData FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

associateData      OPERATION ::=
{
    ARGUMENT      AssociateDataArgument
    RESULT        AssociateDataResult
    ERRORS        {universalFailure}
    CODE          local: 230
}

AssociateDataArgument ::= SEQUENCE
{
    existingCall      ConnectionID,
    accountCode       [0] IMPLICIT AccountInfo      OPTIONAL,
    authCode          [1] IMPLICIT AuthCode          OPTIONAL,
    correlatorData    [2] IMPLICIT CorrelatorData    OPTIONAL,
    callQualifyingData [3] IMPLICIT CallQualifyingData OPTIONAL,
    extensions        CSTACCommonArguments          OPTIONAL}

AssociateDataResult ::=
CHOICE
{extensions        CSTACCommonArguments,
 noData            NULL}

-- The parameters accountCode, authCode, correlatorData and
-- callQualifyingData are conditional. At least one of these parameters has
-- to be provided in the service request.

END -- of CSTA-associate-data
```

16.1.2 Cancel telephony tones

```
CSTA-cancel-telephony-tones
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) cancel-telephony-tones( 231) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

cancelTelephonyTones          OPERATION ::=
{
    ARGUMENT      CancelTelephonyTonesArgument
    RESULT        CancelTelephonyTonesResult
    ERRORS        {universalFailure}
    CODE          local: 231
}

CancelTelephonyTonesArgument ::= SEQUENCE
{
    connectionToStopTone      ConnectionID,
    extensions                 CSTACommonArguments      OPTIONAL}

CancelTelephonyTonesResult ::=
CHOICE
{extensions                 CSTACommonArguments,
 noData                     NULL}

END -- of CSTA-cancel-telephony-tones
```

16.1.3 Generate digits

```
CSTA-generate-digits
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) generate-digits( 232) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

generateDigits      OPERATION ::=
{
  ARGUMENT      GenerateDigitsArgument
  RESULT        GenerateDigitsResult
  ERRORS        {universalFailure}
  CODE          local: 232
}

GenerateDigitsArgument ::= SEQUENCE
{
  connectionToSendDigits ConnectionID,
  digitMode               DigitMode           OPTIONAL,
  charactersToSend        IA5String,
  toneDuration            [0] IMPLICIT INTEGER OPTIONAL,
  pulseRate               [1] IMPLICIT INTEGER OPTIONAL,
  pauseDuration           [2] IMPLICIT INTEGER OPTIONAL,
  extensions              CSTACCommonArguments OPTIONAL}

GenerateDigitsResult ::=
CHOICE
{extensions              CSTACCommonArguments,
 noData                  NULL}

DigitMode ::= ENUMERATED
{
  rotaryPulse (0),
  dTMF        (1)}

-- The parameter charactersToSend is further restrained. Refer to ECMA 269,
-- 18.3.1 for restraints.

END -- of CSTA-generate-digits
```

16.1.4 Generate telephony tones

```
CSTA-generate-telephony-tones
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) generate-telephony-tones( 233) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
TelephonyTone FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

generateTelephonyTones      OPERATION ::=
{
    ARGUMENT    GenerateTelephonyTonesArgument
    RESULT      GenerateTelephonyTonesResult
    ERRORS      {universalFailure}
    CODE        local: 233
}

GenerateTelephonyTonesArgument ::= SEQUENCE
{
    connectionToSendTone    ConnectionID,
    toneToSend              TelephonyTone,
    toneDuration             INTEGER                OPTIONAL,
    extensions               CSTACCommonArguments  OPTIONAL}

GenerateTelephonyTonesResult ::=
CHOICE
{extensions               CSTACCommonArguments,
 noData                   NULL}

END -- of CSTA-generate-telephony-tones
```

16.1.5 Send user information

```
CSTA-send-user-information
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-user-information( 234) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendUserInfo      OPERATION ::=
{
    ARGUMENT      SendUserInfoArgument
    RESULT        SendUserInfoResult
    ERRORS        {universalFailure}
    CODE          local: 234
}

SendUserInfoArgument ::= SEQUENCE
{
    existingCall      ConnectionID,
    userData          UserData,
    extensions        CSTACommonArgumentsOPTIONAL}

SendUserInfoResult ::=
CHOICE
{extensions          CSTACommonArguments,
 noData              NULL}

END -- of CSTA-send-user-information
```

16.2 Events

16.2.1 Call information

```
CSTA-call-information-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-information-event( 41) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
CallingDeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallQualifyingData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

CallInformationEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  device                 SubjectDeviceID,
  callingDevice          CallingDeviceID          OPTIONAL,
  accountInfo            [0] IMPLICIT AccountInfo  OPTIONAL,
  authCode               [1] IMPLICIT AuthCode     OPTIONAL,
  correlatorData         [2] IMPLICIT CorrelatorData OPTIONAL,
  servicesPermitted      [3] IMPLICIT ServicesPermitted OPTIONAL,
  userData               UserData                 OPTIONAL,
  callQualifyingData     [4] IMPLICIT CallQualifyingData OPTIONAL,
  connectionInfo         ConnectionInformation    OPTIONAL,
  extensions             CSTACommonArguments      OPTIONAL}

-- At least one of the parameters callingDevice, accountInfo, authCode,
-- correlatorData, servicesPermitted, userData, callQualifyingData
-- and connectionInfo must be provided.

END -- of CSTA-call-information-event
```

16.2.2 Charging

```
CSTA-charging-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charging-event( 240) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types(129) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) };

ChargingEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  chargedDevice           DeviceID,
  chargingInfo            ChargingInfo,
  cause                  EventCause      OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

END -- of CSTA-charging-event
```


16.2.3 Digits generated

```
CSTA-digits-generated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) digits-generated-event( 241) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

DigitsGeneratedEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  digitGeneratedList      IA5String,
  digitDurationList       [0] IMPLICIT SEQUENCE OF INTEGER    OPTIONAL,
  pauseDurationList       [1] IMPLICIT SEQUENCE OF INTEGER    OPTIONAL,
  connectionInfo          ConnectionInformation                OPTIONAL,
  extensions              CSTACCommonArguments                OPTIONAL}

-- The parameter digitGeneratedList is further restrained. Refer to ECMA 269,
-- 18.2.3.1 for restraints.

END -- of CSTA-digits-generated-event
```

16.2.4 Telephony tones generated

```
CSTA-telephony-tones-generated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) telephony-tones-generated-event( 242) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
TelephonyTone FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

TelephonyTonesGeneratedEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  toneGenerated           TelephonyTone      OPTIONAL,
  toneFrequency           [0] IMPLICIT INTEGER OPTIONAL,
  toneDuration           [1] IMPLICIT INTEGER OPTIONAL,
  pauseDuration          [2] IMPLICIT INTEGER OPTIONAL,
  connectionInfo         ConnectionInformation OPTIONAL,
  extensions             CSTACommonArguments OPTIONAL}

-- The parameter toneGenerated is conditional. Refer to ECMA 269,
-- 18.2.4.1 for conditions.

END -- of CSTA-telephony-tones-generated-event
```

16.2.5 Service completion failure

```
CSTA-service-completion-failure-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) service-completion-failure-event( 243) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) connection-states( 125) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

ServiceCompletionFailureEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  primaryCall             PrimaryOrSecondaryCall,
  secondaryCall           [0] IMPLICIT PrimaryOrSecondaryCall    OPTIONAL,
  otherDevsPrimaryCallList [1] IMPLICIT SEQUENCE OF OtherCall    OPTIONAL,
  otherDevsSecondaryCallList [2] IMPLICIT SEQUENCE OF OtherCall  OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics  OPTIONAL,
  cause                  EventCause,
  extensions              CSTACommonArguments                    OPTIONAL}

PrimaryOrSecondaryCall ::= SEQUENCE
{
  deviceID      DeviceID,
  connectionID  ConnectionID,
  localConnectionState LocalConnectionState,
  connectionInfo ConnectionInformation OPTIONAL}

OtherCall ::= SEQUENCE
{
  deviceID      DeviceID,
  connectionID  ConnectionID,
  localConnectionState LocalConnectionState OPTIONAL,
  connectionInfo ConnectionInformation OPTIONAL}

END -- of CSTA-charging-event
```

17 Media attachment services and events

17.1 Services

17.1.1 Attach media service

```
CSTA-attach-media-service
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) attach-media-service( 244) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
MediaServiceType, MediaServiceInstanceID, ConnectionMode,
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

attachMediaService OPERATION ::=
{
    ARGUMENT    AttachMediaServiceArgument
    RESULT      AttachMediaServiceResult
    ERRORS      {universalFailure}
    CODE        local: 244
}

AttachMediaServiceArgument ::= SEQUENCE
{
    connection          ConnectionID,
    mediaServiceType     MediaServiceType,
    mediaServiceVersion  INTEGER OPTIONAL,
    mediaServiceInstanceID MediaServiceInstanceID OPTIONAL,
    connectionMode       ConnectionMode,
    requestedConnectionState LocalConnectionState OPTIONAL,
    extensions           CSTACommonArguments OPTIONAL}

AttachMediaServiceResult ::= SEQUENCE
{
    mediaConnection      ConnectionID OPTIONAL,
    mediaDevice           [0] IMPLICIT DeviceID OPTIONAL,
    mediaServiceInstanceID MediaServiceInstanceID OPTIONAL,
    mediaConnectionInfo  [1] IMPLICIT ConnectionInformation OPTIONAL,
    extensions           CSTACommonArguments OPTIONAL}

-- The parameters mediaConnection and mediaDevice are conditional. Refer to ECMA 269,
-- 19.1.1.1 for conditions.

END -- of CSTA-attach-media-service
```

17.1.2 Detach media service

```
CSTA-detach-media-service
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) detach-media-service( 245) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
MediaServiceType FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

detachMediaService OPERATION ::=
{
    ARGUMENT    DetachMediaServiceArgument
    RESULT      DetachMediaServiceResult
    ERRORS      {universalFailure}
    CODE        local: 245
}

DetachMediaServiceArgument ::= SEQUENCE
{
    connection      ConnectionID,
    mediaServiceType MediaServiceType,
    extensions       CSTACCommonArguments OPTIONAL}

DetachMediaServiceResult ::= CHOICE
{
    extensions  CSTACCommonArguments,
    noData      NULL}

END -- of CSTA-detach-media-service
```

17.2 Events

17.2.1 Media attached

```
CSTA-media-attached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-attached-event( 246) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaServiceType, MediaServiceInstanceID, MediaStreamID,
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

MediaAttachedEvent ::= SEQUENCE
{
  mediaConnection          ConnectionID,
  mediaDevice              SubjectDeviceID,
  mediaServiceType         MediaServiceType,
  mediaServiceVersion      INTEGER OPTIONAL,
  mediaServiceInstanceID   [0] IMPLICIT MediaServiceInstanceID OPTIONAL,
  mediaStreamID            [1] IMPLICIT MediaStreamID OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      CallCharacteristics OPTIONAL,
  localConnectionInfo      LocalConnectionState OPTIONAL,
  mediaConnectionInfo      [3] IMPLICIT ConnectionInformation OPTIONAL,
  extension                CSTACommonArguments OPTIONAL}

-- The parameters mediaStreamID and localConnectionInfo are conditional.
-- Refer to ECMA 269, 19.2.1 for conditions

END -- of CSTA-media-attached-service
```

17.2.2 Media detached

```
CSTA-media-detached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-detached-event( 247) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaServiceType, MediaServiceInstanceID, MediaStreamID,
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

MediaDetachedEvent ::= SEQUENCE
{
  mediaConnection          ConnectionID,
  mediaDevice              SubjectDeviceID,
  mediaServiceType         MediaServiceType,
  mediaServiceVersion      INTEGER OPTIONAL,
  mediaServiceInstanceID   [0] IMPLICIT MediaServiceInstanceID OPTIONAL,
  mediaStreamID            [1] IMPLICIT MediaStreamID OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      CallCharacteristics OPTIONAL,
  localConnectionInfo      LocalConnectionState OPTIONAL,
  mediaConnectionInfo      [3] IMPLICIT ConnectionInformation OPTIONAL,
  extension                CSTACommonArguments OPTIONAL
}

-- The parameters mediaStreamID and localConnectionInfo are conditional.
-- Refer to ECMA 269, 19.2.2 for conditions

END -- of CSTA-media-detached-service
```

18 Routeing services

18.1 Registration services

18.1.1 Route register

```
CSTA-route-register
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-register( 248) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
RouteRegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types(129) }
MediaClass FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

routeRegister OPERATION ::=
{
    ARGUMENT    RouteRegisterArgument
    RESULT      RouteRegisterResult
    ERRORS      {universalFailure}
    CODE        local: 248
}

RouteRegisterArgument ::= SEQUENCE
{
    routeingDevice          DeviceID          OPTIONAL,
    requestedRouteingMediaClass MediaClass      OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

RouteRegisterResult ::= SEQUENCE
{
    routeRegisterReqID      RouteRegisterReqID,
    actualRouteingMediaClass MediaClass          OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

-- The parameters routeingDevice and actualRouteingMediaClass are conditional.
-- Refer to ECMA 269, 20.1.1 for conditions.

END -- of CSTA-route-register
```


18.1.2 Route register abort

```
CSTA-route-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-register-abort( 249) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
RouteRegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeRegisterAbort OPERATION ::=
{
    ARGUMENT          RouteRegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE              local: 249
}

RouteRegisterAbortArgument ::= SEQUENCE
{
    routeRegisterReqID    RouteRegisterReqID,
    extensions            CSTACommonArguments    OPTIONAL}

END -- of CSTA-route-register-abort
```

18.1.3 Route register cancel

```
CSTA-route-register-cancel
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-register-cancel( 250) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
RouteRegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeRegisterCancel OPERATION ::=
{
    ARGUMENT    RouteRegisterCancelArgument
    RESULT      RouteRegisterCancelResult
    ERRORS      {universalFailure}
    CODE        local: 250
}

RouteRegisterCancelArgument ::= SEQUENCE
{
    routeRegisterReqID    RouteRegisterReqID,
    extensions             CSTACommonArguments    OPTIONAL}

RouteRegisterCancelResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-route-register-cancel
```

18.2 Services

18.2.1 Re-Route

```
CSTA-re-route-request
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) re-route-request( 82) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) };

reRouteRequest OPERATION ::=
{
  ARGUMENT          ReRouteRequestArgument
  ERRORS             {universalFailure}
  ALWAYS RESPONDS    FALSE
  CODE               local: 32
}

ReRouteRequestArgument ::= SEQUENCE
{
  crossRefIdentifier    RouteingCrossRefID,
  routeRegisterReqID    [0] IMPLICIT RouteRegisterReqID    OPTIONAL,
  replyTimeout          [1] IMPLICIT INTEGER                OPTIONAL,
  correlatorData        [2] IMPLICIT CorrelatorData          OPTIONAL,
  extensions            CSTACommonArguments                  OPTIONAL}

-- The parameters RouteRegisterReqID and CorrelatorData are
-- conditional. Refer to ECMA 269, 20.2.1.1 for conditions.

END -- of CSTA-re-route-request
```

18.2.2 Route end

```
CSTA-route-end-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta( 180) route-end-request( 85) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure, ErrorValue FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeEndRequest OPERATION ::=
{
    ARGUMENT          RouteEndRequestArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 35
}

RouteEndRequestArgument ::= SEQUENCE {
    crossRefIdentifier    RouteingCrossRefID,
    routeRegisterReqID    [ 0 ] IMPLICIT RouteRegisterReqID    OPTIONAL,
    errorValue            [ 1 ] ErrorValue                      OPTIONAL,
    correlatorData        [ 2 ] IMPLICIT CorrelatorData         OPTIONAL,
    extensions            CSTACommonArguments                  OPTIONAL}

-- The parameters RouteRegisterReqID and CorrelatorData are
-- conditional. Refer to ECMA 269, 20.2.2.1 for conditions.

END -- of CSTA-route-end-request
```

18.2.3 Route reject

```
CSTA-route-reject
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-reject( 86) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

routeReject OPERATION ::=
{
  ARGUMENT          RouteRejectArgument
  ERRORS             {universalFailure}
  ALWAYS RESPONDS    FALSE
  CODE               local: 36
}

RouteRejectArgument ::=
  SEQUENCE
  {crossRefIdentifier      RouteingCrossRefID,
   routeRegisterReqID      [0] IMPLICIT RouteRegisterReqID OPTIONAL,
   rejectCause             [1] IMPLICIT RejectCause          OPTIONAL,
   correlatorData          [2] IMPLICIT CorrelatorData        OPTIONAL,
   extensions              CSTACommonArguments                OPTIONAL}

RejectCause ::= ENUMERATED
{
  busyOverflow             (1),
  queueTimeOverflow        (2),
  capacityOverflow         (3),
  calendarOverflow         (4),
  unknownOverflow          (5)}

-- The parameters routeRegisterReqID is conditional. Refer to ECMA 269, 20.2.3.1
-- for conditions.

END -- of CSTA-route-reject
```

18.2.4 Route request

```
CSTA-route-request
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-request( 81) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
AssociatedCallingDeviceID, AssociatedCalledDeviceID, CalledDeviceID,
CallingDeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, SelectValue, RouteRegisterReqID, RouteingCrossRefID
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

routeRequest OPERATION ::=
{
  ARGUMENT          RouteRequestArgument
  ERRORS             {universalFailure}
  ALWAYS RESPONDS    FALSE
  CODE               local: 31
}

RouteRequestArgument ::= SEQUENCE
{
  crossRefIdentifier      RouteingCrossRefID,
  routeRegisterReqID      [0] IMPLICIT RouteRegisterReqID      OPTIONAL,
  currentRoute            CalledDeviceID,
  callingDevice            CallingDeviceID                      OPTIONAL,
  routeingDevice          SubjectDeviceID                      OPTIONAL,
  routedCall              ConnectionID                          OPTIONAL,
  routeSelAlgorithm       [1] IMPLICIT SelectValue             OPTIONAL,
  associatedCallingDevice  AssociatedCallingDeviceID            OPTIONAL,
  associatedCalledDevice   AssociatedCalledDeviceID             OPTIONAL,
  priority                 [2] IMPLICIT BOOLEAN                OPTIONAL,
  replyTimeout            [3] IMPLICIT INTEGER                 OPTIONAL,
  correlatorData          [4] IMPLICIT CorrelatorData           OPTIONAL,
  mediaCallCharacteristics [5] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [6] IMPLICIT CallCharacteristics     OPTIONAL,
  routeCallInfo            [7] IMPLICIT ConnectionInformation   OPTIONAL,
  extensions               CSTACommonArguments                 OPTIONAL}

-- The parameters routeRegisterReqID, routeCall, associatedCallingDevice
-- and correlatorData are conditional. Refer to ECMA 269, 20.2.4.1
-- for conditions.

END -- of CSTA-route-request
```

18.2.5 Route select

```
CSTA-Route-select-request
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-select-request( 83) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CorrelatorData, RetryValue, RouteingCrossRefID, RouteRegisterReqID
FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

routeSelectRequest      OPERATION ::=
{
  ARGUMENT          RouteSelectRequestArgument
  ERRORS             {universalFailure}
  ALWAYS RESPONDS    FALSE
  CODE               local: 33
}

RouteSelectRequestArgument ::=
SEQUENCE
{crossRefIdentifier    RouteingCrossRefID,
 routeRegisterReqID    [0] IMPLICIT RouteRegisterReqID      OPTIONAL,
 routeSelected         [1] DeviceID,
 alternateRoutes       [2] IMPLICIT SEQUENCE OF DeviceID     OPTIONAL,
 remainRetries         [3] RetryValue                        OPTIONAL,
 routeUsedReq         [4] IMPLICIT BOOLEAN                   OPTIONAL,
 correlatorData        [5] IMPLICIT CorrelatorData           OPTIONAL,
 extensions            CSTACommonArguments                   OPTIONAL}
```

-- The parameter RouteRegisterReqID is conditional. Refer to ECMA 269,
-- 20.2.5.1 for conditions.

END -- of CSTA-route-select-request

18.2.6 Route used

```
CSTA-route-used-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-used-request( 84) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CallingDeviceID, CalledDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeUsedRequest      OPERATION ::=
{
    ARGUMENT          RouteUsedRequestArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 34
}

RouteUsedRequestArgument ::=
SEQUENCE
{crossRefIdentifier    RouteingCrossRefID,
 routeRegisterReqID    [0] IMPLICIT RouteRegisterReqID OPTIONAL,
 routeUsed             CalledDeviceID,
 callingDevice          CallingDeviceID OPTIONAL,
 domain                BOOLEAN OPTIONAL,
 correlatorData         [1] IMPLICIT CorrelatorData OPTIONAL,
 extensions             CSTACommonArguments OPTIONAL}

-- The parameters RouteRegisterReqID and CorrelatorData are
-- conditional. Refer to ECMA 269, 20.2.6.1 for conditions.

END -- of CSTA-route-used-request
```


19 Physical device features

19.1 Services

19.1.1 Button press

```
CSTA-button-press
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) button-press( 260) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

buttonPress OPERATION ::=
{
  ARGUMENT    ButtonPressArgument
  RESULT      ButtonPressResult
  ERRORS      {universalFailure}
  CODE        local: 260
}

ButtonPressArgument ::= SEQUENCE
{
  device      DeviceID,
  button      ButtonID,
  extensions  CSTACommonArguments OPTIONAL}

ButtonPressResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-button-press
```

19.1.2 Get auditory apparatus information

```
CSTA-get-auditory-apparatus-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auditory-apparatus-information( 261) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, AuditoryApparatusList FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getAuditoryApparatusInformation OPERATION ::=
{
  ARGUMENT    GetAuditoryApparatusInformationArgument
  RESULT      GetAuditoryApparatusInformationResult
  ERRORS      {universalFailure}
  CODE        local: 261
}

GetAuditoryApparatusInformationArgument ::= SEQUENCE
{
  device                DeviceID,
  auditoryApparatus      AuditoryApparatusID OPTIONAL,
  extensions             CSTACommonArguments OPTIONAL}

GetAuditoryApparatusInformationResult ::= SEQUENCE
{
  auditoryApparatusList  AuditoryApparatusList,
  extensions             CSTACommonArguments    OPTIONAL}

END -- of CSTA-get-auditory-apparatus-information
```

19.1.3 Get button information

```
CSTA-get-button-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-button-information( 262) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getButtonInformation OPERATION ::=
{
  ARGUMENT    GetButtonInformationArgument
  RESULT      GetButtonInformationResult
  ERRORS      {universalFailure}
  CODE        local: 262
}

GetButtonInformationArgument ::= SEQUENCE
{
  device      DeviceID,
  button      ButtonID,
  extensions  CSTACommonArguments OPTIONAL,
}

GetButtonInformationResult ::= SEQUENCE
{
  buttonList  ButtonList,
  extensions  CSTACommonArguments OPTIONAL,
}

ButtonList ::= SEQUENCE OF SEQUENCE
{
  button      ButtonID,
  buttonLabel [0] IMPLICIT IA5String OPTIONAL,
  buttonLabelSettable [1] IMPLICIT BOOLEAN OPTIONAL,
  buttonFunction [2] IMPLICIT IA5String OPTIONAL,
  buttonAssociatedNumber [3] IMPLICIT DeviceID OPTIONAL,
  buttonAssociatedNumberSettable [4] IMPLICIT BOOLEAN OPTIONAL,
  buttonPressIndicator [5] IMPLICIT BOOLEAN OPTIONAL,
  lampList      SEQUENCE OF LampID OPTIONAL,
}
```

END -- of CSTA-get-button-information

19.1.4 Get display

```
CSTA-get-display
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-display( 263) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DisplayID, CharacterSet FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getDisplay OPERATION ::=
{
  ARGUMENT      GetDisplayArgument
  RESULT        GetDisplayResult
  ERRORS        {universalFailure}
  CODE          local: 263
}

GetDisplayArgument ::= SEQUENCE
{
  device      DeviceID,
  display     DisplayID          OPTIONAL,
  extensions  CSTACCommonArguments OPTIONAL}

GetDisplayResult ::= SEQUENCE
{
  displayList      DisplayList,
  extensions       CSTACCommonArguments OPTIONAL}

DisplayList ::= SEQUENCE OF SEQUENCE
{
  displayID      DisplayID,
  logicalRows    INTEGER,
  logicalColumns INTEGER,
  physicalRows   [0] IMPLICIT INTEGER OPTIONAL,
  physicalColumns [1] IMPLICIT INTEGER OPTIONAL,
  physicalBaseRowNumber [2] IMPLICIT INTEGER OPTIONAL,
  physicalBaseColumnNumber [3] IMPLICIT INTEGER OPTIONAL,
  characterSet    CharacterSet OPTIONAL,
  contentsOfDisplay IA5String}

-- The parameters physicalRows, physicalColumns, physicalBaseRowNumber and
-- physicalBaseColumnNumber are conditional. Refer to ECMA 269, clause 21.1.4
-- for conditions.

END -- of CSTA-get-display
```

19.1.5 Get hookswitch status

```
CSTA-get-hookswitch-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-hookswitch-status( 264) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getHookswitchStatus OPERATION ::=
{
  ARGUMENT    GetHookswitchStatusArgument
  RESULT      GetHookswitchStatusResult
  ERRORS      {universalFailure}
  CODE        local: 264
}

GetHookswitchStatusArgument ::= SEQUENCE
{
  device      DeviceID,
  hookswitch  HookswitchID          OPTIONAL,
  extensions  CSTACommonArguments  OPTIONAL}

GetHookswitchStatusResult ::= SEQUENCE
{
  hookswitchStatusList  HookswitchStatusList,
  extensions            CSTACommonArguments  OPTIONAL}

HookswitchStatusList ::= SEQUENCE OF SEQUENCE
{
  hookswitch      HookswitchID,
  hookswitchOnHook  BOOLEAN}

END -- of CSTA-get-hookswitch-status
```

19.1.6 Get lamp information

```
CSTA-get-lamp-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-lamp-information( 265) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID, LampColor FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getLampInformation OPERATION ::=
{
  ARGUMENT    GetLampInformationArgument
  RESULT      GetLampInformationResult
  ERRORS      {universalFailure}
  CODE        local: 265
}

GetLampInformationArgument ::= SEQUENCE
{
  device      DeviceID,
  lamp        LampID,
  extensions  CSTACommonArguments OPTIONAL,
}

GetLampInformationResult ::= SEQUENCE
{
  lampList    LampList,
  extensions  CSTACommonArguments OPTIONAL,
}

LampList ::= SEQUENCE OF SEQUENCE
{
  lamp        LampID,
  lampLabel   [0] IMPLICIT OCTET STRING OPTIONAL,
  button      [1] IMPLICIT ButtonID OPTIONAL,
  lampColor   LampColor OPTIONAL,
}

END -- of CSTA-get-lamp-information
```

19.1.7 Get lamp mode

```
CSTA-get-lamp-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-lamp-mode( 266) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID, LampColor, LampMode, LampBrightness
FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getLampMode OPERATION ::=
{
  ARGUMENT      GetLampModeArgument
  RESULT        GetLampModeResult
  ERRORS        {universalFailure}
  CODE          local: 266
}

GetLampModeArgument ::= SEQUENCE
{
  device      DeviceID,
  lamp        LampID
  extensions  CSTACommonArguments OPTIONAL}

GetLampModeResult ::= SEQUENCE
{
  lampModeList  LampModeList,
  lamp          LampID
  extensions     CSTACommonArguments OPTIONAL}

LampModeList ::= SEQUENCE OF SEQUENCE
{
  lamp          LampID,
  lampMode      LampMode,
  lampBrightness [0] IMPLICIT LampBrightness OPTIONAL,
  lampColor      [1] IMPLICIT LampColor OPTIONAL,
  button         [2] IMPLICIT ButtonID OPTIONAL}

END -- of CSTA-get-lamp-mode
```

19.1.8 Get message waiting indicator

```
CSTA-get-message-waiting-indicator
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-message-waiting-indicator( 267) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getMessageWaitingIndicator OPERATION ::=
{
  ARGUMENT    GetMessageWaitingIndicatorArgument
  RESULT      GetMessageWaitingIndicatorResult
  ERRORS      {universalFailure}
  CODE        local: 267
}

GetMessageWaitingIndicatorArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACCommonArguments    OPTIONAL}

GetMessageWaitingIndicatorResult ::= SEQUENCE
{
  messageWaitingOn    BOOLEAN,
  deviceForMessage     DeviceID          OPTIONAL,
  lampIsPresent       BOOLEAN          OPTIONAL,
  extensions           CSTACCommonArguments    OPTIONAL}

END -- of CSTA-get-message-waiting-indicator
```


19.1.9 Get microphone gain

```
CSTA-get-microphone-gain
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-microphone-gain( 268) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicGainAbs FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getMicrophoneGain OPERATION ::=
{
  ARGUMENT    GetMicrophoneGainArgument
  RESULT      GetMicrophoneGainResult
  ERRORS      {universalFailure}
  CODE        local: 268
}

GetMicrophoneGainArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetMicrophoneGainResult ::= SEQUENCE
{
  microphoneGainList MicrophoneGainList,
  extensions          CSTACommonArguments OPTIONAL}

MicrophoneGainList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus AuditoryApparatusID,
  micGainAbs        MicGainAbs          OPTIONAL}

END -- of CSTA-get-microphone-gain
```

19.1.10 Get microphone mute

```
CSTA-get-microphone-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-microphone-mute( 269) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getMicrophoneMute OPERATION ::=
{
  ARGUMENT      GetMicrophoneMuteArgument
  RESULT        GetMicrophoneMuteResult
  ERRORS        {universalFailure}
  CODE          local: 269
}

GetMicrophoneMuteArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetMicrophoneMuteResult ::= SEQUENCE
{
  microphoneMuteList MicrophoneMuteList,
  extensions          CSTACommonArguments OPTIONAL}

MicrophoneMuteList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus AuditoryApparatusID,
  microphoneMuteOn  BOOLEAN}

END -- of CSTA-get-microphone-mute
```

19.1.11 Get ringer status

```
CSTA-get-ringer-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-ringer-status( 270) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getRingerStatus OPERATION ::=
{
  ARGUMENT    GetRingerStatusArgument
  RESULT      GetRingerStatusResult
  ERRORS      {universalFailure}
  CODE        local: 270
}

GetRingerStatusArgument ::= SEQUENCE
{
  device      DeviceID,
  ringer      RingerID,
  extensions  CSTACommonArguments OPTIONAL,
}

GetRingerStatusResult ::= SEQUENCE
{
  ringerStatusList  RingerStatusList,
  extensions        CSTACommonArguments OPTIONAL}

RingerStatusList ::= SEQUENCE OF SEQUENCE
{
  ringer      RingerID,
  ringMode    RingMode,
  ringCount   [0] IMPLICIT INTEGER (0..100)    OPTIONAL,
  ringPattern [1] IMPLICIT INTEGER              OPTIONAL,
  ringVolAbs  [2] IMPLICIT INTEGER (0..100)    OPTIONAL}

END -- of CSTA-get-ringer-status
```

19.1.12 Get speaker mute

```
CSTA-get-speaker-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-speaker-mute( 271) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getSpeakerMute OPERATION ::=
{
  ARGUMENT    GetSpeakerMuteArgument
  RESULT      GetSpeakerMuteResult
  ERRORS      {universalFailure}
  CODE        local: 271
}

GetSpeakerMuteArgument ::= SEQUENCE
{
  device                DeviceID,
  auditoryApparatus     AuditoryApparatusID    OPTIONAL,
  extensions             CSTACommonArguments    OPTIONAL}

GetSpeakerMuteResult ::= SEQUENCE
{
  speakerMuteList       SpeakerMuteList,
  extensions             CSTACommonArguments    OPTIONAL}

SpeakerMuteList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus     AuditoryApparatusID,
  speakerMuteOn         BOOLEAN}

END -- of CSTA-get-speaker-mute
```

19.1.13 Get speaker volume

```
CSTA-get-speaker-volume
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-speaker-volume( 272) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, VolAbs FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getSpeakerVolume OPERATION ::=
{
  ARGUMENT    GetSpeakerVolumeArgument
  RESULT      GetSpeakerVolumeResult
  ERRORS      {universalFailure}
  CODE        local: 272
}

GetSpeakerVolumeArgument ::= SEQUENCE
{
  device                DeviceID,
  auditoryApparatus     AuditoryApparatusID    OPTIONAL,
  extensions             CSTACCommonArguments  OPTIONAL}

GetSpeakerVolumeResult ::= SEQUENCE
{
  speakerVolumeList     SpeakerVolumeList,
  extensions             CSTACCommonArguments  OPTIONAL}

SpeakerVolumeList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus     AuditoryApparatusID,
  speakerVolAbs         VolAbs                  OPTIONAL}

END -- of CSTA-get-speaker-volume
```

19.1.14 Set button information

```
CSTA-set-button-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-button-information( 273) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setButtonInformation OPERATION ::=
{
  ARGUMENT      SetButtonInformationArgument
  RESULT        SetButtonInformationResult
  ERRORS        {universalFailure}
  CODE          local: 273
}

SetButtonInformationArgument ::= SEQUENCE
{
  device          DeviceID,
  button          ButtonID,
  buttonLabel     IA5String (SIZE(0..64)) OPTIONAL,
  buttonAssociatedNumber DeviceID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}
-- At least one of the parameters buttonLabel and
-- buttonAssociatedNumber has to be provided.

SetButtonInformationResult ::= CHOICE
{
  extensions      CSTACommonArguments,
  noData          NULL}

END -- of CSTA-set-button-information
```

19.1.15 Set display

```
CSTA-set-display
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-display( 274) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setDisplay OPERATION ::=
{
  ARGUMENT      SetDisplayArgument
  RESULT        SetDisplayResult
  ERRORS        {universalFailure}
  CODE          local: 274
}

SetDisplayArgument ::= SEQUENCE
{
  device          DeviceID,
  display         DisplayID,
  physicalBaseRowNumber [0] IMPLICIT INTEGER,
  physicalBaseColumnNumber [1] IMPLICIT INTEGER,
  contentsOfDisplay IA5String (SIZE(0..240)),
  offset          [2] IMPLICIT INTEGER,
  extensions      CSTACCommonArguments
}

SetDisplayResult ::= CHOICE
{
  extensions CSTACCommonArguments,
  noData      NULL}

-- The parameters DisplayID is conditional. Refer to ECMA 269, clause 21.1.15
-- for conditions.

END -- of CSTA-set-display
```

19.1.16 Set hookswitch status

```
CSTA-set-hookswitch-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-hookswitch-status( 275) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setHookswitchStatus OPERATION ::=
{
  ARGUMENT      SetHookswitchStatusArgument
  RESULT        SetHookswitchStatusResult
  ERRORS        {universalFailure}
  CODE          local: 275
}

SetHookswitchStatusArgument ::= SEQUENCE
{
  device          DeviceID,
  hookswitch      HookswitchID,
  hookswitchOnHook  BOOLEAN,
  extensions      CSTACommonArguments OPTIONAL}

SetHookswitchStatusResult ::= CHOICE
{
  extensions      CSTACommonArguments,
  noData          NULL}

END -- of CSTA-set-hookswitch-status
```


19.1.17 Set lamp mode

```
CSTA-set-lamp-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-lamp-mode( 276) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
LampID, LampColor, LampMode, LampBrightness
FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setLampMode OPERATION ::=
{
  ARGUMENT      SetLampModeArgument
  RESULT        SetLampModeResult
  ERRORS        {universalFailure}
  CODE          local: 276
}

SetLampModeArgument ::= SEQUENCE
{
  device          DeviceID,
  lamp            LampID,
  lampMode        LampMode,
  lampBrightness  LampBrightness  OPTIONAL,
  lampColor       LampColor       OPTIONAL,
  extensions      CSTACommonArguments  OPTIONAL}

SetLampModeResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-lamp-mode
```

19.1.18 Set message waiting indicator

```
CSTA-set-message-waiting-indicator
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-message-waiting-indicator( 277) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setMessageWaitingIndicator OPERATION ::=
{
  ARGUMENT    SetMessageWaitingIndicatorArgument
  RESULT      SetMessageWaitingIndicatorResult
  ERRORS      {universalFailure}
  CODE        local: 277
}

SetMessageWaitingIndicatorArgument ::= SEQUENCE
{
  device          DeviceID,
  messageWaitingOn  BOOLEAN,
  extensions       CSTACommonArguments    OPTIONAL}

SetMessageWaitingIndicatorResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-message-waiting-indicator
```

19.1.19 Set microphone gain

```
CSTA-set-microphone-gain
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-microphone-gain( 278) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicrophoneGain FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setMicrophoneGain OPERATION ::=
{
  ARGUMENT    SetMicrophoneGainArgument
  RESULT      SetMicrophoneGainResult
  ERRORS      {universalFailure}
  CODE        local: 278
}

SetMicrophoneGainArgument ::= SEQUENCE
{
  device                DeviceID,
  auditoryApparatus     AuditoryApparatusID,
  microphoneGain         MicrophoneGain,
  extensions             CSTACommonArguments    OPTIONAL}

SetMicrophoneGainResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-set-microphone-gain
```

19.1.20 Set microphone mute

```
CSTA-set-microphone-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-microphone-mute( 279) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setMicrophoneMute OPERATION ::=
{
  ARGUMENT      SetMicrophoneMuteArgument
  RESULT        SetMicrophoneMuteResult
  ERRORS        {universalFailure}
  CODE          local: 279
}

SetMicrophoneMuteArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID,
  microphoneMuteOn BOOLEAN,
  extensions      CSTACommonArguments OPTIONAL}

SetMicrophoneMuteResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-microphone-mute
```

19.1.21 Set ringer status

```
CSTA-set-ringer-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-ringer-status( 280) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode, Volume FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setRingerStatus OPERATION ::=
{
  ARGUMENT      SetRingerStatusArgument
  RESULT        SetRingerStatusResult
  ERRORS        {universalFailure}
  CODE          local: 280
}

SetRingerStatusArgument ::= SEQUENCE
{
  device          DeviceID,
  ringer          RingerID,
  ringMode        RingMode
  ringPattern     [1] IMPLICIT INTEGER
  ringVolume      [2] Volume
  extensions      CSTACCommonArguments
  OPTIONAL,
  OPTIONAL,
  OPTIONAL,
  OPTIONAL}

SetRingerStatusResult ::= CHOICE
{
  extensions      CSTACCommonArguments,
  noData          NULL}

-- At least one of the parameters ringMode, ringPattern and ringVolume
-- must be provided in the service request.

END -- of CSTA-set-ringer-status
```

19.1.22 Set speaker mute

```
CSTA-set-speaker-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-speaker-mute( 281) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setSpeakerMute OPERATION ::=
{
  ARGUMENT      SetSpeakerMuteArgument
  RESULT        SetSpeakerMuteResult
  ERRORS        {universalFailure}
  CODE          local: 281
}

SetSpeakerMuteArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID,
  speakerMuteOn   BOOLEAN,
  extensions      CSTACommonArguments OPTIONAL}

SetSpeakerMuteResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-speaker-mute
```

19.1.23 Set speaker volume

```
CSTA-set-speaker-volume
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-speaker-volume( 282) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, Volume FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setSpeakerVolume OPERATION ::=
{
  ARGUMENT      SetSpeakerVolumeArgument
  RESULT        SetSpeakerVolumeResult
  ERRORS        {universalFailure}
  CODE          local: 282
}

SetSpeakerVolumeArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID,
  speakerVolume   Volume,
  extensions      CSTACommonArguments OPTIONAL}

SetSpeakerVolumeResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-speaker-volume
```

19.2 Events

19.2.1 Button information

```
CSTA-button-information-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) button-information-event( 283) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

ButtonInformationEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                  SubjectDeviceID,
  button                  ButtonID,
  buttonLabel             IA5String (SIZE(0..64)) OPTIONAL,
  buttonAssociatedNumber  DeviceID              OPTIONAL,
  buttonPressIndicator    BOOLEAN              OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

-- At least one of the parameters buttonLabel, buttonPressIndicator and
-- buttonAssociatedNumber has to be provided.

END -- of CSTA-button-information-event
```


19.2.2 Button press

```
CSTA-button-press-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-press-event( 284) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

ButtonPressEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    device                  SubjectDeviceID,
    button                  ButtonID,
    buttonLabel             IA5String (SIZE(0..64))          OPTIONAL,
    buttonAssociatedNumber  DeviceID                          OPTIONAL,
    extensions              CSTACommonArguments              OPTIONAL}

-- At least one of the parameters buttonLabel and
-- buttonAssociatedNumber has to be provided.

END -- of CSTA-button-press-event
```

19.2.3 Display updated

```
CSTA-display-updated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) display-updated-event( 285) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
DisplayID, CharacterSet FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

DisplayUpdatedEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                  SubjectDeviceID,
  displayID               DisplayID          OPTIONAL,
  logicalRows             INTEGER,
  logicalColumns          INTEGER,
  physicalRows             [0] IMPLICIT INTEGER OPTIONAL,
  physicalColumns          [1] IMPLICIT INTEGER OPTIONAL,
  physicalBaseRowNumber    [2] IMPLICIT INTEGER OPTIONAL,
  physicalBaseColumnNumber [3] IMPLICIT INTEGER OPTIONAL,
  characterSet             CharSet            OPTIONAL,
  contentsOfDisplay        IA5String,
  extensions              CSTACommonArguments OPTIONAL}

-- The parameters physicalRows, physicalColumns, physicalBaseRowNumber and
-- physicalBaseColumnNumber are conditional. Refer to ECMA 269, clause 21.2.3
-- for conditions.

END -- of CSTA-display-updated-event
```

19.2.4 Hookswitch

```
CSTA-hookswitch-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) hookswitch-event( 286) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

HookswitchEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    device                  SubjectDeviceID,
    hookswitch              HookswitchID,
    hookswitchOnHook        BOOLEAN,
    extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-hookswitch-event
```

19.2.5 Lamp mode

```
CSTA-lamp-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) lamp-mode-event( 287) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
LampID, LampMode, LampBrightness, LampColor
FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

LampModeEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    device                 SubjectDeviceID,
    lamp                   LampID,
    lampLabel              OCTET STRING (SIZE(0..64))      OPTIONAL,
    lampMode               LampMode,
    lampBrightness         LampBrightness                  OPTIONAL,
    lampColor              LampColor                       OPTIONAL,
    extensions             CSTACommonArguments             OPTIONAL}

-- At least one of the parameters lampLabel, lampBrightness and lampColor
-- has to be provided.

END -- of CSTA-lamp-mode-event
```

19.2.6 Message waiting

```
CSTA-message-waiting-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) message-waiting-event( 44) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

MessageWaitingEvent ::=SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    targetDevice           SubjectDeviceID,
    deviceForMessage       DeviceID           OPTIONAL,
    messageWaitingOn       BOOLEAN,
    extensions             CSTACCommonArguments OPTIONAL}

END -- of CSTA-message-waiting-event
```

19.2.7 Microphone gain

```
CSTA-microphone-gain-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-gain-event( 288) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicrophoneGain FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

MicrophoneGainEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    invokingDevice         SubjectDeviceID,
    auditoryApparatus      AuditoryApparatusID,
    microphoneGain         MicrophoneGain,
    extensions             CSTACommonArguments    OPTIONAL}

END -- of CSTA-microphone-gain-event
```

19.2.8 Microphone mute

```
CSTA-microphone-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-mute-event( 45) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

MicrophoneMuteEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    invokingDevice         SubjectDeviceID,
    auditoryApparatus      AuditoryApparatusID,
    microphoneMuteOn       BOOLEAN,
    extensions              CSTACCommonArguments    OPTIONAL}

END -- of CSTA-microphone-mute-event
```

19.2.9 Ringer status

```
CSTA-ringer-status-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) ringer-status-event( 289) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode, Volume FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

RingerStatusEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                  SubjectDeviceID,
  ringer                  RingerID,
  ringMode                RingMode                OPTIONAL,
  ringCount               [0] IMPLICIT INTEGER (0..100)  OPTIONAL,
  ringPattern              [1] IMPLICIT INTEGER          OPTIONAL,
  ringVolume              [2] Volume                OPTIONAL,
  extensions               CSTACommonArguments          OPTIONAL}

-- At least one of the parameters ringMode, ringCount, ringPattern and
-- ringVolume must be provided.

END -- of CSTA-ringer-status-event
```


19.2.10 Speaker mute

```
CSTA-speaker-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-mute-event( 46) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

SpeakerMuteEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    invokingDevice         SubjectDeviceID,
    auditoryApparatus      AuditoryApparatusID,
    speakerMuteOn          BOOLEAN,
    extensions              CSTACCommonArguments OPTIONAL}

END -- of CSTA-speaker-mute-event
```

19.2.11 Speaker volume

```
CSTA-speaker-volume-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) speaker-volume-event( 47) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, Volume FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

SpeakerVolumeEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  invokingDevice          SubjectDeviceID,
  auditoryApparatus       AuditoryApparatusID,
  speakerVolume           Volume,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-speaker-volume-event
```

20 Logical device features

20.1 Services

20.1.1 Call back non-call-related

```
CSTA-call-back-non-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-non-call-related( 300) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackNonCallRelated OPERATION ::=
{
  ARGUMENT    CallBackNonCallRelatedArgument
  RESULT      CallBackNonCallRelatedResult
  ERRORS      {universalFailure}
  CODE        local: 300
}

CallBackNonCallRelatedArgument ::= SEQUENCE
{
  originatingDevice    DeviceID,
  targetDevice         DeviceID,
  extensions            CSTACommonArguments OPTIONAL}

CallBackNonCallRelatedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-call-back-non-call-related
```

20.1.2 Call back message non-call-related

```
CSTA-call-back-message-non-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-non-call-related( 301) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackMessageNonCallRelated OPERATION ::=
{
  ARGUMENT    CallBackMessageNonCallRelatedArgument
  RESULT      CallBackMessageNonCallRelatedResult
  ERRORS      {universalFailure}
  CODE        local: 301
}

CallBackMessageNonCallRelatedArgument ::= SEQUENCE
{
  originatingDevice    DeviceID,
  targetDevice         DeviceID,
  extensions            CSTACommonArguments OPTIONAL}

CallBackMessageNonCallRelatedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-call-back-message-non-call-related
```

20.1.3 Cancel call back

```
CSTA-cancel-call-back
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) cancel-call-back( 302) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

cancelCallBack OPERATION ::=
{
  ARGUMENT      CancelCallBackArgument
  RESULT        CancelCallBackResult
  ERRORS        {universalFailure}
  CODE          local: 302
}

CancelCallBackArgument ::= SEQUENCE
{
  originatingDevice      DeviceID,
  targetDevice            DeviceID,
  extensions              CSTACCommonArguments OPTIONAL}

CancelCallBackResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-cancel-call-back
```

20.1.4 Cancel call back message

```
CSTA-cancel-call-back-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) cancel-call-back-message( 303) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

cancelCallBackMessage OPERATION ::=
{
  ARGUMENT    CancelCallBackMessageArgument
  RESULT      CancelCallBackMessageResult
  ERRORS      {universalFailure}
  CODE        local: 303
}

CancelCallBackMessageArgument ::= SEQUENCE
{
  originatingDevice    DeviceID,
  targetDevice          DeviceID,
  extensions            CSTACommonArguments OPTIONAL}

CancelCallBackMessageResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-cancel-call-back-message
```

20.1.5 Get agent state

```
CSTA-get-agent-state
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-agent-state( 304) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentState, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getAgentState OPERATION ::=
{
  ARGUMENT    GetAgentStateArgument
  RESULT      GetAgentStateResult
  ERRORS      {universalFailure}
  CODE        local: 304
}

GetAgentStateArgument ::= SEQUENCE
{
  device      DeviceID,
  acdGroup    DeviceID                OPTIONAL,
  extensions  CSTACommonArguments    OPTIONAL}

GetAgentStateResult ::= SEQUENCE
{
  agentStateList      AgentStateList,
  extensions           CSTACommonArguments OPTIONAL}

AgentStateList ::= SEQUENCE SIZE (1..32) OF AgentStateEntry

AgentStateEntry ::= SEQUENCE
{
  agentID      AgentID                OPTIONAL,
  loggedOnState  BOOLEAN,
  agentInfo     SEQUENCE OF AgentInfo  OPTIONAL}

-- The parameter agentID is conditional. Refer to ECMA 269, 22.1.5 for
-- conditions.

AgentInfo ::= SEQUENCE
{
  acdGroup      DeviceID                OPTIONAL,
  agentState     AgentState,
  pendingAgentState  [0] IMPLICIT PendingAgentState  OPTIONAL,
  agentStateCondition  [1] IMPLICIT AgentStateCondition  OPTIONAL}

-- The parameters acdGroup and pendingAgentState are
-- conditional. Refer to ECMA 269, 22.1.5 for conditions.

AgentStateCondition ::= ENUMERATED
{
  forcedPause (0),
  other       (1)}

END -- of CSTA-get-agent-state
```

20.1.6 Get auto answer

```
CSTA-get-auto-answer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auto-answer( 305) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getAutoAnswer OPERATION ::=
{
  ARGUMENT    GetAutoAnswerArgument
  RESULT      GetAutoAnswerResult
  ERRORS      {universalFailure}
  CODE        local: 305
}

GetAutoAnswerArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACCommonArguments OPTIONAL}

GetAutoAnswerResult ::= SEQUENCE
{
  autoAnswerOn      BOOLEAN,
  numberOfRings      INTEGER          OPTIONAL,
  extensions         CSTACCommonArguments OPTIONAL}

END -- of CSTA-get-auto-answer
```


20.1.7 Get auto work mode

```
CSTA-get-auto-work-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auto-work-mode( 306) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getAutoWorkMode OPERATION ::=
{
  ARGUMENT    GetAutoWorkModeArgument
  RESULT      GetAutoWorkModeResult
  ERRORS      {universalFailure}
  CODE        local: 306
}

GetAutoWorkModeArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetAutoWorkModeResult ::= SEQUENCE
{
  autoWorkOn      BOOLEAN,
  autoWorkInterval INTEGER OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-get-auto-work-mode
```

20.1.8 Get caller id status

```
CSTA-get-caller-id-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-caller-id-status( 307) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getCallerIDStatus OPERATION ::=
{
  ARGUMENT    GetCallerIDStatusArgument
  RESULT      GetCallerIDStatusResult
  ERRORS      {universalFailure}
  CODE        local: 307
}

GetCallerIDStatusArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetCallerIDStatusResult ::= SEQUENCE
{
  callerIDProvided  BOOLEAN,
  extensions        CSTACommonArguments OPTIONAL}

END -- of CSTA-get-caller-id-status
```

20.1.9 Get do not disturb

```
CSTA-get-do-not-disturb
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-do-not-disturb( 308) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getDoNotDisturb OPERATION ::=
{
  ARGUMENT      GetDoNotDisturbArgument
  RESULT        GetDoNotDisturbResult
  ERRORS        {universalFailure}
  CODE          local: 308
}

GetDoNotDisturbArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetDoNotDisturbResult ::= SEQUENCE
{
  doNotDisturbOn      BOOLEAN,
  callOrigination      CallOrigination      OPTIONAL,
  callingDeviceList    SEQUENCE OF DeviceID  OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}

END -- of CSTA-get-do-not-disturb
```

20.1.10 Get forwarding

```
CSTA-get-forwarding
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-forwarding( 309) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ForwardList FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getForwarding OPERATION ::=
{
  ARGUMENT    GetForwardingArgument
  RESULT      GetForwardingResult
  ERRORS      {universalFailure}
  CODE        local: 309
}

GetForwardingArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetForwardingResult ::= SEQUENCE
{
  forwardingList ForwardList,
  extensions     CSTACommonArguments OPTIONAL}

END -- of CSTA-get-forwarding
```

20.1.11 Get last number dialed

```
CSTA-get-last-number-dialed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-last-number-dialed( 310) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getLastNumberDialed OPERATION ::=
{
  ARGUMENT    GetLastNumberDialedArgument
  RESULT      GetLastNumberDialedResult
  ERRORS      {universalFailure}
  CODE        local: 310
}

GetLastNumberDialedArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetLastNumberDialedResult ::= SEQUENCE
{
  numberDialed      DeviceID,
  extensions         CSTACommonArguments OPTIONAL}

END -- of CSTA-get-last-number-dialed
```

20.1.12 Get routing mode

```
CSTA-get-routeing-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-routeing-mode( 311) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getRouteingMode OPERATION ::=
{
  ARGUMENT    GetRouteingModeArgument
  RESULT      GetRouteingModeResult
  ERRORS      {universalFailure}
  CODE        local: 311
}

GetRouteingModeArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetRouteingModeResult ::= SEQUENCE
{
  routeingMode    BOOLEAN,
  extensions       CSTACommonArguments    OPTIONAL}

END -- of CSTA-get-routeing-mode
```

20.1.13 Set agent state

```
CSTA-set-agent-state
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-agent-state( 312) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentPassword, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setAgentState OPERATION ::=
{
  ARGUMENT      SetAgentStateArgument
  RESULT        SetAgentStateResult
  ERRORS        {universalFailure}
  CODE          local: 312
}

SetAgentStateArgument ::= SEQUENCE
{
  device          DeviceID,
  requestedAgentState  ReqAgentState,
  agentID         [2] IMPLICIT AgentID          OPTIONAL,
  password        [3] IMPLICIT AgentPassword     OPTIONAL,
  group           DeviceID                       OPTIONAL,
  extensions      CSTACommonArguments            OPTIONAL}

SetAgentStateResult ::= SEQUENCE
{
  pendingAgentState  PendingAgentState    OPTIONAL,
  extensions         CSTACommonArguments  OPTIONAL}

-- The parameters agentID, pendingAgentState and group are conditional.
-- Refer to ECMA 269, 22.1.13 for conditions.

ReqAgentState ::= ENUMERATED
{
  loggedOn          (0),
  loggedOff         (1),
  notReady          (2),
  ready             (3),
  workingAfterCall  (4)}

END -- of CSTA-set-agent-state
```

20.1.14 Set auto answer

```
CSTA-set-auto-answer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-auto-answer( 313) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setAutoAnswer OPERATION ::=
{
  ARGUMENT    SetAutoAnswerArgument
  RESULT      SetAutoAnswerResult
  ERRORS      {universalFailure}
  CODE        local: 313
}

SetAutoAnswerArgument ::= SEQUENCE
{
  device          DeviceID,
  autoAnswerOn    BOOLEAN,
  numberOfRings   INTEGER          OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

SetAutoAnswerResult ::= CHOICE
{
  extensions      CSTACommonArguments,
  noData          NULL}

END -- of CSTA-set-auto-answer
```


20.1.15 Set auto work mode

```
CSTA-set-auto-work-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-auto-work-mode( 314) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setAutoWorkMode OPERATION ::=
{
  ARGUMENT    SetAutoWorkModeArgument
  RESULT      SetAutoWorkModeResult
  ERRORS      {universalFailure}
  CODE        local: 314
}

SetAutoWorkModeArgument ::= SEQUENCE
{
  device          DeviceID,
  autoWorkOn      BOOLEAN,
  autoWorkInterval INTEGER (0..6000)    OPTIONAL,
  extensions      CSTACCommonArguments  OPTIONAL}

SetAutoWorkModeResult ::= CHOICE
{
  extensions CSTACCommonArguments,
  noData     NULL}

END -- of CSTA-set-auto-work-mode
```

20.1.16 Set caller id status

```
CSTA-set-caller-id-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-caller-id-status( 315) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setCallerIDStatus OPERATION ::=
{
  ARGUMENT      SetCallerIDStatusArgument
  RESULT        SetCallerIDStatusResult
  ERRORS        {universalFailure}
  CODE          local: 315
}

SetCallerIDStatusArgument ::= SEQUENCE
{
  device          DeviceID,
  callerIDProvided  BOOLEAN,
  extensions      CSTACCommonArguments OPTIONAL}

SetCallerIDStatusResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-set-caller-id-status
```

20.1.17 Set do not disturb

```
CSTA-set-do-not-disturb
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-do-not-disturb( 316) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setDoNotDisturb OPERATION ::=
{
  ARGUMENT    SetDoNotDisturbArgument
  RESULT      SetDoNotDisturbResult
  ERRORS      {universalFailure}
  CODE        local: 316
}

SetDoNotDisturbArgument ::= SEQUENCE
{
  device                DeviceID,
  doNotDisturbOn        BOOLEAN,
  callOrigination        CallOrigination    OPTIONAL,
  callingDeviceList      SEQUENCE OF DeviceID  OPTIONAL,
  extensions             CSTACommonArguments  OPTIONAL}

SetDoNotDisturbResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-do-not-disturb
```

20.1.18 Set forwarding

```
CSTA-set-forwarding
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-forwarding( 317) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ForwardingType FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setForwarding OPERATION ::=
{
  ARGUMENT      SetForwardingArgument
  RESULT        SetForwardingResult
  ERRORS        {universalFailure}
  CODE          local: 317
}

SetForwardingArgument ::= SEQUENCE
{
  device          DeviceID,
  forwardingType  ForwardingType          OPTIONAL,
  activateForward BOOLEAN,
  forwardDN       DeviceID                OPTIONAL,
  ringCount       INTEGER (1..100)        OPTIONAL,
  extensions      CSTACommonArguments     OPTIONAL}

SetForwardingResult ::= CHOICE
{
  extensions      CSTACommonArguments,
  noData          NULL}

-- The parameters forwardingType and forwardDN are conditional. Refer to
-- ECMA 269, 22.1.18 for conditions.

END -- of CSTA-set-forwarding
```

20.1.19 Set routing mode

```
CSTA-set-routeing-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-routeing-mode( 318) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setRouteingMode OPERATION ::=
{
  ARGUMENT      SetRouteingModeArgument
  RESULT        SetRouteingModeResult
  ERRORS        {universalFailure}
  CODE          local: 318
}

SetRouteingModeArgument ::= SEQUENCE
{
  device          DeviceID,
  routeingMode    BOOLEAN,
  extensions      CSTACCommonArguments OPTIONAL}

SetRouteingModeResult ::= CHOICE
{
  extensions      CSTACCommonArguments,
  noData          NULL}

END -- of CSTA-set-routeing-mode
```

20.2 Events

20.2.1 Agent busy

```
CSTA-agent-busy-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-busy-event( 319) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentBusyEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                AgentID                      OPTIONAL,
  acdGroup               DeviceID                      OPTIONAL,
  pendingAgentState      [2] IMPLICIT PendingAgentState OPTIONAL,
  cause                  [3] IMPLICIT EventCause       OPTIONAL,
  extensions             CSTACommonArguments          OPTIONAL}

-- The parameters agentID, acdGroup and pendingAgentState are conditional.
-- Refer to ECMA 269, 22.2.1 for conditions.

END -- of CSTA-agent-busy-event
```

20.2.2 Agent logged off

```
CSTA-agent-logged-off-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-logged-off-event( 320) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentLoggedOffEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                [2] IMPLICIT AgentID          OPTIONAL,
  acdGroup               DeviceID                      OPTIONAL,
  agentPassword          [3] IMPLICIT AgentPassword     OPTIONAL,
  cause                  EventCause                    OPTIONAL,
  extensions             CSTACommonArguments            OPTIONAL}

-- The parameters agentID and acdGroup are conditional.
-- Refer to ECMA 269, 22.2.2 for conditions.

END -- of CSTA-agent-logged-off-event
```

20.2.3 Agent logged on

```
CSTA-agent-logged-on-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-logged-on-event( 321) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentLoggedOnEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                [2] IMPLICIT AgentID          OPTIONAL,
  acdGroup               DeviceID                      OPTIONAL,
  agentPassword          [3] IMPLICIT AgentPassword     OPTIONAL,
  cause                  EventCause                    OPTIONAL,
  extensions              CSTACommonArguments           OPTIONAL}

-- The parameters agentID and acdGroup are conditional.
-- Refer to ECMA 269, 22.2.3 for conditions.

END -- of CSTA-agent-logged-on-event
```


20.2.4 Agent not ready

```
CSTA-agent-not-ready-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-not-ready-event( 322) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentNotReadyEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                AgentID              OPTIONAL,
  acdGroup               DeviceID              OPTIONAL,
  cause                  EventCause            OPTIONAL,
  extensions              CSTACCommonArguments OPTIONAL}

-- The parameters agentID and acdGroup are conditional.
-- Refer to ECMA 269, 22.2.4 for conditions.

END -- of CSTA-agent-not-ready-event
```

20.2.5 Agent ready

```
CSTA-agent-ready-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-ready-event( 323) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentReadyEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                AgentID              OPTIONAL,
  acdGroup               DeviceID              OPTIONAL,
  cause                  EventCause            OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

-- The parameters agentID and acdGroup are conditional.
-- Refer to ECMA 269, 22.2.5 for conditions.

END -- of CSTA-agent-ready-event
```

20.2.6 Agent working after call

```
CSTA-agent-working-after-call-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-working-after-call-event( 324) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
AgentID, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentWorkingAfterCallEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  agentDevice            SubjectDeviceID,
  agentID                AgentID                                OPTIONAL,
  acdGroup               DeviceID                                OPTIONAL,
  pendingAgentState      [2] IMPLICIT ENUMERATED
    {notReady (0),
     ready (1),
     null (2)}
  cause                  [3] IMPLICIT EventCause                OPTIONAL,
  extensions              CSTACommonArguments                    OPTIONAL}

-- The parameters agentID, acdGroup and pendingAgentState are conditional.
-- Refer to ECMA 269, 22.2.6 for conditions.

END -- of CSTA-agent-working-after-call-event
```

20.2.7 Auto answer

```
CSTA-auto-answer-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) auto-answer-event( 40) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AutoAnswerEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  invokingDevice         SubjectDeviceID,
  autoAnswerOn           BOOLEAN,
  numberOfRings          INTEGER          OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

END -- of CSTA-auto-answer-event
```

20.2.8 Auto work mode

```
CSTA-auto-work-mode-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) auto-work-mode-event( 326) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AutoWorkModeEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  invokingDevice         SubjectDeviceID,
  autoWorkOn             BOOLEAN,
  autoWorkInterval       INTEGER,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-auto-work-mode-event
```

20.2.9 Call back

```
CSTA-call-back-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-event( 327) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallBackEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  originatingDevice      SubjectDeviceID,
  targetDevice           SubjectDeviceID,
  callBackSetCanceled    BOOLEAN,
  extensions             CSTACommonArguments OPTIONAL}

END -- of CSTA-call-back-event
```

20.2.10 Call back message

```
CSTA-call-back-message-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-event( 328) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallBackMessageEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  originatingDevice      SubjectDeviceID,
  targetDevice           SubjectDeviceID,
  callBackMsgSetCanceled BOOLEAN,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-call-back-message-event
```

20.2.11 Caller id status

```
CSTA-caller-id-status-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) caller-id-status-event( 329) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallerIDStatusEvent ::= SEQUENCE
{
  device                DeviceID,
  callerIDProvided      BOOLEAN,
  extensions             CSTACommonArguments OPTIONAL}

END -- of CSTA-caller-id-status-event
```


20.2.12 Do not disturb

```
CSTA-do-not-disturb-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) do-not-disturb-event( 42) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

DoNotDisturbEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                 SubjectDeviceID,
  doNotDisturbOn         BOOLEAN,
  callOrigination        CallOrigination      OPTIONAL,
  callingDeviceList       SEQUENCE OF DeviceID OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-do-not-disturb-event
```

20.2.13 Forwarding

```
CSTA-forwarding-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) forwarding-event( 43) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
ForwardingType, ForwardDefault FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

ForwardingEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                  SubjectDeviceID,
  forwardingType          ForwardingType      OPTIONAL,
  forwardStatus           BOOLEAN,
  forwardTo               DeviceID            OPTIONAL,
  forwardDefault          ForwardDefault      OPTIONAL,
  ringCount              INTEGER (1..100)    OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-forwarding-event
```

20.2.14 Routeing mode

```
CSTA-routeing-mode-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) routeing-mode-event( 332) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

RouteingModeEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                 SubjectDeviceID,
  routeingMode           BOOLEAN,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-routeing-mode-event
```

21 Device maintenance events

21.1 Events

21.1.1 Back in service

```
CSTA-back-in-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) back-in-service-event( 333) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

BackInServiceEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    device                  SubjectDeviceID,
    cause                   EventCause          OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-back-in-service-event
```

21.1.2 Device capabilities changed

```
CSTA-device-capabilities-changed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-capabilities-changed-event( 334) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

DeviceCapsChangedEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                  SubjectDeviceID,
  cause                   EventCause          OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-device-capabilities-changed-event
```

21.1.3 Out of service

```
CSTA-out-of-service-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) out-of-service-event( 335) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorCrossRefID FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
;

OutOfServiceEvent ::= SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  device                 SubjectDeviceID,
  cause                  EventCause          OPTIONAL,
  extensions              CSTACCommonArguments  OPTIONAL}

END -- of CSTA-out-of-service-event
```

22 I/O services

22.1 Registration services

22.1.1 I/O register

```
CSTA-io-register
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) io-register( 340) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

ioRegister      OPERATION ::=
{
    ARGUMENT      IORegisterArgument
    RESULT        IORegisterResult
    ERRORS        {universalFailure}
    CODE          local: 340
}

IORegisterArgument ::= SEQUENCE
{
    ioDevice      DeviceID          OPTIONAL,
    extensions    CSTACommonArguments OPTIONAL}

IORegisterResult ::= SEQUENCE
{
    ioRegisterReqID      IORegisterReqID,
    extensions           CSTACommonArguments OPTIONAL}

-- The parameter ioDevice is conditional. Refer to ECMA 269, 24.1.1
-- for conditions.

END -- of CSTA-io-register
```

22.1.2 I/O register abort

```
CSTA-io-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) io-register-abort( 341) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

ioRegisterAbort      OPERATION ::=
{
    ARGUMENT          IORegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE              local: 341
}

IORegisterAbortArgument ::= SEQUENCE
{
    ioRegisterReqID      IORegisterReqID,
    extensions           CSTACommonArguments      OPTIONAL}

END -- of CSTA-io-register-abort
```


22.1.3 I/O register cancel

```
CSTA-io-register-cancel
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) io-register-cancel( 342) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

ioRegisterCancelOPERATION ::=
{
  ARGUMENT    IORegisterCancelArgument
  RESULT      IORegisterCancelResult
  ERRORS      {universalFailure}
  CODE        local: 342
}

IORegisterCancelArgument ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID,
  extensions            CSTACommonArguments    OPTIONAL}

IORegisterCancelResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData     NULL}

END -- of CSTA-io-register-cancel
```

22.2 Services

22.2.1 Data path resumed

```
CSTA-data-path-resumed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-path-resumed( 118) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

dataPathResumedOPERATION ::=
{
  ARGUMENT    DataPathResumedArgument
  RESULT      DataPathResumedResult
  ERRORS      { universalFailure }
  CODE        local: 118
}

DataPathResumedArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   IORegisterReqID      OPTIONAL,
  extensions        CSTACommonArguments  OPTIONAL}

DataPathResumedResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL }

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.1
-- for conditions.

END -- of CSTA-data-path-resumed
```

22.2.2 Data path suspended

```
CSTA-data-path-suspended
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-path-suspended( 116) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

dataPathSuspendedOPERATION ::=
{
  ARGUMENT    DataPathSuspendedArgument
  RESULT      DataPathSuspendedResult
  ERRORS      {universalFailure}
  CODE        local: 116
}

DataPathSuspendedArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioReqRegisterID   IORegisterReqID      OPTIONAL,
  extensions        CSTACommonArguments  OPTIONAL}

DataPathSuspendedResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL }

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.2
-- for conditions.

END -- of CSTA-data-path-suspended
```

22.2.3 Fast data

```
CSTA-fast-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) fast-data( 119) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
CSTAObject FROM CSTA-switching-function-objects
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta( 180) switching-function-objects( 122) }
DataPathType, IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

fastData
{
  ARGUMENT    FastDataArgument
  RESULT      FastDataResult
  ERRORS      {universalFailure}
  CODE        local: 119
}

FastDataArgument ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID          OPTIONAL,
  object                CSTAObject,
  dataPathType          DataPathType             OPTIONAL,
  displayAttributes     DisplayAttribute         OPTIONAL,
  ioData                OCTET STRING (SIZE(0..240)) OPTIONAL,
  extensions             CSTACommonArguments     OPTIONAL}

FastDataResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.3
-- for conditions.

DisplayAttribute ::= SEQUENCE
{
  displayID          DisplayID          OPTIONAL,
  physicalBaseRowNumber [0] IMPLICIT INTEGER OPTIONAL,
  physicalBaseColumnNumber [1] IMPLICIT INTEGER OPTIONAL,
  offset             [2] IMPLICIT INTEGER OPTIONAL}
-- The parameter displayID is conditional. Refer to ECMA 269, 24.2.3
-- for conditions.

END -- of CSTA-fast-data
```

22.2.4 Resume data path

```
CSTA-resume-data-path
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) resume-data-path( 117) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

resumeDataPath      OPERATION ::=
{
    ARGUMENT      ResumeDataPathArgument
    RESULT        ResumeDataPathResult
    ERRORS        {universalFailure}
    CODE          local: 117
}

ResumeDataPathArgument ::= SEQUENCE
{
    ioCrossRefID      IOCrossRefID,
    ioRegisterReqID   IORegisterReqID      OPTIONAL,
    extensions        CSTACommonArguments  OPTIONAL}

ResumeDataPathResult ::= CHOICE
{
    extensions        CSTACommonArguments,
    noData            NULL }

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.4
-- for conditions.

END -- of CSTA-resume-data-path
```

22.2.5 Send broadcast data

```
CSTA-send-broadcast-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-broadcast-data( 114) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DataPathType, DisplayAttributeList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendBroadcastData  OPERATION ::=
{
    ARGUMENT      SendBroadcastDataArgument
    RESULT        SendBroadcastDataResult
    ERRORS        {universalFailure}
    CODE          local: 114
}

SendBroadcastDataArgument ::= SEQUENCE
{
    ioData          OCTET STRING (SIZE(0..240)),
    dataPathType    DataPathType                      OPTIONAL,
    displayAttributes DisplayAttributeList              OPTIONAL,
    extensions       CSTACommonArguments                OPTIONAL}

SendBroadcastDataResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL}

END -- of CSTA-send-broadcast-data
```

22.2.6 Send data

```
CSTA-send-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-data( 112) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
IOCrossRefID, IORegisterReqID, DisplayAttributeList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendData          OPERATION ::=
{
    ARGUMENT      SendDataArgument
    RESULT        SendDataResult
    ERRORS        {universalFailure}
    CODE          local: 112
}

SendDataArgument ::= SEQUENCE
{
    ioCrossRefID      IOCrossRefID,
    ioRegisterReqID   [0] IMPLICIT IORegisterReqID      OPTIONAL,
    displayAttributes DisplayAttributeList              OPTIONAL,
    ioData            OCTET STRING (SIZE(0..240)),
    ioCause           EventCause                        OPTIONAL,
    extensions        CSTACommonArguments              OPTIONAL}

SendDataResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData     NULL}

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.6
-- for conditions.

END -- of CSTA-send-data
```

22.2.7 Send multicast data

```
CSTA-send-multicast-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-multicast-data( 113) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, DisplayAttributeList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendMulticastDataOPERATION ::=
{
    ARGUMENT      SendMulticastDataArgument
    RESULT        SendMulticastDataResult
    ERRORS        {universalFailure}
    CODE          local: 113
}

SendMulticastDataArgument ::= SEQUENCE
{
    ioCrossRefIDList      SEQUENCE OF IOCrossRefID,
    ioData                OCTET STRING (SIZE(0..240))          OPTIONAL,
    displayAttributes     DisplayAttributeList                 OPTIONAL,
    extensions            CSTACCommonArguments                 OPTIONAL}

SendMulticastDataResult ::= CHOICE
{
    extensions    CSTACCommonArguments,
    noData        NULL}

END -- of CSTA-send-multicast-data
```


22.2.8 Start data path

```
CSTA-start-data-path
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) start-data-path( 110) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTAObject FROM CSTA-switching-function-objects
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta( 180) switching-function-objects( 122) }
DataPathType, IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

startDataPathOPERATION ::=
{
    ARGUMENT      StartDataPathArgument
    RESULT        StartDataPathResult
    ERRORS        {universalFailure}
    CODE          local: 110
}

StartDataPathArgument ::= SEQUENCE
{
    ioRegisterReqID          IORegisterReqID          OPTIONAL,
    object                   CSTAObject,
    dataPathDirection        [0] IMPLICIT DataPathDirection  OPTIONAL,
    dataPathType              [1] IMPLICIT DataPathType        OPTIONAL,
    displayID                 DisplayID                  OPTIONAL,
    numberOfCharactersToCollect [2] IMPLICIT INTEGER           OPTIONAL,
    terminationCharacter       IA5String (SIZE(1..1))         OPTIONAL,
    timeout                   [3] IMPLICIT INTEGER           OPTIONAL,
    extensions                 CSTACommonArguments          OPTIONAL}

StartDataPathResult ::=SEQUENCE
{
    ioCrossRefID          IOCrossRefID,
    numberOfCharactersToCollect [0] IMPLICIT INTEGER  OPTIONAL,
    terminationCharacter       IA5String(SIZE(1..1))  OPTIONAL,
    timeout                    [1] IMPLICIT INTEGER  OPTIONAL,
    extensions                 CSTACommonArguments    OPTIONAL}

-- The parameters ioRegisterReqID and DisplayID are conditional. Refer to ECMA 269, 24.2.8
-- for conditions.

DataPathDirection ::= ENUMERATED
{
    computeFunctionToObject      (0),
    objectToComputeFunction      (1),
    bidirectional                 (2)}

END -- of CSTA-start-data-path
```

22.2.9 Stop data path

```
CSTA-stop-data-path
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop-data-path( 111) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

stopDataPathOPERATION ::=
{
  ARGUMENT      StopDataPathArgument
  RESULT        StopDataPathResult
  ERRORS        {universalFailure}
  CODE          local: 111
}

StopDataPathArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   IORegisterReqID      OPTIONAL,
  extensions        CSTACommonArguments  OPTIONAL}

StopDataPathResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.9
-- for conditions.

END -- of CSTA-stop-data-path
```

22.2.10 Suspend data path

```
CSTA-suspend-data-path
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-data-path( 115) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

suspendDataPathOPERATION ::=
{
    ARGUMENT    SuspendDataPathArgument
    RESULT      SuspendDataPathResult
    ERRORS      {universalFailure}
    CODE        local: 115
}

SuspendDataPathArgument ::= SEQUENCE
{
    ioCrossRefID      IOCrossRefID,
    ioRegisterReqID   IORegisterReqID      OPTIONAL,
    extensions        CSTACommonArguments  OPTIONAL}

SuspendDataPathResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL }

-- The parameter ioRegisterReqID is conditional. Refer to ECMA 269, 24.2.10
-- for conditions.

END -- of CSTA-suspend-data-path
```

23 Data Collection Services

23.1 Services

23.1.1 Data Collected

```
CSTA-data-collected
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collected( 343) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollected OPERATION ::=
{
  ARGUMENT    DataCollectedArgument
  RESULT      DataCollectedResult
  ERRORS      {universalFailure}
  CODE        local: 343
}

DataCollectedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  digitsData           [0] IMPLICIT DigitsData           OPTIONAL,
  telTonesData         [1] IMPLICIT TelTonesData         OPTIONAL,
  connectionInformation [2] IMPLICIT ConnectionInformation OPTIONAL,
  dcollCause           DcollCause                         OPTIONAL,
  extensions           CSTACommonArguments                OPTIONAL}

DataCollectedResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

-- The parameters digitsData and telTonesData are conditional. Refer to ECMA 269, 25.1.1
-- for conditions

DigitsData ::= SEQUENCE
{
  digitsDetected      IA5String (SIZE(0..64)),
  digitsDuration      [0] IMPLICIT SEQUENCE OF INTEGER  OPTIONAL,
  digitsPauseDuration [1] IMPLICIT SEQUENCE OF INTEGER  OPTIONAL}

TelTonesData ::= SEQUENCE
{
  toneDetected      ToneDetected,
  toneFrequency      [0] IMPLICIT INTEGER              OPTIONAL,
  toneDuration       [1] IMPLICIT INTEGER              OPTIONAL,
  tonePauseDuration  [2] IMPLICIT INTEGER              OPTIONAL}

ToneDetected ::= ENUMERATED
{
  beep              ( 0),
  billing            ( 1),
  busy               ( 2),
  carrier            ( 3),
  confirmation       ( 4),
  dial               ( 5),
```

```
faxCNG          ( 6),
hold            ( 7),
howler          ( 8),
intrusion       ( 9),
modemCNG        (10),
park            (11),
recordWarning   (12),
reorder         (13),
ringback        (14),
silence         (15),
sitVC           (16),
sitIC           (17),
sitRO           (18),
sitNC           (19),
other           (20)}

DcollCause ::= ENUMERATED
{
    flushCharReceived (0),
    charCountReached  (1),
    timeout            (2),
    sfTerminated       (3)}

END -- of CSTA-data-collected
```

23.1.2 Data Collection Resumed

```
CSTA-data-collection-resumed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collection-resumed( 344) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollectionResumed OPERATION ::=
{
  ARGUMENT    DataCollectionResumedArgument
  RESULT      DataCollectionResumedResult
  ERRORS      {universalFailure}
  CODE        local: 344
}

DataCollectionResumedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACommonArguments    OPTIONAL}

DataCollectionResumedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-data-collection-resumed
```

23.1.3 Data Collection Suspended

```
CSTA-data-collection-suspended
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collection-suspended( 345) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollectionSuspended OPERATION ::=
{
  ARGUMENT    DataCollectionSuspendedArgument
  RESULT      DataCollectionSuspendedResult
  ERRORS      {universalFailure}
  CODE        local: 345
}

DataCollectionSuspendedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACommonArguments    OPTIONAL}

DataCollectionSuspendedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-data-collection-suspended
```

23.1.4 Resume Data Collection

```
CSTA-resume-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) resume-data-collection( 346) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

resumeDataCollection OPERATION ::=
{
  ARGUMENT    ResumeDataCollectionArgument
  RESULT      ResumeDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 346
}

ResumeDataCollectionArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACommonArguments    OPTIONAL}

ResumeDataCollectionResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-resume-data-collection
```


23.1.5 Start Data Collection

```
CSTA-start-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) start-data-collection( 347) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

startDataCollection OPERATION ::=
{
  ARGUMENT    StartDataCollectionArgument
  RESULT      StartDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 347
}

StartDataCollectionArgument ::= SEQUENCE
{
  object          CallObject,
  dataCollType    DataCollType          OPTIONAL,
  digitsReportingCriteria DigitsReportingCriteria OPTIONAL,
  extensions      CSTACommonArguments    OPTIONAL}

StartDataCollectionResult ::= SEQUENCE
{
  dcollCrossRefID DcollCrossRefID,
  extensions      CSTACommonArguments    OPTIONAL}

CallObject ::= CHOICE
{
  device    DeviceID,
  call      ConnectionID}

DataCollType ::= ENUMERATED
{
  digits    (0),
  telTones  (1)}

DigitsReportingCriteria ::= SEQUENCE
{
  numChars  [0] IMPLICIT INTEGER    OPTIONAL,
  flushChar IA5String (SIZE(1..1))  OPTIONAL,
  timeout   [1] IMPLICIT INTEGER    OPTIONAL}

-- If the parameter digitsReportingCriteria is present, at least one of its
-- components has to be present.

END -- of CSTA-start-data-collection
```

23.1.6 Stop Data Collection

```
CSTA-stop-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop-data-collection( 348) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

stopDataCollection OPERATION ::=
{
  ARGUMENT      StopDataCollectionArgument
  RESULT        StopDataCollectionResult
  ERRORS        {universalFailure}
  CODE          local: 348
}

StopDataCollectionArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACCommonArguments      OPTIONAL}

StopDataCollectionResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-stop-data-collection
```

23.1.7 Suspend Data Collection

```
CSTA-suspend-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) suspend-data-collection( 349) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

suspendDataCollection OPERATION ::=
{
  ARGUMENT    SuspendDataCollectionArgument
  RESULT      SuspendDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 349
}

SuspendDataCollectionArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACommonArguments    OPTIONAL}

SuspendDataCollectionResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-suspend-data-collection
```

24 Voice unit services and events

24.1 Services

24.1.1 Concatenate message

```
CSTA-concatenate-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) concatenate-message( 500) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

concatenateMessage OPERATION ::=
{
    ARGUMENT    ConcatenateMessageArgument
    RESULT      ConcatenateMessageResult
    ERRORS      {universalFailure}
    CODE        local: 500
}

ConcatenateMessageArgument ::= SEQUENCE
{
    messagesToConcatenate SEQUENCE OF MessageID,
    extensions            CSTACommonArguments OPTIONAL}

ConcatenateMessageResult ::= SEQUENCE
{
    concatenatedMessage MessageID,
    extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-concatenate-message
```

24.1.2 Delete message

```
CSTA-delete-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) delete-message( 501) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

deleteMessageOPERATION ::=
{
    ARGUMENT    DeleteMessageArgument
    RESULT      DeleteMessageResult
    ERRORS      {universalFailure}
    CODE        local: 501
}

DeleteMessageArgument ::= SEQUENCE
{
    messageToBeDeleted    MessageID,
    extensions             CSTACommonArguments    OPTIONAL}

DeleteMessageResult ::=CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-delete-message
```

24.1.3 Play message

```
CSTA-play-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) play-message( 502) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID, TerminatingConditions FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

playMessage      OPERATION ::=
{
  ARGUMENT      PlayMessageArgument
  RESULT        PlayMessageResult
  ERRORS        {universalFailure}
  CODE          local: 502
}

PlayMessageArgument ::= SEQUENCE
{
  messageToBePlayed      MessageID,
  overConnection         ConnectionID,
  duration               INTEGER                OPTIONAL,
  termination            TerminatingConditions OPTIONAL,
  extensions             CSTACommonArguments   OPTIONAL}

PlayMessageResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData     NULL}

END -- of CSTA-play-message
```

24.1.4 Query voice attribute

```
CSTA-query-voice-attribute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) query-voice-attribute( 503) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
AttributeInfo, MessageID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

queryVoiceAttributeOPERATION ::=
{
  ARGUMENT    QueryVoiceAttributeArgument
  RESULT      QueryVoiceAttributeResult
  ERRORS      {universalFailure}
  CODE        local: 503
}

QueryVoiceAttributeArgument ::= SEQUENCE
{
  messageToQuery      MessageID,
  attributeToQuery     AttributeToQuery,
  connection           ConnectionID          OPTIONAL,
  extensions           CSTACCommonArguments  OPTIONAL}

QueryVoiceAttributeResult ::= SEQUENCE
{
  attribute           AttributeInfo,
  extensions          CSTACCommonArguments  OPTIONAL}

AttributeToQuery ::= ENUMERATED
{
  encodingAlgorithm    (0),
  samplingRate          (1),
  duration              (2),
  fileName              (3),
  currentPosition       (4),
  currentSpeed          (5),
  currentVolume         (6),
  currentLevel          (7),
  currentState          (8)
}
```

END -- of CSTA-query-voice-attribute

24.1.5 Record message

```
CSTA-record-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) record-message( 511) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID, EncodingAlgorithm, TerminatingConditions
    FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

recordMessageOPERATION ::=
{
    ARGUMENT    RecordMessageArgument
    RESULT      RecordMessageResult
    ERRORS      {universalFailure}
    CODE        local: 511
}

RecordMessageArgument ::= SEQUENCE
{
    callToBeRecorded      ConnectionID,
    samplingRate           [0] IMPLICIT INTEGER    OPTIONAL,
    encodingAlgorithm      EncodingAlgorithm        OPTIONAL,
    maxDuration            [1] IMPLICIT INTEGER    OPTIONAL,
    termination            TerminatingConditions  OPTIONAL,
    extensions             CSTACommonArguments      OPTIONAL}

RecordMessageResult ::= SEQUENCE
{
    resultingMessage      MessageID,
    extensions            CSTACommonArguments      OPTIONAL}

END -- of CSTA-record-message
```


24.1.6 Reposition

```
CSTA-reposition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) reposition( 504) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

reposition      OPERATION ::=
{
    ARGUMENT      RepositionArgument
    RESULT        RepositionResult
    ERRORS        {universalFailure}
    CODE          local: 504
}

RepositionArgument ::= SEQUENCE
{
    connection      ConnectionID,
    periodOfReposition      Period,
    messageToReposition      MessageID          OPTIONAL,
    extensions      CSTACCommonArguments      OPTIONAL}

RepositionResult ::= CHOICE
{
    extensions      CSTACCommonArguments,
    noData          NULL}

-- The parameter messageToReposition is conditional. Refer to ECMA 269, 26.1.6
-- for conditions.

Period ::= CHOICE
{
    absolutePosition      ENUMERATED
        {
            startOfMessage(0),
            endOfMessage(1)},
    relativePosition      INTEGER}

END -- of CSTA-reposition
```

24.1.7 Resume

```
CSTA-resume
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) resume( 505) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

resume
    OPERATION ::=
    {
        ARGUMENT    ResumeArgument
        RESULT      ResumeResult
        ERRORS      {universalFailure}
        CODE        local: 505
    }

ResumeArgument ::= SEQUENCE
{
    connection          ConnectionID,
    messageToResume     MessageID          OPTIONAL,
    duration            INTEGER              OPTIONAL,
    extensions           CSTACommonArguments OPTIONAL}

ResumeResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData     NULL}

-- The parameter messageToResume is conditional. Refer to ECMA 269, 26.1.7
-- for conditions.

END -- of CSTA-resume
```

24.1.8 Review

```
CSTA-review
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) review( 506) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

review
{
    ARGUMENT    ReviewArgument
    RESULT      ReviewResult
    ERRORS      {universalFailure}
    CODE        local: 506
}

ReviewArgument ::= SEQUENCE
{
    connection          ConnectionID,
    periodToReview      PeriodToReview,
    messageToReview     MessageID          OPTIONAL,
    extensions          CSTACommonArguments OPTIONAL}

ReviewResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData     NULL}

-- The parameter messageToReview is conditional. Refer to ECMA 269, 26.1.8
-- for conditions.

PeriodToReview ::= CHOICE
{
    startOfMessage      NULL,
    lengthOfReview      INTEGER}

END -- of CSTA-review
```

24.1.9 Set voice attribute

```
CSTA-set-voice-attribute
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) set-voice-attribute( 507) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
Volume FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setVoiceAttributeOPERATION ::=
{
    ARGUMENT      SetVoiveAttributeArgument
    RESULT        SetVoiveAttributeResult
    ERRORS        {universalFailure}
    CODE          local: 507
}

SetVoiveAttributeArgument ::= SEQUENCE
{
    connection      ConnectionID,
    attributeToSet   AttributeToSet,
    message          MessageID          OPTIONAL,
    extensions       CSTACommonArguments OPTIONAL}

SetVoiveAttributeResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL}

-- The parameter message is conditional. Refer to ECMA 269, 26.1.6
-- for conditions.

AttributeToSet ::= CHOICE
{
    currentSpeed      [0] IMPLICIT INTEGER,
    currentVolume     [1] Volume,
    currentGain        [2] IMPLICIT INTEGER (0 .. 100)}

END -- of CSTA-set-voice-attribute
```

24.1.10 Stop

```
CSTA-stop
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop( 508) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

stop
{
    ARGUMENT    StopArgument
    RESULT      StopResult
    ERRORS      {universalFailure}
    CODE        local: 508
}

StopArgument ::= SEQUENCE
{
    connection          ConnectionID,
    messageToBeStopped  MessageID
    extensions           CSTACommonArguments OPTIONAL,
                       OPTIONAL}

StopResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL}

-- The parameter messageToBeStopped is conditional. Refer to ECMA 269,
-- 26.1.10 for conditions.

END -- of CSTA-stop
```

24.1.11 Suspend

```
CSTA-suspend
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend( 509) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

suspend OPERATION ::=
{
    ARGUMENT      SuspendArgument
    RESULT        SuspendResult
    ERRORS        {universalFailure}
    CODE          local: 509
}

SuspendArgument ::= SEQUENCE
{
    connection    ConnectionID,
    message       MessageID
                  OPTIONAL,
    extensions    CSTACommonArguments    OPTIONAL}

SuspendResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

-- The parameter message is conditional. Refer to ECMA 269, 26.1.11
-- for conditions.

END -- of CSTA-suspend
```

24.1.12 Synthesize message

```
CSTA-synthesize-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) synthesize-message( 510) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ControlData, MessageID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

synthesizeMessage OPERATION ::=
{
  ARGUMENT    SynthesizeMessageArgument
  RESULT      SynthesizeMessageResult
  ERRORS      {universalFailure}
  CODE        local: 510
}

SynthesizeMessageArgument ::= SEQUENCE
{
  textToBeSynthesized    IA5String,
  control                 ControlData          OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

SynthesizeMessageResult ::= SEQUENCE
{
  synthesizedMessage      MessageID,
  extensions              CSTACommonArguments  OPTIONAL}

END -- of CSTA-synthesize-message
```

24.2 Events

24.2.1 Play

```
CSTA-play-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) play( 75) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) };

PlayEvent ::=SEQUENCE
{
  monitorCrossRefID      MonitorCrossRefID,
  connection             ConnectionID,
  message                MessageID,
  length                 [0] IMPLICIT INTEGER           OPTIONAL,
  currentPosition        [1] IMPLICIT INTEGER           OPTIONAL,
  speed                  [2] IMPLICIT INTEGER           OPTIONAL,
  cause                  EventCause                     OPTIONAL,
  servicesPermitted       ServicesPermitted              OPTIONAL,
  extensions              CSTACommonArguments            OPTIONAL}

END -- of CSTA-play-event
```


24.2.2 Record

```
CSTA-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) record( 76) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

RecordEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                MessageID,
    length                 [0] IMPLICIT INTEGER OPTIONAL,
    currentPosition        [1] IMPLICIT INTEGER OPTIONAL,
    cause                  EventCause OPTIONAL,
    servicesPermitted       ServicesPermitted OPTIONAL,
    extensions              CSTACCommonArguments OPTIONAL}

END -- of CSTA-record-event
```

24.2.3 Review

```
CSTA-review-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) review( 77) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

ReviewEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                MessageID,
    length                 [0] IMPLICIT INTEGER OPTIONAL,
    currentPosition        [1] IMPLICIT INTEGER OPTIONAL,
    cause                  EventCause OPTIONAL,
    servicesPermitted       ServicesPermitted OPTIONAL,
    extensions              CSTACCommonArguments OPTIONAL}

END -- of CSTA-review-event
```

24.2.4 Stop

```
CSTA-stop-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop( 78) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

StopEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                 MessageID,
    length                  [0] IMPLICIT INTEGER OPTIONAL,
    currentPosition        [1] IMPLICIT INTEGER OPTIONAL,
    cause                   EventCause OPTIONAL,
    servicesPermitted       ServicesPermitted OPTIONAL,
    extensions              CSTACCommonArguments OPTIONAL}

END -- of CSTA-stop-event
```

24.2.5 Suspend play

```
CSTA-suspend-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-play( 79) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

SuspendPlayEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                MessageID,
    length                 [0] IMPLICIT INTEGER OPTIONAL,
    currentPosition        [1] IMPLICIT INTEGER OPTIONAL,
    cause                  EventCause OPTIONAL,
    servicesPermitted       ServicesPermitted OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-suspend-play-event
```

24.2.6 Suspend record

```
CSTA-suspend-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-record( 80) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

SuspendRecordEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                MessageID,
    length                 [0] IMPLICIT INTEGER OPTIONAL,
    currentPosition        [1] IMPLICIT INTEGER OPTIONAL,
    cause                  EventCause OPTIONAL,
    servicesPermitted       ServicesPermitted OPTIONAL,
    extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-suspend-record-event
```

24.2.7 Voice attribute changed

```
CSTA-voice-attributes-change-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) voice-attributes-change-event( 74) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
Volume FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

VoiceAttributesChangeEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    connection             ConnectionID,
    message                MessageID,
    playVolume             [0] Volume OPTIONAL,
    recordingGain           [1] IMPLICIT INTEGER (0 .. 100) OPTIONAL,
    speed                  [2] IMPLICIT INTEGER OPTIONAL,
    currentPosition       [3] IMPLICIT INTEGER OPTIONAL,
    cause                  EventCause OPTIONAL,
    servicesPermitted      ServicesPermitted OPTIONAL,
    extensions             CSTACCommonArguments OPTIONAL}

END -- of CSTA-voice-attributes-change-event
```

25 Call detail record services

25.1 Services

25.1.1 Call detail records notification

```
CSTA-call-detail-records-notification
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-records-notification( 360) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRReason FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

CDRNotification OPERATION ::=
{
    ARGUMENT    CDRNotificationArgument
    RESULT      CDRNotificationResult
    ERRORS      {universalFailure}
    CODE        local: 360
}

CDRNotificationArgument ::= SEQUENCE
{
    cdrCrossRefID    CDRCrossRefID,
    cdrReason        CDRReason          OPTIONAL,
    extensions       CSTACommonArguments OPTIONAL}

CDRNotificationResult ::= CHOICE
{
    extensions       CSTACommonArguments,
    noData           NULL}

END -- of CSTA-call-detail-records-notification
```

25.1.2 Call detail records report

```
CSTA-call-detail-records-report
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-records-report( 361) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRInfo FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

CDRReport      OPERATION ::=
{
    ARGUMENT      CDRReportArgument
    RESULT        CDRReportResult
    ERRORS        {universalFailure}
    CODE          local: 361
}

CDRReportArgument ::= SEQUENCE
{
    cdrCrossRefID          CDRCrossRefID,
    numberOfRecordsSent    INTEGER (1..128),
    cdrInfo                CDRInfo,
    lastStoredCDRReportSent    BOOLEAN          OPTIONAL,
    extensions              CSTACCommonArguments    OPTIONAL}
-- The parameter lastStoredCDRReportSent is conditional. Refer to ECMA 269, 27.1.2
-- for conditions.

CDRReportResult ::= CHOICE
{
    extensions      CSTACCommonArguments,
    noData          NULL}

END -- of CSTA-call-detail-records-report
```


25.1.3 Send stored call detail records

```
CSTA-send-stored-call-detail-records
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-stored-call-detail-records( 362) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTIMEPERIOD FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

sendStoredCDR    OPERATION ::=
{
    ARGUMENT      SendStoredCDRArgument
    RESULT        SendStoredCDRResult
    ERRORS        {universalFailure}
    CODE          local: 362
}

SendStoredCDRArgument ::= SEQUENCE
{
    cdrCrossRefID  CDRCrossRefID,
    timePeriod     CDRTIMEPERIOD          OPTIONAL,
    extensions     CSTACCommonArguments   OPTIONAL}

SendStoredCDRResult ::= CHOICE
{
    extensions     CSTACCommonArguments,
    noData         NULL}

END -- of CSTA-send-stored-call-detail-records
```

25.1.4 Start call detail records transmission

```
CSTA-start-call-detail-records-transmission
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) start-call-detail-records-transmission( 363) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTransferMode FROM CSTA-call-detail-record
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-detail-record( 132) };

startCDRTransmission OPERATION ::=
{
  ARGUMENT    StartCDRTransmissionArgument
  RESULT      StartCDRTransmissionResult
  ERRORS      {universalFailure}
  CODE        local: 363
}

StartCDRTransmissionArgument ::= SEQUENCE
{
  transferMode    CDRTransferMode,
  extensions      CSTACommonArguments    OPTIONAL}

StartCDRTransmissionResult ::= SEQUENCE
{
  cdrCrossRefID   CDRCrossRefID,
  extensions      CSTACommonArguments    OPTIONAL}

END -- of CSTA-start-call-detail-records-transmission
```

25.1.5 Stop call detail records transmission

```
CSTA-stop-call-detail-records
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop-call-detail-records( 364) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTermReason FROM CSTA-stop-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

stopCDRTransmission      OPERATION ::=
{
    ARGUMENT      StopCDRTransmissionArgument
    RESULT        StopCDRTransmissionResult
    ERRORS        {universalFailure}
    CODE          local: 364
}

StopCDRTransmissionArgument ::= SEQUENCE
{
    cdrCrossRefID   CDRCrossRefID,
    cdrTermReason   CDRTermReason          OPTIONAL,
    extensions      CSTACCommonArguments   OPTIONAL}

StopCDRTransmissionResult ::= CHOICE
{
    extensions      CSTACCommonArguments,
    noData          NULL}

END -- of CSTA-stop-call-detail-records
```

26 Vendor specific extensions services and events

26.1 Registration services

26.1.1 Escape register

```
CSTA-escape-register
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-register( 365) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escapeRegister OPERATION ::=
{
    ARGUMENT      EscapeRegisterArgument
    RESULT        EscapeRegisterResult
    ERRORS        {universalFailure}
    CODE          local: 365
}

EscapeRegisterArgument ::= CHOICE
{
    extensions      CSTACCommonArguments,
    noData          NULL}

EscapeRegisterResult ::= SEQUENCE
{
    escapeRegisterID      EscapeRegisterID,
    extensions            CSTACCommonArguments      OPTIONAL}

END -- of CSTA-escape-register
```

26.1.2 Escape register abort

```
CSTA-escape-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-register-abort( 366) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escapeRegisterAbort OPERATION ::=
{
    ARGUMENT          EscapeRegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 366
}

EscapeRegisterAbortArgument ::= SEQUENCE
{
    escapeRegisterID    EscapeRegisterID,
    extensions          CSTACommonArguments    OPTIONAL}

END -- of CSTA-escape-register-abort
```

26.1.3 Escape register cancel

```
CSTA-escape-register-cancel
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-register-cancel( 367) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escapeRegisterCancel OPERATION ::=
{
    ARGUMENT    EscapeRegisterCancelArgument
    RESULT      EscapeRegisterCancelResult
    ERRORS      {universalFailure}
    CODE        local: 367
}

EscapeRegisterCancelArgument ::= SEQUENCE
{
    escapeRegisterID      EscapeRegisterID,
    extensions            CSTACommonArguments    OPTIONAL}

EscapeRegisterCancelResult ::= CHOICE
{
    extensions            CSTACommonArguments,
    noData                NULL}

END -- of CSTA-escape-register-cancel
```

26.2 Services

26.2.1 Escape

```
CSTA-escape-service
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) escape-service( 91) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTASecurityData FROM CSTA-security
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) security( 128) }
CSTACCommonArguments, CSTAPrivateData FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) escape-types( 135) };

escape OPERATION ::=
{
  ARGUMENT      EscapeArgument
  RESULT        EscapeResult
  ERRORS        {universalFailure}
  CODE          local: 51
}

EscapeArgument ::= SEQUENCE
{
  escapeRegisterID      EscapeRegisterID,
  security              CSTASecurityData      OPTIONAL,
  privateData           CSTAPrivateData
}

EscapeResult ::= CHOICE
{
  extensions          CSTACCommonArguments,
  noData              NULL}

END -- of CSTA-escape-register-cancel
```

26.2.2 Private data version selection

```
CSTA-private-data-version-selection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) private-data-version-selection( 368) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

privateDataVersionSelection OPERATION ::=
{
  ARGUMENT    PrivateDataVersionSelectionArgument
  RESULT      PrivateDataVersionSelectionResult
  ERRORS      {universalFailure}
  CODE        local: 368
}

PrivateDataVersionSelectionArgument ::= INTEGER

PrivateDataVersionSelectionResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-private-data-version-selection
```


26.3 Events

26.3.1 Private event

```
CSTA-private-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) private-event( 71) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
MonitorCrossRefID FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CSTASecurityData FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) }
CSTAPrivateData FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

PrivateEvent ::= SEQUENCE
{
    monitorCrossRefID      MonitorCrossRefID,
    security               CSTASecurityData      OPTIONAL,
    privateData            CSTAPrivateData
}
```

END -- of CSTA-private-event

Annex A

(normative)

Protocol Implementation Conformance Statement (PICS) Proforma

A.1 Introduction

The Protocol Implementation Conformance Statement (PICS) is a statement of which capabilities and options of the protocol have been implemented. The PICS can have a number of uses, including use:

- by the protocol implementor, as a check-list to reduce the risk of failure to conform to the standard through oversight;
- by the supplier and acquirer (or potential acquirer) of the implementation, as a detailed indication of the capabilities of the implementation, stated relative to the common basis for understanding provided by the standard PICS proforma;
- by the user (or potential user) of the implementation, as a basis for initially checking the possibility of interworking with another implementation (note that, while interworking cannot be guaranteed, failure to interwork can often be predicted from incompatible PICS);
- by a protocol tester, as the basis for selecting appropriate tests against which to assess the claim for conformance of the implementation.

A.2 Conformance

The supplier of a protocol implementation which is claimed to conform to ECMA-285 shall complete a copy of the Protocol Implementation Conformance Statement (PICS) proforma in A.5, "PICS proforma".

A.3 Instructions for completing the PICS proforma

The first part of the PICS proforma, the Implementation Identification (A.4, "Implementation identification", on page 308), is to be completed as indicated with the information necessary to identify fully both the supplier and the implementation.

The main part of the PICS proforma, A.5, "PICS proforma", is a fixed format questionnaire divided into subclauses each containing a group of individual items. These items represent options specified in ECMA-269 (mandatory items are not represented). Answers to the questionnaire items are to be provided in the appropriate columns by marking an answer to indicate a restricted choice (Yes or No), and optionally clarifying this response with a comment.

Where a service or event is not supported, as indicated by entering No for the first entry in a table, any parameters or dependent service components in the rest of that table are not applicable, it is then not necessary to complete items in any subsidiary entries in the table.

A.4 Implementation identification

Supplier	
Protocol Version	Phase III, First Edition
Date of Statement	
Contact point for queries about the PICS	
Implementation Name(s) and Version(s)	
Other information necessary for full identification - e.g. Name(s) and Version(s) for machines and/or operating systems; system name(s)	

The first five items are required for all implementations; other information may be completed as appropriate in meeting the requirement for full identification.

The terms Name and Version should be interpreted appropriately to correspond with a supplier's terminology (e.g. Type, Series, Model).

A.5 PICS proforma

A.5.1 CSTA Profiles

CSTA Profiles group together services and events, where each profile specifies a set of services and events that are supported by the implementation. Switching Function implementors shall indicate support for one or more profiles in the table below. Specifying support for a profile shall be accompanied by specifying support for the services and events encompassed by the profile, as well as any other services and events that the implementation supports.

Description: Profile(s) Supported	Supported?		Comments
	Yes	No	
Basic Telephony Profile			
Routeing Profile			

A.5.2 Capability Exchange Services

A.5.2.1 Get Logical Device Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Logical Device Information			
Service Request optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
groupDeviceAttributes			
namedDeviceTypes			
shortFormDeviceID			
agentLogOnModels			
appearanceList			
otherPhysicalDeviceList			
miscMonitorCaps			
associatedGroupList			
maxCallbacks			
maxAutoAnswerRings			
maxActiveCalls			
maxHeldCalls			
maxFwdSettings			
maxDevicesInConf			
transAndConfSetup			
deviceOnDeviceMonitorFilter			
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
mediaClassSupport			
mediaServiceCapsList			
connectionRateList			
delayToleranceList			
numberOfChannels			
maxChannelBind			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
routeingServList			
logDevServList			
logDevEvtsList			
deviceMaintEvtsList			
security			
privateData			

A.5.2.2 Get Physical Device Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Physical Device Information			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
groupDeviceAttributes			
namedDeviceTypes			
otherLogicalDeviceList			
deviceModelName			
deviceOnDeviceMonitorFilter			
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
maxDisplays			
maxButtons			
maxLamps			
maxRingPatterns			
physDevServList			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
physDevEvtsList			
security			
privateData			

A.5.2.3 Get Switching Function Capabilities

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Switching Function Capabilities			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
callCharacteristicsSupported			
mediaClassSupport			
numberOfChannels			
maxChannelBind			
miscMediaCallCharacteristics			
connectionRateList			
delayToleranceRateList			
pauseTime			
currentTime			
messageSeqNumbers			
timeStampMode			
securityMode			
securityFormat			
privateDataFormat			
transAndConfSetup			
deviceOnDeviceMonitorFilter			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
miscMonitorCaps			
correlatorDataSupported			
dynamicFeatureSupported			
acdModels			
agentLogonModels			
agentStateModels			
routeingServList			
logDevServList			
logDevEvtsList			
physDevServList			
physDevEvtsList			
deviceMaintEvtsList			
statusReportingServList			
capExchangeServList			
cdrServList			
vendorSpecificServList			
vendorSpecificEvtsList			
privateDataVersionList			
systemStatusTimer			
simpleThreshold			
filterThreshold			
mediaServiceCapsList			
security			
privateData			

A.5.2.4 Get Switching Function Devices

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Switching Function Devices			
Service Request optional parameters			
requestedDeviceID			
requestedDeviceCategory			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.2.5 Switching Function Devices

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Switching Function Devices			
Service Request optional parameters			
segmentID			
security			
privateData			

A.5.3 System Services

A.5.3.1 Change System Status Filter

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Change System Status Filter			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.3.2 System Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register			
Service Request optional parameters			
requestedStatusFilter			
security			
privateData			
Service Response optional parameters			
actualStatusFilter			
security			
privateData			

A.5.3.3 System Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register Abort			
Service Request optional parameters			
security			
privateData			

A.5.3.4 System Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.3.5 Request System Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Request System Status			
Service Request optional parameters			
sysStatRegisterID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.3.6 System Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Status			
Service Request optional parameters			
sysStatRegisterID			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

A.5.3.7 Switching Function Capabilities Changed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Switching Function Capabilities Changed			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.3.8 Switching Function Devices Changed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Switching Function Devices Changed			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.4 Monitoring Services

A.5.4.1 Change Monitor Filter

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Change Monitor Filter			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
actualFilterList			
security			
privateData			

A.5.4.2 Monitor Start

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Monitor Start			
Service Request optional parameters			
requestedMonitorFilter			
monitorType			
requestedMonitorMediaClass			
security			
privateData			
Service Response optional parameters			
actualMonitorFilter			
actualMonitorMediaClass			
monitorExistingCalls			
security			
privateData			

A.5.4.3 Monitor Stop

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Monitor Stop			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.5 Snapshot Services

A.5.5.1 Snapshot Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Snapshot Call			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
serviceCrossRefID			
snapshotData			
mediaCallCharacteristics			
callCharacteristics			
callingDevice			
calledDevice			
associatedCallingDevice			
associatedCalledDevice			
correlatorData			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.5.2 Snapshot Device

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Snapshot Device			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
serviceCrossRefID			
snapshotData			
security			
privateData			

A.5.5.3 Snapshot CallData

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Snapshot CallData			
Service Request optional parameters			
segmentID			
security			
privateData			

A.5.5.4 Snapshot DeviceData

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Snapshot DeviceData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Request optional parameters			
segmentID			
security			
privateData			

A.5.6 Call Control Services

A.5.6.1 Accept Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Accept Call			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.2 Alternate Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Alternate Call			
Service Request optional parameters			
connectionReservation			
consultOptions			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.6.3 Answer Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Answer Call			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.4 Call Back Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Back Call-Related			
Service Request optional parameters			
callCharateristics			
security			
privateData			
Service Response optional parameters			
targetDevice			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.6.5 Call Back Message Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Back Message Call-Related			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
targetDevice			
security			
privateData			

A.5.6.6 Camp On Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Camp On Call			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.7 Clear Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Clear Call			
Service Request optional parameters			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.8 Clear Connection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Clear Connection			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.9 Conference Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Conference Call			
Service Request optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
connections			
conferenceCallInfo			
security			
privateData			

A.5.6.10 Consultation Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Consultation Call			
Service Request optional parameters			
connectionReservation			
accountCode			
authCode			
correlatorData			
userData			
callCharacteristics			
mediaCallCharacteristics			
callingConnectionInfo			
consultOptions			
security			
privateData			
Service Response optional parameters			
mediaCallCharacteristics			
initiatedCallInfo			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.6.11 Deflect Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Deflect Call			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.12 Dial Digits

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Dial Digits			
Service Request optional parameters			
correlatorData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.13 Directed Pickup Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Directed Pickup Call			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
pickedCall			
pickedCallInfo			
security			
privateData			

A.5.6.14 Group Pickup Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Group Pickup Call			
Service Request optional parameters			
pickGroup			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
pickedCall			
pickedCallInfo			
security			
privateData			

A.5.6.15 Hold Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Hold Call			
Service Request optional parameters			
connectionReservation			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.16 Intrude Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Intrude Call			
Service Request optional parameters			
participationType			
userData			
security			
privateData			
Service Response optional parameters			
conferencedCall			
conferencedCallInfo			
security			
privateData			

A.5.6.17 Join Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Join Call			
Service Request optional parameters			
autoOriginate			
participationType			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
conferencedCallInfo			
security			
privateData			

A.5.6.18 Make Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Make Call			
Service Request optional parameters			
accountCode			
authCode			
autoOriginate			
correlatorData			
userData			
callCharacteristics			
medaCallCharacteristics			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
callingConnectionInfo			
security			
privateData			
Service Response optional parameters			
mediaCallCharacteristics			
initiatedCallInfo			
security			
privateData			

A.5.6.19 Make Predictive Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Make Predictive Call			
Service Request optional parameters			
signallingDetection			
destinationDetection			
defaultAction			
accountCode			
authCode			
autoOriginate			
alertTime			
correlatorData			
callCharacteristics			
userData			
security			
privateData			
Service Response optional parameters			
initiatedCallInfo			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			

A.5.6.20 Park Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Park Call			
Service Request optional parameters			
correlatorData			
security			
privateData			
Service Response optional parameters			
parkedTo			
security			
privateData			

A.5.6.21 Reconnect Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Reconnect Call			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.22 Retrieve Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Retrieve Call			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.6.23 Single Step Conference Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Single Step Conference Call			
Service Request optional parameters			
participationType			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
conferencedCallInfo			
security			
privateData			

A.5.6.24 Single Step Transfer Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Single Step Transfer Call			
Service Request optional parameters			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
connections			
transferredCallInfo			
security			
privateData			

A.5.6.25 Transfer Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Transfer Call			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
connections			
transferredCallInfo			
security			
privateData			

A.5.7 Call Control Events

A.5.7.1 Bridged

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Bridged			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
bridgedConnectionInfo			
security			
privateData			

A.5.7.2 Call Cleared

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Call Cleared			
correlatorData			
userData			
mediaCallCharacteristics			
callCharacteristics			
security			
privateData			

A.5.7.3 Conferenced

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Conferenced			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
secondaryOldCall			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
security			
privateData			

A.5.7.4 Connection Cleared

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Connection Cleared			
localConnectionInfo			
correlatorData			
userData			
chargingInfo			
servicesPermitted			
mediaCallCharateristics			
callCharacteristics			
droppedConnectionInfo			
security			
privateData			

A.5.7.5 Delivered

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Delivered			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
connectionInfo			
security			
privateData			

A.5.7.6 Digits Dialed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Digits Dialed			
localConnectionInfo			
correlatorData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
diallingConnectionInfo			
callCharacteristics			
security			
privateData			

A.5.7.7 Diverted

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Diverted			
callingDevice			
calledDevice			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
connectionInfo			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
security			
privateData			

A.5.7.8 Established

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Established			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
establishConnectionInfo			
security			
privateData			

A.5.7.9 Failed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Failed			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
failedConnectionInfo			
security			
privateData			

A.5.7.10 Held

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Held			
localConnectionInfo			
correlatorData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
heldConnectionInfo			
security			
privateData			

A.5.7.11 Network Capabilities Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Network Capabilities Changed			
localConnectionInfo			
correlatorData			
userData			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
networkCapability			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
outboundConnectionInfo			
security			
privateData			

A.5.7.12 Network Reached

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Network Reached			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
networkCapability			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
outboundConnectionInfo			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
security			
privateData			

A.5.7.13 Offered

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Offered			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
offeredConnectionInfo			
security			
privateData			

A.5.7.14 Originated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Originated			
originatingDevice			
localConnectionInfo			
correlatorData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
originatedConnectionInfo			
security			
privateData			

A.5.7.15 Queued

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Queued			
numberQueued			
callsInFront			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
queuedConnectionInfo			
security			
privateData			

A.5.7.16 Retrieved

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Retrieved			
localConnectionInfo			
correlatorData			
servicePermitted			
mediaCallCharacteristics			
callCharacteristics			
retrievedConnectionInfo			
security			
privateData			

A.5.7.17 Service Initiated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Service Initiated			
localConnectionInfo			
correlatorData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
initiatedConnectionInfo			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
security			
privateData			

A.5.7.18 Transferred

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Transferred			
secondaryOldCall			
localConnectionInfo			
correlatorData			
userData			
chargingInfo			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
security			
privateData			

A.5.8 Call Associated Feature Services

A.5.8.1 Associate Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Associate Data			
Service Request optional parameters			
accountCode			
authCode			
correlatorData			
callQualifyingData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.8.2 Cancel Telephony Tones

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Cancel Telephony Tones			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.8.3 Generate Digits

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Generate Digits			
Service Request optional parameters			
digitMode			
toneDuration			
pulseRate			
pauseDuration			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.8.4 Generate Telephony Tones

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Generate Telephony Tones			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Request optional parameters			
toneDuration			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.8.5 Send User Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send User Information			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.9 Call Associated Feature Events

A.5.9.1 Call Information

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Call Information			
callingDevice			
accountInfo			
authorisationCode			
correlatorData			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
servicesPermitted			
userData			
callQualifyingData			
connectionInfo			
security			
privateData			

A.5.9.2 Charging

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Charging			
cause			
security			
privateData			

A.5.9.3 Digits Generated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Digits Generated			
digitDurationList			
pauseDurationList			
connectionInfo			
security			
privateData			

A.5.9.4 Telephony Tones Generated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Telephony Tones Generated			
toneGenerated			
toneFrequency			
toneDuration			
pauseDuration			
connectionInfo			
security			
privateData			

A.5.9.5 Service Completion Failure

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Service Completion Failure			
secondaryCall			
otherDevicesPrimaryCallList			
otherDevicesSecondaryCallList			
mediaCallCharacteristics			
security			
privateData			

A.5.10 Media Attachment Services

A.5.10.1 Attach Media Service

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Attach Media Service			
Service Request optional parameters			
mediaServiceVersion			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
mediaServiceInstanceID			
requestedConnectionState			
security			
privateData			
Service Response optional parameters			
mediaConnection			
mediaDevice			
mediaServiceInstanceID			
mediaConnectionInfo			
security			
privateData			

A.5.10.2 Detach Media Service

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Detach Media Service			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.11 Media Attachment Events

A.5.11.1 Media Attached

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Media Attached			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
mediaServiceVersion			
mediaServiceInstanceID			
mediaStreamID			
mediaCallCharacteristics			
callCharacteristics			
localConnectionInfo			
mediaConnectionInfo			
security			
privateData			

A.5.11.2 Media Detached

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Media Detached			
mediaServiceVersion			
mediaServiceInstanceID			
mediaStreamID			
mediaCallCharacteristics			
callCharacteristics			
localConnectionInfo			
mediaConnectionInfo			
security			
privateData			

A.5.12 Routeing Services

A.5.12.1 Route Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Register			
Service Request optional parameters			
routeingDevice			
requestedRouteingMediaClass			
security			
privateData			
Service Response optional parameters			
actualRouteingMediaClass			
security			
privateData			

A.5.12.2 Route Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Register Abort			
Service Request optional parameters			
security			
privateData			

A.5.12.3 Route Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Register Cancel			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.12.4 Re-Route

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Re-Route			
Service Request optional parameters			
routeRegisterReqID			
replyTimeout			
correlatorData			
security			
privateData			

A.5.12.5 Route End

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route End			
Service Request optional parameters			
routeRegisterReqID			
errorValue			
correlatorData			
security			
privateData			

A.5.12.6 Route Reject

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Reject			
Service Request optional parameters			
routeRegisterReqID			
rejectCause			
correlatorData			
security			
privateData			

A.5.12.7 Route Request

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Request			
Service Request optional parameters			
routeRegisterReqID			
callingDevice			
routeingDevice			
routedCall			
routeSelAlgorithm			
associatedCallingDevice			
associatedCalledDevice			
priority			
replyTimeout			
correlatorData			
mediaCallCharacteristics			
callCharacteristics			
routedCallInfo			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.12.8 Route Select

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Select			
Service Request optional parameters			
routeRegisterReqID			
alternateRoutes			
remainRetries			
routeUsedReq			
correlatorData			
security			
privateData			

A.5.12.9 Route Used

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Used			
Service Request optional parameters			
routeRegisterReqID			
callingDevice			
domain			
correlatorData			
security			
privateData			

A.5.13 Physical Device Services

A.5.13.1 Button Press

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Button Press			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.2 Get Auditory Apparatus Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Auditory Apparatus Information			
Service Request optional parameters			
auditoryApparatus			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.3 Get Button Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Button Information			
Service Request optional parameters			
button			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.4 Get Display

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Display			
Service Request optional parameters			
displayID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.5 Get HookSwitch Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get HookSwitch Status			
Service Request optional parameters			
hookswitch			
security			
privateData			
Service Response optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.13.6 Get Lamp Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Lamp Information			
Service Request optional parameters			
lamp			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.7 Get Lamp Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Lamp Mode			
Service Request optional parameters			
lamp			
security			
privateData			
Service Response optional parameters			
lamp			
security			
privateData			

A.5.13.8 Get Message Waiting Indicator

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Message Waiting Indicator			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
deviceForMessage			
lampIsPresent			
security			
privateData			

A.5.13.9 Get Microphone Gain

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Microphone Gain			
Service Request optional parameters			
auditoryApparatus			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.10 Get Microphone Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Microphone Mute			
Service Request optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
auditoryApparatus			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.11 Get Ringer Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Ringer Status			
Service Request optional parameters			
ringer			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.12 Get Speaker Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Speaker Mute			
Service Request optional parameters			
auditoryApparatus			
security			
privateData			
Service Response optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			

A.5.13.13 Get Speaker Volume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Speaker Volume			
Service Request optional parameters			
auditoryApparatus			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.14 Set Button Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Button Information			
Service Request optional parameters			
buttonLabel			
buttonAssociatedNumber			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.15 Set Display

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Display			
Service Request optional parameters			
displayID			
physicalBaseRowNumber			
physicalBaseColumnNumber			
offset			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.16 Set HookSwitch Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set HookSwitch Status			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.17 Set Lamp Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Lamp Mode			
Service Request optional parameters			
lampBrightness			
lampColor			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.18 Set Message Waiting Indicator

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Message Waiting Indicator			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.19 Set Microphone Gain

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Microphone Gain			
Service Request optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.20 Set Microphone Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Microphone Mute			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.21 Set Ringer Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Ringer Status			
Service Request optional parameters			
ringMode			
ringPattern			
ringVolume			
security			
privateData			
Service Response optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.13.22 Set Speaker Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Speaker Mute			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.13.23 Set Speaker Volume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Speaker Volume			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.14 Physical Device Events

A.5.14.1 Button Information

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Button Information			
buttonLabel			
buttonAssociatedNumber			
buttonPressIndicator			
security			
privateData			

A.5.14.2 Button Press

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Button Press			
buttonLabel			
buttonAssociatedNumber			
security			
privateData			

A.5.14.3 Display Updated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Display Updated			
displayID			
physicalRows			
physicalColumns			
physicalBaseRowNumber			
physicalBaseColumnNumber			
characterSet			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			

A.5.14.4 Hookswitch

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Hookswitch			
security			
privateData			

A.5.14.5 Lamp Mode

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Lamp Mode			
lampLabel			
lampBrightness			
lampColor			
security			
privateData			

A.5.14.6 Message Waiting

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Message Waiting			
deviceForMessage			
security			
privateData			

A.5.14.7 Microphone Gain

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Microphone Gain			
security			
privateData			

A.5.14.8 Microphone Mute

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Microphone Mute			
security			
privateData			

A.5.14.9 Ringer Status

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Ringer Status			
ringMode			
ringCount			
ringPattern			
ringVolume			
security			
privateData			

A.5.14.10 Speaker Mute

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Speaker Mute			
security			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.14.11 Speaker Volume

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Speaker Volume			
timeStamp			
security			
privateData			

A.5.15 Logical Device Services

A.5.15.1 Call Back Non-Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Back Non-Call-Related			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.2 Call Back Message Non-Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Back Message Non-Call-Related			
Service Request optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.3 Cancel Call Back

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Cancel Call Back			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.4 Cancel Call Back Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Cancel Call Back Message			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.5 Get Agent State

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Agent State			
Service Request optional parameters			
acdGroup			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.6 Get Auto Answer

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Auto Answer			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
numberOfRings			
security			
privateData			

A.5.15.7 Get Auto Work Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Auto Work Mode			
Service Request optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
autoWorkInterval			
security			
privateData			

A.5.15.8 Get Caller ID Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Caller ID Status			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.9 Get Do Not Disturb

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Do Not Disturb			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
callOrigination			
callingDeviceList			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			

A.5.15.10 Get Forwarding

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Forwarding			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.11 Get Last Number Dialed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Last Number Dialed			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.12 Get Routeing Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Routeing Mode			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.13 Set Agent State

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Agent State			
Service Request optional parameters			
agentID			
password			
group			
security			
privateData			
Service Response optional parameters			
pendingAgentState			
security			
privateData			

A.5.15.14 Set Auto Answer

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Auto Answer			
Service Request optional parameters			
numberOfRings			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.15 Set Auto Work Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Auto Work Mode			
Service Request optional parameters			
autoWorkInterval			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.16 Set Caller ID Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Caller ID Status			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.17 Set Do Not Disturb

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Do Not Disturb			
Service Request optional parameters			
callOrigination			
callingDeviceList			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.18 Set Forwarding

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Forwarding			
Service Request optional parameters			
forwardingType			
forwardDN			
ringCount			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.15.19 Set Routeing Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Routeing Mode			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.16 Logical Device Events

A.5.16.1 Agent Busy

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Busy			
agentID			
acdGroup			
pendingAgentState			
cause			
security			
privateData			

A.5.16.2 Agent Logged Off

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Logged Off			
agentID			
acdGroup			
agentPassword			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
cause			
security			
privateData			

A.5.16.3 Agent Logged On

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Logged On			
agentID			
acdGroup			
agentPassword			
cause			
security			
privateData			

A.5.16.4 Agent Not Ready

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Not Ready			
agentID			
acdGroup			
cause			
security			
privateData			

A.5.16.5 Agent Ready

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Ready			
agentID			
acdGroup			
cause			
security			
privateData			

A.5.16.6 Agent Working After Call

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Working After Call			
agentID			
acdGroup			
pendingAgentState			
cause			
security			
privateData			

A.5.16.7 Auto Answer

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Auto Answer			
numberOfRings			
security			
privateData			

A.5.16.8 Auto Work Mode

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Auto Work Mode			
security			
privateData			

A.5.16.9 Call Back

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Call Back			
security			
privateData			

A.5.16.10 Call Back Message

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Call Back Message			
security			
privateData			

A.5.16.11 Caller ID Status

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Caller ID Status			
security			
privateData			

A.5.16.12 Do Not Disturb

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Do Not Disturb			
callOrigination			
callingDeviceList			
security			
privateData			

A.5.16.13 Forwarding

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Forwarding			
forwardingType			
forwardTo			
forwardDefault			
ringCount			
security			
privateData			

A.5.16.14 Routeing Mode

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Routeing Mode			
security			
privateData			

A.5.17 Device Maintenance Events

A.5.17.1 Back In Service

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Back In Service			
cause			
security			
privateData			

A.5.17.2 Device Capabilities Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Device Capabilities Changed			
cause			
security			
privateData			

A.5.17.3 Out of Service

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Out of Service			
cause			
security			
privateData			

A.5.18 I/O Services

A.5.18.1 I/O Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
I/O Register			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Request optional parameters			
ioDevice			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.2 I/O Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
I/O Register Abort			
Service Request optional parameters			
security			
privateData			

A.5.18.3 I/O Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
I/O Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.4 Data Path Resumed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Path Resumed			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.5 Data Path Suspended

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Path Suspended			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.6 Fast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Fast Data			
Service Request optional parameters			
ioRegisterReqID			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
dataPathType			
displayAttributes			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.7 Resume Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Resume Data Path			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.8 Send Broadcast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send Broadcast Data			
Service Request optional parameters			
dataPathType			
displayAttributes			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.9 Send Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send Data			
Service Request optional parameters			
ioRegisterReqID			
displayAttributes			
ioCause			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.10 Send Multicast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send Multicast Data			
Service Request optional parameters			
ioData			
displayAttributes			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.18.11 Start Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Start Data Path			
Service Request optional parameters			
ioRegisterReqID			
dataPathDirection			
dataPathType			
displayID			
numberOfCharsToCollect			
terminationCharacter			
timeout			
security			
privateData			
Service Response optional parameters			
numberOfCharsToCollect			
terminationCharacter			
timeout			
security			
privateData			

A.5.18.12 Stop Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Stop Data Path			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.18.13 Suspend Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Suspend Data Path			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19 Data Collection Services

A.5.19.1 Data Collected

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Collected			
Service Request optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
digitsData			
telTonesData			
connectionInfo			
dcollCause			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19.2 Data Collection Resumed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Collection Resumed			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19.3 Data Collection Suspended

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Collection Suspended			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.19.4 Resume Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Resume Data Collection			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19.5 Start Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Start Data Collection			
Service Request optional parameters			
dataCollType			
digitsReportingCriteria			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19.6 Stop Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Stop Data Collection			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.19.7 Suspend Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Suspend Data Collection			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20 Voice Unit Services

A.5.20.1 Concatenate Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Concatenate Message			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

A.5.20.2 Delete Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Delete Message			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.3 Play Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Play Message			
Service Request optional parameters			
duration			
termination			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.4 Query Voice Attribute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Query Voice Attribute			
Service Request optional parameters			
connection			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.5 Record Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Record Message			
Service Request optional parameters			
samplingRate			
encodingAlgorithm			
maxDuration			
termination			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.6 Reposition

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Reposition			
Service Request optional parameters			
messageToReposition			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.7 Resume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Resume			
Service Request optional parameters			
messageToResume			
duration			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.8 Review

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Review			
Service Request optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
messageToReview			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.9 Set Voice Attribute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Voice Attribute			
Service Request optional parameters			
message			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.10 Stop

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Stop			
Service Request optional parameters			
messageToBeStopped			
security			
privateData			
Service Response optional parameters			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			

A.5.20.11 Suspend

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Suspend			
Service Request optional parameters			
message			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.20.12 Synthesize Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Synthesize Message			
Service Request optional parameters			
control			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.21 Voice Unit Events

A.5.21.1 Play

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Play			
length			
currentPosition			
speed			
cause			
servicesPermitted			
security			
privateData			

A.5.21.2 Record

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Record			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

A.5.21.3 Review

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Review			
length			
currentPosition			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
cause			
servicesPermitted			
security			
privateData			

A.5.21.4 Stop

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Stop			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

A.5.21.5 Suspend Play

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Suspend Play			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

A.5.21.6 Suspend Record

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Suspend Record			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

A.5.21.7 Voice Attribute Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Voice Attribute Changed			
playVolume			
recordingGain			
speed			
currentPosition			
cause			
security			
privateData			

A.5.22 Call Detail Record (CDR) Services

A.5.22.1 Call Detail Records Notification

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Detail Records Notification			
Service Request optional parameters			
cdrReason			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.22.2 Call Detail Records Report

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Detail Records Report			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.22.3 Send Stored Call Detail Records

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send Stored Call Detail Records			
Service Request optional parameters			
timePeriod			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.22.4 Start Call Detail Records Transmission

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Start Call Detail Records Transmission			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.22.5 Stop Call Detail Records Transmission

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Stop Call Detail Records Transmission			
Service Request optional parameters			
cdrTermReason			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.23 Vendor Specific Extension Services

A.5.23.1 Escape Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Escape Register			
Service Request optional parameters			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

A.5.23.2 Escape Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Escape Register Abort			
Service Request optional parameters			
security			
privateData			

A.5.23.3 Escape Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Escape Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

A.5.23.4 Escape

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Escape			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Request optional parameters			
escapeRegisterID			
security			
Service Response optional parameters			
security			
privateData			

A.5.23.5 Private Data Version Selection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Private Data Version Selection			
Service Response optional parameters			
security			
privateData			

A.5.24 Vendor Specific Extension Events

A.5.24.1 Private Event

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Private Event			
security			

Printed copies can be ordered from:

ECMA
114 Rue du Rhône
CH-1204 Geneva
Switzerland

Fax: +41 22 849.60.01
Internet: documents@ecma.ch

Files can be downloaded from our FTP site, **ftp.ecma.ch**, logging in as **anonymous** and giving your E-mail address as **password**. This Standard is available from library **ECMA-ST** as an Acrobat PDF file (file E285-PDF.PDF). File E285-EXP.TXT gives a short presentation of the Standard.

Our web site, <http://www.ecma.ch>, gives full information on ECMA, ECMA activities, ECMA Standards and Technical Reports.

ECMA

**114 Rue du Rhône
CH-1204 Geneva
Switzerland**

This Standard ECMA-285 is available free of charge in printed form and as a file.

See inside cover page for instructions